

TABLE OF CONTENTS

<u>Paragraph</u>	<u>Page</u>
<u>SECTION I - GENERAL DESCRIPTION</u>	
1. General	1
2. Reference Data.	1
a. Apparatus Included With Standard Shipment	1
b. Frequency Response.	2
c. Input Impedance	2
d. Input Level	2
e. Output Impedance.	2
f. Output Level.	2
g. Compression Ratio	2
h. Operate Time.	2
i. Release Time.	2
j. Distortion.	2
k. Hum and Noise	2
l. Power Source.	2
3. Vacuum Tube Complement.	2
<u>SECTION II - THEORY OF OPERATION</u>	
1. Mechanical Theory	3
2. Electrical Theory	3
a. General	3
b. Input Amplifier	3
c. Limiter Circuit	3
d. Output Amplifier Stages	5
e. Metering Circuits	5
f. Power Supply Circuits	5
<u>SECTION III - INSTALLATION AND INITIAL ADJUSTMENT</u>	
1. Installation.	9
a. Preliminary	9
b. Installation Procedure.	9
2. Initial Adjustments10
a. General10
b. Control Functions10
c. Principle of Operation.12
d. Energizing the Equipment.12
3. Amount of Control13

SECTION IV - OPERATION

1. General.14
2. Routine Operation.14
a. Gain Control14
3. Metering14
4. Use Without Limiter Action16

SECTION V - MAINTENANCE

1. Fuse Replacement17
2. Tube Replacement17
3. Trouble Shooting17
a. General.17
b. Distortion17
c. Noise.19
d. Voltage Measurements20
e. Resistance Measurements.20
4. Replacement Parts.21

SECTION VI - PARTS LISTS

1. Introduction21
Parts List23

SECTION VII - MISCELLANEOUS DRAWINGS

ILLUSTRATIONS

<u>Figure</u>	<u>Title</u>
1-1	Type 26W Limiting Amplifier
2-1	Functional Block Diagram
2-2	Input Amplifier Circuit
2-3	Limiter Circuit
2-4	Output Amplifier Circuit
2-5	Power Supply Circuits
2-6	Metering Circuits
3-1	Input Attenuator Connections
3-2	Operate and Release Time Controls
3-3	Normal Test Switch and Limiter Balance Controls
4-1	Operating Controls
5-1	Tube Locating Diagram
7-1	Parts Arrangement, Panel Removed
7-2	Parts Arrangement, Rear
7-3	Complete Schematic
7-4	26W Limiting Characteristics Curve
7-5	Distortion Characteristic Curve