

TABLE OF CONTENTS

<u>Paragraph</u>	<u>Page</u>
<u>SECTION 1 - GENERAL DESCRIPTION</u>	
1.1. General	1-1
1.2. Reference Data.	1-2
1.3. Tube Complement	1-2
<u>SECTION 2 - INSTALLATION</u>	
2.1. Unpacking	2-1
2.2. Placing Transmitter	2-1
2.3. External Connections.	2-1
2.3.1. Power Line.	2-1
2.3.2. Microphone and Key.	2-1
2.3.3. Receiver Disabling Circuit.	2-1
2.3.4. Remote Relay Connections.	2-2
2.3.5. CW Sidetone	2-2
2.3.6. Receiver Muting	2-2
2.3.7. Radiation System.	2-2
2.3.8. External Antenna Tuner (not supplied)	2-2
<u>SECTION 3 - ADJUSTMENT AND OPERATION</u>	
3.1. Adjustment.	3-1
3.1.1. 600 v - 700 v Switch.	3-1
3.1.2. Calibration	3-1
3.2. Operation	3-1
3.2.1. General	3-1
3.2.2. Function of Controls.	3-2
3.2.3. Operation Procedure	3-2
3.2.4. Typical Meter Readings.	3-5
3.2.5. Dial Calibration.	3-5
3.2.6. Antenna Loading Table	3-5
<u>SECTION 4 - CIRCUIT DESCRIPTION</u>	
4.1. General	4-1
4.2. Circuit Description	4-1
4.2.1. RF Circuits	4-1
4.2.2. Audio Circuits.	4-2
4.2.3. High Voltage Supply	4-2
4.2.4. Low Voltage Supply.	4-2
4.2.5. Receiver Muting Circuit	4-2
<u>SECTION 5 - MAINTENANCE</u>	
5.1. Inspection.	5-1
5.1.1. General	5-1

TABLE OF CONTENTS

<u>Paragraph</u>		<u>Page</u>
<u>SECTION 5 - MAINTENANCE (Cont.)</u>		
5.1.2.	Rountine Inspection	5-1
5.2.	Trouble Shooting	5-3
5.2.1.	General	5-3
5.2.2.	Fuses	5-3
5.3.	Alignment	5-4
5.3.1.	General	5-4
5.3.2.	High Frequency Oscillator	5-4
5.3.3.	Multiplier Stages	5-6
5.3.4.	Modulator Bias Adjustment	5-6
5.4.	Lubrication	5-7
5.5.	Oscillator Tube Removal	5-7
5.6.	Desiccant Capsule	5-7

SECTION 6 - PARTS LIST

LIST OF ILLUSTRATIONS

<u>Figure</u>	<u>Title</u>
1-1	Model 32V-1 Amateur Transmitter
2-1	Tube Placement Diagram
2-2	Typical Antenna Tuner
2-3	Typical Antenna Tuner Circuits
3-1	Control Functions
3-2	Typical Dial Readings
5-1	Alignment Adjustments
5-2	Parts Arrangement - Top View
5-3	Parts Arrangement - Bottom View
5-4	Parts Arrangement - Left Side Open
5-5	Parts Arrangement - Right Side Open
5-6	Parts Arrangement - Rear Open
5-7	Parts Arrangement - 70E-8 Open
5-8	Model 32V-1 Complete Schematic Diagram