

SERVICEBULLETIN

COLLINS RADIO COMPANY

Cedar Rapids, Iowa 52406

EQUIPMENT TYPE: KWS-1 TRANSMITTER

SERVICE BULLETIN NO. 4

DATE 9-20-57 Page 1 of 1

SUBJECT: ARCHING OF PLATE TRANSFORMER T503

A few cases of trouble have been encountered with the plate transformer, T503, in the Power Supply of the KWS-1 arching from the transformer to the baffle mounted on the transformer. It is recommended that a close inspection of units in the field be made to assure a minimum clearance of 3/8 inch between the baffle plate and transformer winding.

Recommended procedure is as follows:

- 1. Turn Filament and Plate switch off.
- 2. Remove front and rear panels from Power Supply.
- 3. Loosen four screws that mount transformer to cabinet.
- 4. Slide transformer as far as possible to the center of the cabinet and tighten transformer mounting screws.
- Loosen two screws that mount baffle plate to transformer. Slide baffle toward side of cabinet as far as possible and tighten mounting screws.