



15 November 1963

Quality Standards Manual

(Formerly Quality Standards for Assembly)

Printed for Use in

Collins Radio Company

Cedar Rapids, Iowa

Toronto, Ontario

Newport Beach, California

Dallas, Texas



a publication of collins radio company

First Issue - August 1961

First Revision - June 1962

Second Printing - November 1962

Second Revision - November 1963

Fourth Printing - January 1967

preface

PURPOSE:

The purpose of this manual is to define the minimum acceptable quality standards of Collins Radio Company.


SCOPE

This manual applies to all corporate divisions of Collins Radio Company and carries the same governing authority on manufactured goods and development products as any other specification or drawing. Design considerations or customer specifications may contain requirements other than stated in this manual. In these cases, the contract or purchase order shall apply.


REVISIONS

As the state-of-the-art advances and better processes are developed, revisions to these standards will be made. This edition incorporates all previous revisions as well as others added at this printing. Revisions will be indicated by vertical bars adjacent to the paragraph affected. Revision or addendum pages will be supplied as necessary. Suggestions for changes or additions should be accompanied by reasons and supporting data and sent to a member of the appropriate committee as listed in the succeeding pages.


All requests for clarification of the Quality Standards Manual should be made to a member of the cognizant subcommittee, as listed in the manual.




E.D. Stambaugh, Director
Quality Assurance, Dallas



E.F. Read, Director
Quality Assurance, Cedar Rapids



V.H. Vogel, Director
Quality Assurance, Newport Beach



R.A. Bach, Director
Quality Assurance, Toronto

Corporate Quality Standards Committee

D. J. Palmer, Cedar Rapids, Chairman
C. R. Manthey, Newport Beach
C. L. Carter, Jr., Dallas
F. M. Rodin, Toronto

CEDAR RAPIDS COMMITTEE

Parent Committee

Donald J. Palmer, Chairman
Richard Starr, Coordinator
All subcommittee chairmen

Quality Assurance Division
Quality Assurance Division

Wiring & Cabling Subcommittee

Lloyd Ashlock, Chairman
Robert J. Walsh
Carl H. Bowles
John M. Jensen

Quality Assurance Division
Development Division
Quality Assurance Division
Manufacturing Division

Electrical Components Subcommittee

Robert D. McArthur, Chairman
Arlo Goodyear
John D. Zimmerman
John C. Haworth
Edward J. Ledvina

Service Division
Development Division
Manufacturing Division
Development Division
Quality Assurance Division

Fastening Subcommittee

Clifford O. Franklin, Chairman
Arlen Blank
Robert Griswold
John E. Kirkpatrick
Jack H. McCallum

Development Division
Manufacturing Division
Development Division
Development Division
Quality Assurance Division

Mechanical and Electromechanical Subcommittee

John G. Donahue, Chairman
Walter L. Koon
Carl E. Anderson
Keith L. Smith

Manufacturing Division
Manufacturing Division
Quality Assurance Division
Development Division

Printed Circuits Subcommittee

Eugene L. Cooley, Chairman
Marvin Slipson
Wendell L. Oliver
Ray Stoner

Development Division
Manufacturing Division
Development Division
Quality Assurance Division

Resistance Welding of Circuitry Subcommittee

William E. Northfield, Chairman
Bruce E. Andree
Martin E. Kacena
Steven C. Meyers

Manufacturing Division
Quality Assurance Division
Manufacturing Division
Research Division

DALLAS DIVISION QUALITY STANDARDS COMMITTEE

Parent Committee

C. L. Carter, Jr., Chairman
D. A. Dochterman, Coordinator
C. O. Bethel
W. J. Fisk
C. S. Knight

Quality Assurance Division
Quality Engineering Division
Microwave Division
Quality Control Department
Fabrication Division

Electrical Assembly Subcommittee

D. K. Jernigan, Chairman
D. L. Kennedy
K. A. Love
J. E. McLaughlin
J. E. Johns
W. E. Trembley

Quality Control Department
Product Analysis Division
R & D "A"
Technical Support Department
Microwave Division
Special Products Division

Mechanical Assembly Subcommittee

C. O. Bethel, Chairman
C. Martin
E. A. Teddlie
R. W. Whitson

Microwave Division
Quality Engineering Division
R & D "B"
Special Products Processes

Fabrication Subcommittee

C. S. Knight, Chairman
K. L. Bitting
F. E. Keefe, Jr.
B. C. Harris
R. P. Helmick

Fabrication Division
Quality Engineering Division
R & D "A"
Fabrication Engineering
Fab. Production II

Tool Subcommittee

C. Martin, Chairman
W. E. Trembley
J. Johns
D. Pedro
W. J. Koper

Quality Engineering Division
Special Products Division
Microwave I. E. Division
Training and Motivation
Inspection Control Division

INFORMATION SCIENCE CENTER

Coordinator - C. R. Manthey

Quality Assurance Division

COLLINS RADIO COMPANY OF CANADA

Quality Standards for Assembly Committee

Floyd Rodin
Norman Allen
Milan Ondrich

Quality Assurance Division
Quality Assurance Division
Quality Assurance Division

table of contents

Section	Page
1 WIRING AND CABLING	1
1.1 Wire, Electrical, Insulated	1
1.1.1 Definitions	1
1.1.2 General	1
1.1.3 Stripping	3
1.1.4 Routing	4
1.1.5 Protection	4
1.1.6 Terminating	8
1.1.7 Splicing	8
1.1.8 Cable Identification	8
1.2 Shielded Wire and Coaxial Cable	8
1.2.1 Routing and Protection	8
1.2.2 Termination	8
1.3 Cabling	9
1.3.1 Cable Tying and Lacing	9
1.3.2 Cable Routing and Securing	9
1.3.3 Cable Protection	19
1.4 Bus Wire	20
1.4.1 General	20
1.4.2 Slack	20
1.4.3 Clearance	20
1.4.4 Insulation	20
1.4.5 Rounded Edges on Tools	20
1.5 Mechanical Connections for Soldering	20
1.5.1 General Requirement	21
1.5.2 Post Terminals	21
1.5.3 Small Wire Sizes	21
1.5.4 Lug Without a Hole for Wire	21
1.5.5 Terminal with a Hole for Wire	21
1.5.6 Location and Direction of Wrap	22
1.5.7 Contact of Wire with Terminal	22
1.5.8 Contact of Threaded Wire	22
1.5.9 Avoiding Tension on Solder	23
1.5.10 Wire Heavier than Terminal	23
1.5.11 Minimum Terminal Spacing	23

table of contents (cont)

Section	Page
1.5.12 Assembly of Solder Lug to Wire	23
1.5.13 Wire to Component Lead Connection	24
1.5.14 Component Leads Used as Terminals	24
1.5.15 Wrapping on Adjacent Terminals	24
1.5.16 Miniature Tube Socket Wiring	24
1.5.17 Wrapping on a Slotted Terminal	25
1.5.18 Cup and Groove Type Terminals	26
1.5.19 Control of Clippings	27
1.5.20 Cloverleafs Terminals	27
1.6 Hand Soldering	27
1.6.1 Definition and Purpose	27
1.6.2 Preparation	28
1.6.3 Method	28
1.6.4 Flux	29
1.6.5 Choice of Solder	29
1.6.6 Wetting Action	29
1.6.7 Amount of Solder	30
1.6.8 Material Imbedded in Solder Joint	30
1.6.9 Wicking Under Insulation	30
1.6.10 Soldering to Sockets	30
1.6.11 Solder Pots	30
1.7 Solderless Electrical Connections	30
1.7.1 Mounting of Lugs	30
1.7.2 Crimp Connections	31
1.8 Sleeving	34
1.8.1 Connector Terminals	34
1.8.2 Pressure or Abrasive Action	34
1.8.3 Grade and Fit	34
1.8.4 Environmental Requirement	34
1.8.5 Cable Covering	34
1.8.6 Tolerance on Length	34
1.9 Coils	35
1.9.1 Marking	35
1.9.2 Insulation	35
1.9.3 Broken Strands	35
1.9.4 Slipped Turns	35

table of contents (cont)

Section	Page
1.9.5 Minimum Inside Diameter	35
1.9.6 Coil Coating	35
1.9.7 Voids in Potted Assembly	35
1.9.8 Wiring and Soldering	35
1.9.9 Similar Coils	36
1.9.10 Securing of Coils, Leads and Terminals	36
1.9.11 Resistor Notches for Coil Winding	37
1.9.12 Damage	37
1.9.13 Winding Direction	37
1.10 Stray Material	37
1.11 Connecting 3-Wire A-C Cord	38
 2 ELECTRICAL COMPONENTS	 39
2.1 Scope	39
2.2 Storage, Handling, and Transportation	39
2.2.1 Storage	39
2.2.2 Damage and Contamination by Handling	39
2.2.3 Damage in Transportation	40
2.2.4 Bending of Component Leads for Storage	40
2.3 Component Defects	40
2.3.1 Damage to Insulation	40
2.3.2 Illegible Component Markings	40
2.3.3 Dents and Chips	40
2.3.4 Cracks	40
2.3.5 Improper Lead Tinning	41
2.3.6 Lead Defects Reference	41
2.3.7 Bent Leads	41
2.3.8 Stray Material	41
2.4 Component Lead Forming and Soldering	41
2.4.1 Changes in Ratings Due to Forming	41
2.4.2 Readability of Markings	41
2.4.3 Sharp Bends in Component Leads	41
2.4.4 Thermoplastic and Teflon Sleeving	42
2.4.5 Lead Forming	42
2.4.6 Soldering on a Welded Area	42

table of contents (cont)

Section	Page
2.5 Use of Tools for Wiring	43
2.5.1 General	43
2.5.2 Tools with Sharp Edges	43
2.5.3 Control of Clippings	43
2.6 Component Positioning and Mounting	43
2.6.1 Positioning Within Boundaries	43
2.6.2 Neatness in Mounting	44
2.6.3 Crossing of Component Leads	44
2.6.4 Access to Mounting Holes and Controls	44
2.6.5 Centering of Components	44
2.6.6 Strain Relief	45
2.6.7 Component Support	45
2.6.8 Misuse of Components for Support	46
2.6.9 Clearance from Sharp Edges and Wiring	46
2.6.10 Vibration	46
2.6.11 Mounting of Heat Dissipating Components	46
2.6.12 Heat Sensitive Components	46
2.6.13 Mounting of Components into Tubelets	47
2.6.14 Centering of Clip-Mounted Components	47
2.6.15 Tightness of Mounting Clips	48
2.6.16 Positioning of Stud-Mounted Components	48
2.6.17 Mounting of Components Having Locating Tabs	48
2.6.18 Connections to Fuse Posts	48
2.6.19 Twist-Tab Components	48
3 FASTENING	49
3.1 Machine Screws	49
3.1.1 Materials and Finishes	50
3.1.2 Countersunk Screws (Flat and Oval Heads)	50
3.1.3 Preferred Sizes and Class of Fit	51
3.1.4 Minimum Thread Engagement and Thread Inserts	51
3.1.5 Thread Projection	52
3.1.6 Tightness	52
3.1.7 Screwhead Imperfections	53
3.1.8 Captive Screws	55

table of contents (cont)

Section	Page
3.2 Setscrews	55
3.2.1 General	55
3.2.2 Types of Drives	56
3.2.3 Point Styles	56
3.2.4 Locking	57
3.3 Tapping Screws	57
3.3.1 Materials and Finishes	57
3.3.2 Types of Tapping Screws	58
3.4 Nuts	58
3.4.1 General	58
3.4.2 Nonlocking Nuts	60
3.4.3 Locking Nuts	62
3.5 Rivets and Eyelets	62
3.5.1 General	62
3.5.2 Rivet Types	64
3.5.3 Material and Workmanship	64
3.6 Washers	64
3.6.1 Flat Washers	65
3.6.2 Lock Washers	67
3.6.3 Compressible Washers	68
3.7 Miscellaneous Fastening and Locking Provisions	68
3.7.1 Liquid Staking	68
3.7.2 Solder Staking	68
3.7.3 Self-Locking Screws	69
3.7.4 Sheet Spring Nuts	69
3.7.5 General Locking Requirement	69
3.7.6 Fastening of Resilient or High Expansion Materials	69
3.7.7 Electrical Connections	70
3.8 Adhesive Bonding	70
3.8.1 Structural Adhesive Bonding	70
3.8.2 Surface Preparation for Structural Bonding	70
3.8.3 Adhesive Bonding, Elastomeric	70
3.9 Stray Hardware	70

table of contents (cont)

Section	Page
4 MECHANICAL AND ELECTROMECHANICAL REQUIREMENTS	71
4.1 General Requirements	71
4.1.1 Minimum Clearance of Moving Parts	71
4.1.2 Cracks, Chips, or Crazing in Glass or Ceramic Seals, Insulators, Terminal Boards, and Connectors	71
4.1.3 Burrs and Sharp Edges	73
4.1.4 Handling, Fitting, and Assembling	73
4.2 Gears	73
4.2.1 Definitions	73
4.2.2 Gear Alignment	74
4.2.3 Gear Lubrication	75
4.2.4 Gear Mesh	75
4.2.5 Gear Loading	75
4.2.6 Clamping Adjustable Gears	76
4.3 Detents	76
4.3.1 Detent Action	76
4.3.2 Binding or Galling	76
4.4 Bearings	76
4.4.1 General	76
4.4.2 Ball Bearings	78
4.4.3 Porous Self-Lubricating Bearings	80
4.4.4 Plastic Sleeve Bearings	81
4.5 Tuning Slug Racks	81
4.5.1 Alignment with Cam	81
4.5.2 Travel	81
4.5.3 Slug Positioning	81
4.5.4 Slug Stud Retainers	81
4.6 Switches and Relays	82
4.6.1 General	82
4.6.2 Switches	83
4.6.3 Relays	84
4.7 Retaining Rings	85
4.7.1 Seating	85
4.7.2 Installation	85

table of contents (cont)

Section	Page
4.7.3 Distortion	85
4.8 Pinned Assemblies	85
4.8.1 Engagement with Hub	85
4.8.2 Protrusion from Hub	85
4.8.3 Tightness of Pins	86
4.8.4 Distortion by Pinning	86
4.9 Lubrication Requirements	87
4.9.1 General	87
4.9.2 Absence of Requirements	87
4.9.3 Lubrication Instruction Plates	87
4.9.4 Application, Quantity and Protection	87
4.10 Appearance and Cleanliness	87
4.10.1 General Requirements	87
4.10.2 External Appearance	88
4.10.3 Internal Appearance	88
4.10.4 Loose Foreign Material	88
4.11 Markings	88
4.11.1 General	88
4.11.2 Decalcomanias (Decals) and Self-Adhesive Labels	89
4.11.3 Ink Stamping	89
4.11.4 Cable Marking Bands	89
4.11.5 Tape Code Labels	89
4.11.6 Nameplates	90
4.12 Latent Contamination	90
5 PRINTED CIRCUIT BOARD ASSEMBLY REQUIREMENTS	91
5.1 Printed Circuit Board Specifications	91
5.2 Eyelets, Tubelets, Terminals, and Plated-Thru Holes	91
5.2.1 Definitions	91
5.2.2 Installation and Application	92
5.2.3 Other Quality Requirements	93
5.3 Component Attachment	93
5.3.1 Components with Wire Leads	93
5.3.2 Hardware Mounted Components	95
5.3.3 "Snap-in" Components	95

table of contents (cont)

Section	Page
5.4 Quality Requirements for Printed Circuit Board Assemblies	95
5.4.1 Component Bodies and Wire Leads	95
5.4.2 Printed Circuitry Separation	96
5.4.3 Base Laminate	96
5.4.4 Repair of Printed Circuit	96
5.5 Soldering on Printed Boards	96
5.5.1 Preparation	97
5.5.2 Fluxes	97
5.5.3 Hand Soldering	97
5.5.4 Dip Soldering	98
5.5.5 Removal of Flux Residues	98
5.5.6 Workmanship Standards - Dip-Soldered Board	99
5.6 Post-Coating	99
5.6.1 Cleaning	99
5.6.2 Masking	99
5.6.3 Cured Coating Requirements	99
5.7 Handling and Packaging	99
6 RESISTANCE WELDING OF CIRCUITRY	101
6.1 Conductors	101
6.1.1 Surface Conditions	101
6.1.2 Bending of Component Leads and Nickel Wire (before welding)	101
6.1.3 Permissible Weld Combinations	102
6.1.4 Conductor Imperfections	102
6.2 Stranded Wire Welding	102
6.3 Spacing From Component Body to Terminal	103
6.4 Angle of Conductors	103
6.4.1 Cylindrical Conductors	103
6.4.2 Ribbon Conductors	103
6.5 Spacing Between Welds on a Terminal	104
6.6 Stacking of Components on Terminals	104
6.7 Connecting Transistors	104
6.8 Clearance	105
6.9 Multiple Terminal Connections	105
6.10 Clipping	106
6.11 Sleeving	106

table of contents (cont)

Section	Page
6.12 Weld Standards	106
6.12.1 Acceptable Welds	106
6.12.2 Defective Welds	107
6.12.3 Discoloration	110
6.13 Repair of Rejected Welding	111
6.14 Solder Beads on "Tin" Dipped Conductors	111
6.15 Inspection	111
6.15.1 Inspector Qualification	111
6.15.2 Inspection Controls	112
6.16 Welding Machine Certification	112
6.17 Butt Welding	112
6.17.1 Acceptable Butt Welds	112
6.17.2 Defective Butt Welds	112
Appendix	
A	A-1
Color Codes	A-1
Typical Diode Polarity Guide	A-7
Transistor Base Diagram	A-8
Part and Assembly Designations	A-9
Tables of Useful Information	A-11
B DEFINITIONS	B-1
C INDEX	C-1

list of illustrations

Figure		Page
1-1	Protection for Wire Through a Hole	5
1-2	Protection for Wire Against Chassis Edge	6
1-3	Protection for Wire over Sharp Object	7
1-4	Acceptable Shield Terminations	10
1-5	Unacceptable Shield Terminations	11
1-6	Cable Dress and Routing	12
1-7A	Step-by-Step Tying First Part of Collins Standard Knot	13
1-7B	Final Step-by-Step Typing of Collins Standard Knot for Cable Ties	14
1-8A	Preparation for Lacing	15
1-8B	Cable Lacing	16
1-8C	Special Steps for Optional Method of Cable Lacing Using "Lacing Awl"	17
1-9	Mechanical Wrap on Post	21
1-10	Wrap for Wire Size No. 26 or Larger on a Lug with No Hole	21
1-11	Minimum Wrap for No. 26 or Larger Wire	22
1-12	Threading Terminals with Wire	22
1-13	Avoiding Tension on Soldered Joint	23
1-14	Lug Assembled to Wire	23
1-15	Wires Connected to Component Leads	24
1-16	Component Leads as Terminals	24
1-17	Miniature Tube Socket with Shield	25
1-18	Minimum Wrap with Stranded Wire on Slotted Terminal	26
1-19	"Bottoming" in Terminals	26
1-20	Section Showing Acceptable Limits of Solder Volume	29
1-21	Section of Unacceptable Soldered Joint	29
1-22	Stacking of Lugs	31
1-23	Insulated Lug	32
1-24	Formed Connector Contact	32
1-25	Machined Closed-Barrel Contact	33
1-26	Two-Piece Uninsulated Ferrule Termination	33
1-27	One-Piece Ferrule Termination	33
1-28	Mounting of Ring Terminals	36
1-29	Cementing Terminals to Coil Form	36
1-30	Maximum Depth of Resistor Notches for Coil Winding	37
1-31	Correct Method of Connecting 3-Wire A-C Cord for 115 Volts	38

list of illustrations

Figure		Page
2-1	Lead Forming	42
2-2	Examples of Specialized Pliers for Lead Forming	43
2-3	Section of Metal Terminal Board Assembly	44
2-4	Mounting Layout	44
2-5	Examples of Strain Relief	45
2-6	Examples of Mounting Components	45
2-7	Examples of Commercially Available Heat Sinks	47
3-1	Screw Heads in Common Use at Collins	49
3-2	Flathead Screws on a Thin Panel	50
3-3	Screwhead Imperfections	54
3-4	Spline Socket Setscrew	56
3-5	Hexagon Socket Setscrew	56
3-6	Slotted Setscrew	56
3-7	Common Setscrew Points	56
3-8	Tapping Screws	57
3-9	Nut Size Specifications	58
3-10	Nut Thickness	58
3-11	Pem Nut Assembly	59
3-12	Hexagon Captive Nuts	59
3-13	Typical Angle Nut	60
3-14	Common Elastic Stop Nuts	60
3-15	Two Lug Anchor Rivet Type All-Metal Lock Nut	61
3-16	Right Angle Rivet Type All-Metal Floating Lock Nut	61
3-17	Slotted Deformed End Lock Nut	62
3-18	Keps Lock Washer-Nut Assembly	62
3-19	Solid Rivets	62
3-20	Semitubular Rivet	63
3-21	Desired Clinch Allowances	63
3-22	Roll-Flanged Eyelet	64
3-23	Rolled Semitubular Rivet	64
3-24	Split Lock Washer	65
3-25	External Tooth Lock Washer	65
3-26	Internal Tooth Lock Washer	65
3-27	Dished Flat-Rim Lock Washer	65
3-28	Nut Added Below Lug	69

list of illustrations (cont)

Figure		Page
4-1	Cracks, Chips and Crazing around Sealed Terminals	72
4-2	Unacceptable Cracks in a Terminal Board	72
4-3	Gear Alignment	73
4-4	Gear Mesh	74
4-5	Alignment Limits for Spur Gears and for Bevel Gears	74
4-6	Separation of Sections of Loaded Gears	76
4-7	Sleeve Bearings, Properly Seated	77
4-8	Bearings not Properly Seated	77
4-9	Incorrect Method of Mounting Bearing	78
4-10	Correct Method of Mounting Bearing on a Shaft	78
4-11	Correct Method of Mounting Bearing in a Housing	78
4-12	Improper Application of Ball Bearing with Filling Notches	79
4-13	Typical Ball Bearing Constructions	79
4-14	Method of Retaining Ball Bearing in Housing	80
4-15	Incorrect Method for Retention of Ball Bearing on Shaft	80
4-16	Button Burnisher for Sizing Oilite Bearings	81
4-17	Contact Alignment for Low Current Applications	83
4-18	Wafer Switch Soldering and Contact Areas	83
4-19	Exaggerated Wiping Action of Relay Contacts	84
4-20	Construction of a Sealed Relay	85
4-21	Pin Engagement and Clearance Checks	86
4-22	Distortion Caused by Improper Pinning	86
5-1	Eyelet, Tubelet, Terminal and Plated-Thru Hole on a Board	92
5-2	Intentionally Split Tubelets	92
5-3	Assembled Printed Circuit Board	94
5-4	Lead Clinch and Cut-Off	95
5-5	Lifted Circuitry Repairable Maximum	96
6-1	Forming of Conductor Before Welding	101
6-2	Spacing from Component to Terminal	103
6-3	Angle Between Lead and Terminal	103
6-4	Spacing Between Welds	104
6-5	Deleted	104
6-6	Minimum Clearance	105
6-7	Position of Terminal	105
6-8	Clipped Wire Dimension and Clearance	106

list of illustrations (cont)

Figure		Page
6-9	Good Weld	106
6-10	Weld Splatter	107
6-11	Cracked Weld	107
6-12	Blow Hole	108
6-13	Burned Weld	108
6-14	Burned Hole	109
6-15	Insufficient Weld	109
6-16	Deformation	110
6-17	Miscentered Leads on Electrodes	110
6-18	Typical Acceptable Butt Weld	112
6-19	Mismatch and Bulge	113

wiring and cabling

1.1 WIRE, ELECTRICAL, INSULATED

1.1.1 Definitions

- A Insulated Electrical Wire: Insulated electrical wire is a single, insulated, metallic conductor of solid, stranded, or tinsel construction which is designed to carry current in an electrical circuit. It is provided with an insulating covering but does not have a metallic covering, sheath, or shield.
- B Point-to-Point Wiring: Point-to-point wiring is wiring from one termination to another in which the individual wire is not part of a cable and the only support to the wire is supplied by the connections to the terminations.
- C Slack: Slack is that length of wire allowed for service loops and/or moving or flexing of parts during operation or maintenance of equipment.

1.1.2 General

- A The size of conductor, type of insulation, and construction of each conductor shall be consistent with the requirements of the application and specified on the assembly drawing. See Collins drawing 554-9999-004 (506-3900-003 for applications before July 1963) or Components Standards manual for wire coding.
- B All insulating materials shall provide adequate dielectric strength and leakage resistance when the equipment is operated under its designated service conditions.
- C The mechanical and electrical properties of the insulation shall not be adversely affected by exposure to temperature or other environmental extremes of the equipment specification.
- D All conductor insulation shall be of the noncombustible or slow-burning type; that is, with the insulated conductor held in a horizontal position in still air, self-sustained combustion of the insulation or lacquer shall not progress at a rate in excess of 1 inch in 1 minute.
- E Single conductor chassis wires which require coding shall be identified by colors in accordance with table I, preferably in the order given. In the code identification numbers, the first digit indicates the background color with the succeeding digits, if any, indicating the color of the stripes. All colors shall fall within the limits of the standard color chips of supplement 1 to RETMA Standard GEN-101-A.
- F The current carrying capacities of wires in conduit or bundles shall be derated to prevent the insulation from being damaged due to heat generated within the wire. The amount of derating required varies with the size of the conductor, type of insulation, and number of wires in the bundle.

TABLE I. WIRE CODING COLORS

BASE	1ST STRIPE	2ND STRIPE	3RD STRIPE	CODE IDENTIFI- CATION NO.
Black				0
Brown				1
Red				2
Orange				3
Yellow				4
Green				5
Blue				6
Violet				7
Gray				8
White				9
White	Black			90
White	Brown			91
White	Red			92
White	Orange			93
White	Green			95
White	Blue			96
White	Black	Red		902
White	Black	Orange		903
White	Black	Green		905
White	Black	Blue		906
White	Brown	Red		912
White	Brown	Orange		913
White	Brown	Green		915
White	Brown	Blue		916
White	Red	Orange		923
White	Red	Green		925
White	Red	Blue		926
White	Orange	Green		935
White	Orange	Blue		936
White	Green	Blue		956
White	Black	Red	Orange	9023
White	Black	Red	Green	9025
White	Black	Red	Blue	9026
White	Brown	Red	Orange	9123
White	Brown	Red	Green	9125
White	Brown	Red	Blue	9126
White	Red	Orange	Green	9235
White	Red	Orange	Blue	9236
White	Red	Green	Blue	9256
White	Orange	Green	Blue	9356

- 1.1.2.G The insulating material must be intact, but a limited amount of repaired damage is allowable. Damage to the nylon (outer) jacket of nylon coated plastic wire may be repaired, provided that the damage is limited to the outer jacket of the wire and is not larger than 1/2 inch long and not more than 1/3 the circumference of the wire. If the damage exceeds these limits, the wire must be replaced.

1.1.3 Stripping

- A Whenever practical, stripping should be done by machine at the time the wire is cut to required lengths.
- B When hand stripping is necessary, it shall be accomplished with properly adjusted stripping tools of an approved type.
- C Conductor imperfections resulting from stripping, forming, or handling of wire leads shall be classified as follows:
1. Abrasions: An abrasion is a scraped or roughened surface finish of a conductor or strand of a conductor. It is identifiable by its lack of definite outline, shallowness, and the fact that it may extend for a relatively long distance along the conductor. Such a condition might result from bare wire being pulled through the feed fingers of a cutting machine, wire being rubbed against a rough surface, or running a straight edge over a wire to determine if excess oxidation is present on the conductor surface. Abrasions do not create any critical stress points and are considered acceptable unless aggravated enough to be considered nicks or indentations.
 2. Indentations: An indentation is a deformation of the surface of the conductor or strands of the conductor by a dull or blunt instrument. Indentations might result from pressure being exerted on bare wire during stripping. Since indentations are radiused to some extent, stress points are not as critical as they would be where sharp corners exist. Indentations with depths not exceeding $1/4$ of the diameter of the conductor or $1/4$ of an individual strand of a conductor shall be considered acceptable. Indentations with depths exceeding $1/4$ of the diameter of the conductor or strands of the conductor shall be classified as defects, and the number of allowable defects shall not exceed those shown in table II.
 3. Broken Strands: Broken strands in a wire or shielding shall be classified as defects and the number of allowable defects shall not exceed those shown in table II.
 4. Nicks: A nick is the partial severance of the conductor or strands of the conductor by a sharp instrument. Nicks normally result from improper stripping of wire by an improperly adjusted stripping tool. Due to the sharp corners present in nicks, very concentrated stress points are created, and nicks in solid conductor wire or in strands of stranded wire shall be classified as defects and the number of allowable defects shall not exceed those shown in table II.

TABLE II. ALLOWABLE CONDUCTOR DEFECTS

NUMBER OF STRANDS	ALLOWABLE NUMBER OF STRANDS CONTAINING DEFECTS
1 through 7	0
8 through 19	1
20 through 40	2
over 40	10%

Wiring and Cabling

- 1.1.3.D Tolerances on length of wire and length of stripped portion of wire as supplied by the Wire Cutting Section are as shown below. Departures from these tolerances must be treated as special orders.

Tolerance on Over-all Length of Wire

Over-all Length of Wire	Tolerance
1 in. to 6 in.	$\pm 1/16$ in.
6 in. to 15 in.	$\pm 1/8$ in.
15 in. to 30 in.	$\pm 5/32$ in.
Above 30 in.	Add a tolerance of $\pm 1/16$ in. for each 16 in.

Tolerance on Length of Strip

Length of Stripped Portion of the Wire	Tolerance
1/8 in.	$\pm 1/32$ in.
3/16 in. to 1-1/2 in.	$\pm 1/16$ in.

1.1.4 Routing

- A All wires shall be routed so that they will not be pinched or damaged, or be under damaging pressure when parts, covers, or subassemblies are in place.
- B Wires connected to the same terminal shall not cross over each other unnecessarily.
- C All wires in a cable connected to the same terminal shall have approximately the same amount of slack and shall be dressed (arranged) to give a uniform appearance.
- D All wires shall be routed and secured in such a manner that they cannot come in contact with moving parts such as gears, switches, relays, slug racks, shafts, dials, and tuning capacitors. See figure 1-6.
- E The minimum inside bend radius of insulated wire shall be not less than 3 times the outer diameter of the wire insulation.

1.1.5 Protection

- A Wherever wire is routed through a hole in a metal chassis, there must be some means of protection, such as a grommet or a 1/16 inch minimum radius around the edge of the hole on both sides of the chassis. Chamfers do not meet this requirement.






Figure 1-1. Protection for Wire Through a Hole

- 1.1.5. B Whenever wires are routed through a slot or against the edge of a metal chassis where pressure is exerted against the metal, the metal edges must present a minimum radius of $\frac{1}{16}$ inch or some means of protection must be provided on the chassis. If constant pressure is not present, the use of sleeving or other suitable protective material over the wire insulation is acceptable. See figure 1-2.

NOT ACCEPTABLE




SLEEVING OVER WIRE WITH
PRESSURE ON CHASSIS.




NO PROTECTION ON CHASSIS
OR WIRE.


ACCEPTABLE



PRESSURE ON WIRE BUT CHASSIS
COVERED BY RESILIENT CHANNEL.



SLEEVING OVER WIRE WITH
NO PRESSURE ON CHASSIS.



METAL EDGE ROLLED OR
ROUNDED TO PROPER
RADIUS.

Figure 1-2. Protection for Wire against Chassis Edge

- 1.1.5.C All wires should be routed and secured away from contact with sharp metal objects such as studs, screw heads, sharp corners on metal parts, and terminal ends. In cases where the wire passes over such sharp objects with no pressure exerted on the object by the wire, the use of sleeving or other suitable protective material over the wire or sharp object, at the point of contact, is acceptable. However, if continual pressure is exerted on the object by the wire, the use of sleeving over the wire is not acceptable for protection. See figure 1-3.




Figure 1-3. Protection for Wire over Sharp Object

- 1.1.5. D All insulated wires must be routed in such a manner that they are not exposed to excessive temperatures by heated or heat generating components.
- E All insulated wires with low heat resistance must be dressed in such a manner to prevent damage when a soldered connection is repaired.
- F When it is necessary to use added protection for a wire, the protective material shall be positioned and secured in such a manner that it always will protect the point for which it was intended.
- G All protective materials used must meet all of the requirements of the equipment specification.
- H All sleeving used for wire protection shall be of an electrical grade.

Wiring and Cabling

1.1.6 Terminating

- A All wire terminations shall meet the requirements of paragraph 1.5, Mechanical Connections.
- B For the convenience of customer maintenance, cabled wires shall be terminated with sufficient slack to permit a minimum of one cut and reconnection.
- C Point-to-point wiring must contain enough slack to prevent the application of any direct stress at the point of termination as a result of flexing during operation of the equipment under its specified service conditions.
- D Point-to-point wiring of insulated stranded wire shall have no more than 1/2 inch slack.
- E Unrestrained point-to-point insulated stranded wiring shall not be used where the distance is over 3 inches.
- F THE REQUIREMENTS OF PARAGRAPHS 1.1.6, B, C, D, and E SHALL NOT APPLY IF THE OPERATION OF THE CIRCUIT INVOLVED WILL BE AFFECTED IN WHICH CASE THE ENGINEERING DRAWING SHALL SPECIFY MORE DETAILED REQUIREMENTS.
- G When terminating insulated wires to solder connections, the insulation shall end not more than 1/16 inch plus one conductor diameter from the terminal to which the connection is made. The insulation shall not be so close to the terminal that it interferes with the soldering of the connection.
- H Terminations involving crimp-type solderless connections shall conform to the requirements of paragraph 1.7.2 and specified assembly procedures.

1.1.7 Splicing

Wires or leads shall not be spliced except as specified in paragraph 1.5.14.

1.1.8 Cable Identification

Identically terminated cable ends (including coax) which may be subject to improper connection shall be identified to aid in making proper connections.

1.2 SHIELDED WIRE AND COAXIAL CABLE

1.2.1 Routing and Protection

- A Wires using metallic shielding unprotected by an outer insulation shall be secured, routed, or protected to prevent the shielding from touching terminals or unprotected conductors of a different potential when subjected to specified service conditions of the equipment.
- B The minimum inside bend radius of coaxial cable shall be not less than 6 times the outer diameter of the cable.

1.2.2 Termination

- A The unshielded portion of shielded wire shall be a minimum but the shield shall be terminated 1/4 inch to 1 inch from the exposed conductor, unless otherwise specified on the drawing.

- B The shield shall be connected to ground on at least one end unless it is part of an "above ground" system, unless otherwise specified by an engineering drawing.
- C The terminated end of a shield must be terminated or captivated in such a manner as to prevent fraying of the shield or damage to the conductor insulation.
- D The conductor shall not be formed against the sharp edge of terminated shielding in such a manner that the insulation will be subjected to damage.
- E For examples of terminating shielding on shielded wire or coax, see figure 1-4. Other methods shall be submitted to the cognizant Quality Standards committee for approval prior to use. For examples of unacceptable terminations, see figure 1-5.

For crimp-type terminations, refer to par. 1.7.2.

- F When shielded braid is subjected to a soldering operation, there must not be enough heat transferred to damage the conductor insulation.
- G For proper assembly of coaxial cables and connectors, refer to the 580-9000-00 series of specifications.
- H Table II in par. 1.1.3 applies to coax center conductors.

1.3 CABLING

1.3.1 Cable Tying and Lacing

- A Wherever practical, insulated wires connecting various parts should be bundled neatly with a minimum crossing of wires and held in their intended position by tying, lacing, or equivalent means of binding at intervals of approximately 1 inch to form a cable or cable harness. See figure 1-6, point A. Cable ties and lacing should be tight after cable installation. At no time should the means of holding a group of wires together cause damage to the wire insulation.
- B When a group of wires are to be bound by means of a tie, the Collins standard knot will be used. See figure 1-7.
- C When a group of wires are to be laced, the proper lacing stitch will be used. See figure 1-8.
- D When cables are to be laced, single lacing stitches may be used on cables with a diameter of 1/2 inch or less. Double lacing is required on the cable at point of wire breakout in a cable harness. See figure 1-6, point B. On cables of a diameter exceeding 1/2 inch, double lacing must be used, except that single lacing stitches may be used on cables up to 1 inch in diameter if the lacing is done on the cable after it is installed. At large breakouts, bends and corners, the number of laces should be increased to hold the wires in their intended position.
- E Only flat ribbon-type lacing cord, or an equivalent binding, shall be used.

1.3.2 Cable Routing and Securing

- A Cables with diameter of 1/2 inch or less should not have an inside bend radius less than the diameter of the cable. However, in no case shall the bend radius be less than 3 times the OD of the largest wire in the cable. Cables with diameter exceeding 1/2 inch but not exceeding 1 inch should not have an inside bend radius less than 3/4 the diameter of the cable. Cables with diameter exceeding 1 inch should not have an inside bend radius less than 1 inch.

ACCEPTABLE











Figure 1-4. Acceptable Shield Terminations

NOT ACCEPTABLE




A Broken strands



B Shield termination frayed, not soldered or captivated.



C Shield termination cut off and soldered leaving jagged edges.



D Loose strands which may short adjacent terminals. Also, twisted shield tinned approximately half its length.



E Insulation damaged by soldering operation. Also, sharp ends of shield exposed.

Figure 1-5. Unacceptable Shield Terminations







Figure 1-6. Cable Dress and Routing




Step 1




Step 2




Step 3




Step 4




Step 5



Step 6




Step 7




Exploded View After Step 7, as Would Be Seen From Side Against Chassis


Figure 1-7A. Step-by-Step Tying First Part of Collins Standard Knot




Step 8




Step 9




Step 10



Step 11




Step 12




When Cutting an End of Cord, Leave
1/8 inch Outside Knot

Step 13


Figure 1-7B. Final Step-by-Step Tying of Collins Standard Knot for Cable Ties




Step 1




Step 2




Step 3




Step 4



Step 5




Step 6




Step 7


Figure 1-8A. Preparation for Lacing




Step 8




Step 9




Step 10



Step 11




Step 12




Step 13

Figure 1-8B. Cable Lacing


1. The lacing cord comes from the lacing tool, on the right in steps 1, 2 and 3 of figure 1-8A.
2. The steps A through E shown below replace steps 4, 5, 6 and 7.




Step A. Form first loop.




Step B. Thread tool under cable and grasp cord near tool.



Step C. Form second loop.




Step D. Pass entire tool through second loop.



Step E. Slide stitch into position and pull it tight.

Repeat steps A through E for the required number of lacing stitches.

Figure 1-8C. Special Steps for Optional Method of Cable Lacing Using "Lacing Awl"
(Sheet 1 of 2)



Step F. Cut, leaving enough cord to terminate as in steps 8 through 13, figure 1-8B. Also cut off excess cord at Collins knot at start of lacing.

3. The lacing is terminated as in steps 8 through 13 of figure 1-8B. However, the lacing stitches will appear double as shown in Step F in place of the lacing shown in Steps 8 through 13.

The lacing can proceed from left to right as well as from right to left as shown.

Figure 1-8C. Steps for Optional Method of Cable Lacing Using "Lacing Awl"
(Sheet 2 of 2)

1.3.2 Cable Routing and Securing (continued from page 9)

- B Cables should follow the contour of the chassis wherever possible.
- C All cables should be secured as necessary to prevent strain on the breakout wires or movement of the cables from their intended positions, and to meet the equipment specifications and shipping requirements.
- D The wire leads from a cable breakout should not be used as a means of support to the cable.
- E Wherever practical, wires should break out of a cable before the point of termination rather than beyond the point of termination. See figure 1-6, point C.
- F Cables shall be routed and secured in such a manner that they cannot come in contact with moving parts such as gears, switches, relays, slug racks, shafts, dials, and tuning capacitors. See figure 1-6, point D.
- G Cables which contain insulated wire shall be routed in such a manner that they are not exposed to excessive temperatures by heated or heat generating components.

1.3.2. (Cont)

- H Cables with a free end or ends must be retained in their connector cable clamps to maintain strain relief at all times for the wires connected to the connector terminals.
- I A pendent cable or wire (movable at one end) shall be restrained at the permanently connected end so as to prevent any chance of breakage due to flexing.
- J Mounting hardware of heavy components may be used to secure nylon cable clamps only after the heavy component is properly mounted.

1.3.3 Cable Protection

- A Wherever a cable is routed through a hole in a metal chassis, some means of protection, such as a grommet, must be used. See figure 6, point E. Cut grommets should not be used unless specified on the drawing and, if used, must provide adequate protection for each wire passing through the hole. A 1/16-inch minimum radius around the edge of the hole on both sides of the chassis will be acceptable. See paragraph 1.1.5, figure 1-1.
- B Wherever unsleeved cable is routed through a slot or against the edge of a metal chassis with constant pressure, the metal edges must have a 1/16-inch minimum radius. However, if constant pressure is not present between the cable and the edge of the chassis, sleeving or an equivalent protective material will be acceptable. See figure 1-6, point F, and paragraph 1.1.5, figure 1-2.
- C All cables should be routed and secured away from contact with sharp metal objects, such as studs, screws, threads, sharp corners on metal parts, and terminal ends. In cases where the wire passes over such sharp objects with no pressure exerted on the object by the cable, the use of sleeving or other suitable protective material over the cable or sharp object, at the point of contact, is acceptable. However, if continual pressure is exerted on the object by the cable, the use of protective material subject to cold-flow, as a substitute for relieving the pressure exerted by the cable, is not acceptable. See figure 6, point G and paragraph 1.1.5, figure 1-3.
- D Where it is necessary to use added protection for a cable, the protective material must be positioned and secured in such a manner it always will provide the protection intended.
- E The protective materials to be used for cables must meet all equipment specifications.
- F Cables which include conductors using metallic shielding unprotected by an outer insulation must be protected or secured to prevent the shielding from coming into contact with exposed terminals or conductors of a different potential.
- G Where cabling is employed between hinged parts, sufficient slack and protection shall be provided to prevent chafing or breaking of protective material or wires with repeated flexing.

1.4 BUS WIRE

1.4.1 General

All bus wire must be neat, direct, and without kinks or more bends than are necessary to give adequate clearance from adjacent parts or terminals. For details on terminating bus wire see paragraphs 1.5 and 1.6.

Imperfections and defects on bus wire shall be controlled by paragraph 1.1.3.C.

1.4.2 Slack

Enough slack shall be provided to prevent the application of any direct stress on parts involved as a result of flexing during operation of the equipment under any conditions of its specifications.

1.4.3 Clearance

Clearance between bare bus wire and any terminal or part carrying a different potential must be no less than .030 inch in their closest positions (including movement during vibration). High circuit potentials require more clearance. Length and size of unsupported and unsleeved bus shall be such that this condition can be met with the equipment subjected to any requirement of the specifications.

1.4.4 Insulation

In cases where the clearance requirement cannot be met, insulated wire should be used or the bus wire must be sleeved. Bus wire complete with extruded insulation is preferred to sleeved bus. If wire is sleeved, the sleeving must not be depended upon to protect the wire under pressure, as sleeving has a low mechanical strength and cold-flows under pressure. (Sleeving will not be required where the spacing requirement of 1.4.3 is met during time the equipment is subjected to specified vibration tests.) When sleeving is used, it must protect the intended point when it is in its worst possible position.

1.4.5 Rounded Edges on Tools

Bending and forming of bus wire shall be accomplished with approved tools having properly rounded edges to prevent damage to the wire.

1.5 MECHANICAL CONNECTIONS FOR SOLDERING

1.5.1 General Requirement

A mechanical connection is a connection before soldering designed to prohibit movement of a member in relation to its connecting member during the soldering operation.

Prior to the soldering process, the parts to be soldered shall be connected mechanically. This may be done by wrapping and crimping the wire on the terminal or inserting the wire through the hole in the terminal (where a hole is provided) and wrapping and crimping the wire.

1.5.2 Post Terminals

Wire larger than number 28 shall contact a terminal post a minimum of 60% but not more than 125% of the post periphery. The wire end shall be shaped to the terminal and not left extended. Figure 1-9 illustrates the minimum and maximum wrap.




Figure 1-9. Mechanical Wrap on Post

1.5.3 Small Wire Sizes

When connecting any stranded or solid wire of size no. 28 and smaller to a terminal, a minimum of 100% to a maximum of 200% wrap shall be required. If a hole is provided in the terminal, the wrap shall be made without using the hole.

1.5.4 Lug Without a Hole for Wire

When connecting stranded or solid wire of size no. 26 or larger to a terminal lug with no hole provided for the wire, the wrap shall contact a minimum of 3 sides of the lug, as in figure 1-10.




Figure 1-10. Wrap for Wire Size No. 26 or Larger on a Lug with No Hole

1.5.5 Terminal with a Hole for Wire

When connecting stranded or solid wire size no. 26 or larger to a terminal with a hole provided for the wire, the wire shall contact a minimum of 3 surfaces of the terminal and shall prevent movement of the wire during the normal soldering operation. However, the protruding end of the wire must not contact the wire insulation. See figure 1-11.




Figure 1-11. Minimum Wrap for No. 26 or Larger Wire

1.5.6 Location and Direction of Wrap

Where a connection is made by wrapping wires or component leads around a terminal, the end of the terminal shall be flush or project above the wires. When two or three wires or component leads are wrapped on the same terminal, they should be wrapped in the same direction.

1.5.7 Contact of Wire with Terminal

Any terminal must be large enough to provide adequate contact area for every wire that connects to it. The wrapping of wire upon wire without each contacting the terminal shall not be permitted.

1.5.8 Contact of Threaded Wire

Where a series of three or more terminals are required to be connected using solid wire, threading the wire shall be permitted provided the wire contacts a minimum of 10% of the terminal contact perimeter such as shown in figure 1-12. Threading shall be limited to terminals on an individual part or board to avoid stress between parts. Component leads shall not be threaded unless the first terminal (terminal closest to the component) is properly wrapped, with strain relief provided. If the distance between post terminals is more than 1/2 inch or if the wire is smaller than no. 22, the post terminals shall be wrapped, not threaded. Terminals which are intended to float after soldering, such as on connectors and tube sockets, may be threaded provided the individual float of each terminal is not impaired.




Figure 1-12. Threading Terminals with Wire

1.5.9 Avoiding Tension on Solder

Wire shall be wrapped to a terminal in such a manner that any tension on the wire shall be transmitted to the terminal and not to the solder. See figure 1-13.




Figure 1-13. Avoiding Tension on Soldered Joint

1.5.10 Wire Heavier than Terminal

Due to difficulty in handling large gauge wires (usually 16 or larger) and in making mechanical connections to comparatively small terminals, such wires should be terminated with lugs or other mechanical devices.

1.5.11 Minimum Terminal Spacing

Space between terminals must be sufficient to permit a minimum clearance of .030 inch (high circuit potentials may require more clearance).

1.5.12 Assembly of Solder Lug to Wire

Mechanical connection between a solder lug and the wire or wires to which it is assembled is obtained by crimping the "ears" of the lug around the wire as shown in figure 1-14. The stripped end of the wire shall protrude slightly beyond the lug ears to be soldered, but the wire and/or solder shall not enter the area so as to interfere with the hardware mounting. Where the lug used has two sets of "ears", the insulation should terminate approximately halfway between them. The "ears" adjacent to the insulation should be crimped firmly around the insulated wire after the soldering operation.




Figure 1-14. Lug Assembled to Wire

1.5.13 Wire to Component Lead Connection

Though not preferred, in making assemblies (other than cables) requiring wire to component lead connections, the smaller (or equal size) wire shall be wrapped a minimum of 1 complete turn around the other wire or lead as shown in figure 1-15. See section 2.6.8.




Figure 1-15. Wires Connected to Component Leads

1.5.14 Component Leads Used as Terminals

Though not preferred, if the design requires that the leads of a component are to be used as terminals, the body of the component shall be mechanically supported, and the component lead length used as a terminal shall be $\frac{3}{8} \pm \frac{1}{8}$ inch measured from the body of the component or component lead support, as shown in figure 1-16. The connecting wire or wires (never more than two) shall not be a larger gauge than the component lead. See section 2.4.5 and figure 2-1 for lead forming details.




Figure 1-16. Component Leads as Terminals

1.5.15 Wrapping on Adjacent Terminals


Wires shall not be wrapped on adjacent sides of adjacent terminals where spacing will not allow 0.030-inch minimum clearance with the terminals in the worst possible position after the connection is complete. See paragraph 4.1.1.B.

1.5.16 Miniature Tube Socket Wiring


To avoid shorts and potential shorts on miniature tube socket terminals when connecting stranded or solid wire, the following procedures shall be followed.

- A Where one or two wires are terminated, both wires shall be wrapped over the top of a terminal, unless the wire diameter is too great.

- B Where more than two wires are terminated, two of the wires shall be wrapped over the top and the balance wrapped on the proper side of a terminal.
- Where more than two wires are connected to adjacent terminals, the wires which are wrapped around the side of the terminal shall be wrapped on the same side.
- C It will not be necessary to wrap wires over the top of terminals 1 and 7 on a 7-terminal tube socket or terminals 1 and 9 on a 9-terminal tube socket, if the wire is wrapped on the side of the terminals next to the wide space between the terminals.
- D Where a miniature tube socket is assembled with a grounding shield, the terminals adjacent to the shield shall be twisted approximately 45° away from the shield before the connecting lead is wrapped. The mechanical connection wrap shall be over the top or on the opposite side of the terminal from the shield. See figure 1-17.
- E See 1.6.10 for soldering of sockets.



WIRES AND TERMINALS
ADJACENT TO SHIELD NOT
PROPERLY POSITIONED



WIRES AND TERMINALS
ADJACENT TO SHIELD
PROPERLY POSITIONED

Figure 1-17. Miniature Tube Socket with Shield

1.5.17 Wrapping on a Slotted Terminal

- A When connecting component leads or solid wires to a slotted (bifurcated) terminal, each lead or solid wire shall be held or connected so as to prevent movement of the lead. The extension of the component lead end through the terminal slot shall be from just visible to 1/16 inch max and shall permit the contour of the lead to be visible after soldering.
- B When connecting stranded wire to a bifurcated terminal, the wire shall be mechanically wrapped. See 1.5.2 and 1.5.3, and figure 1-18.




Figure 1-18. Minimum Wrap with Stranded Wire on Slotted Terminal

- C Component leads or wires should be fully seated in the terminal slot.
- D The number of leads or wires in a slotted terminal shall be limited to meet the requirements of 1.5.7.
- E Solid wires or leads shall not be deformed, nor stranded wires cut, in order to fit in the terminal slot. The slotted terminal shall not be altered to accommodate the insertion of wires or leads.
- F It is preferred that the insulation of wires routed through the back side of a hollow slotted type terminal be inserted into the terminal and the tinned lead wrapped around the terminal. See figure 1-18B. Wire leads used in this manner shall be inspected for defects due to stripping before use. Insulation of high heat resistance is required for this application.

1.5.18 Cup and Groove Type Terminals

- A When terminating stranded or solid wire to a cup or groove type terminal such as those used in connectors, the wire shall bottom in the terminal as shown in figure 1-19; or when a hole in the terminal is used, the connection shall meet the requirements of paragraph 1.5.5.




Figure 1-19. "Bottoming" in Terminals

- B The diameter of wire terminating in a cup or groove type terminal shall be less than or equal to the diameter of the maximum wire gauge allowable as specified on the connector specification drawing. The wire cross-section at the termination in a cup or groove type terminal shall not be altered. An adapter, such as 306-1000/1005 is recommended where the wire is too large for the terminal. Crimp connections shall be made in accordance with paragraph 1.7.2.
- C The maximum number of wires terminating in a cup or groove type terminal shall be that number of wires with combined wire diameters equal to the maximum wire diameter allowable as specified on the connector specification drawing.
- D All connector pins having float before soldering shall have individual float after soldering. Float shall be determined by moving the cup or groove type terminal or connector pin.
- E After soldering to a miniature cup or groove type terminal, the spacing between adjacent terminals shall not be materially decreased due to the soldering operation. A light film of solder on the outside of the cup or groove type terminal is allowable. Also when the lead is wrapped through a hole in a groove type terminal, the spacing between terminal rows after soldering shall meet the requirements of paragraph 1.5.11 or 4.1.1. B.
- F Prefilling of cup or groove-type terminals shall be permissible provided that the filling operation is immediately followed by the insertion of adequately tinned wire.

1.5.19 Control of Clippings

Methods should be provided to keep wire clippings out of electronic equipment rather than depending entirely on later removal.

1.5.20 Cloverleaf Terminals

- A When connecting leads or solid wires, each shall be held or connected to prevent movement during the soldering process.
- B Protrusion of the component lead through the terminal shall be from just visible to 1/16 inch maximum.
- C A center post shall be used for connection of stranded wire to the terminal in order to get at least 60 percent wrap.
- D Solid wires, component leads or center posts shall not be deformed to fit in the terminal. The terminal shall not be altered to accommodate wires, leads or posts.

1.6 HAND SOLDERING

1.6.1 Definition and Purpose

Soldering is the joining together of two metals by a fusible alloy. The alloy of tin and lead is called soft solder. Solder containing a small percentage of silver is sometimes used.

The purpose of soldering is to obtain a nonporous and continuously metallic connection that is not adversely affected by operational temperature extremes, that withstands torsional stress and strain without rupture, and that has a constant and permanent electrical value.

Wiring and Cabling

Since the prime application for soldering in electronic equipment is the joining of a wire to a terminal, standards in this section will be based on that operation. The same general requirements apply to other soldering applications.

1.6.2 Preparation

- A Surfaces to be soldered shall be free of grease, dirt, oxide, scale, or other foreign materials.
- B All wires, component leads, and terminals which do not have an easily solderable coating shall be tinned before soldering.
- C All forming of leads shall be done prior to soldering. All trimmed lead ends shall be protected by solder tinning or other protective coating.

1.6.3 Method

- A In making a proper solder joint, it is necessary that there be no movement of the members until the solder has hardened completely. Movement of the members could result in a fractured or weakened joint which would break later under strain. Prevention of this movement is the reason for making the wire mechanically secure to the terminal prior to soldering.
- B In the soldering operation, the member or members to be soldered must be hot enough to maintain the solder in a molten condition until the necessary "wetting" action takes place. It is important that the soldering iron or other source of heat be of adequate temperature and heat capacity to maintain the metal being soldered at the proper fusion temperature.
- C The soldering iron tip should be kept seated and tight within the iron and kept free from excessive oxidation to ensure maximum transfer of heat from the heating element to the tip. The diameter of the tip shall be as large as practical to ensure maximum heat transfer in a minimum length of time. A bright, clean, well tinned, smooth face shall be kept on the tip; the tinned portion should extend a minimum of 1/2 inch back from the pointed end.

- D Heat sinks free of rosin shall be used on the leads of all components that could be damaged by the heat of normal soldering.
- E If a solder connection is to be reheated, the old solder should be removed and new solder applied, unless the reason is insufficient solder, in which case additional solder would be applied.

1.6.4 Flux

- A The flux employed shall be type AR (rosin) as specified in Federal Specification QQ-S-571. Prior to the use of any other flux, approval of the cognizant Quality Standards Committee must be obtained and its use conducted in accordance with an applicable Process Specification.
- B The soldered connection should be cleaned of excessive rosin and other residues after soldering.

1.6.5 Choice of Solder

The solder alloy that melts most easily is 63% tin and 37% lead. Its melting point is 361°F. The solder spool or bar usually is marked with the tin percentage first, as 63/37, 60/40, 50/50, 40/60, or 30/70. The 63/37 solder is preferred (60/40 is also acceptable) unless otherwise specified.

If silver is included in the solder, the silver percentage figure usually follows the tin and lead percentages and is followed by the letters AG.

1.6.6 Wetting Action

Since soldering is an alloy fusion of the solder and the part, a good solder joint should give indications of a "wetting" action of the molten solder on the base metal. That is, the boundary of the solder at its junction with the part should be concave rather than convex. See figure 1-20 and figure 1-21. The solder should not have a dull appearance and should have no projections or sharp points.




Figure 1-20. Section Showing Acceptable Limits of Solder Volume




Figure 1-21. Section of Unacceptable Soldered Joint

Wiring and Cabling

1.6.7 Amount of Solder

Only enough solder should be applied to allow adequate alloying action to take place but the solder shall form a visible fillet between wire and terminal. The general outline of the members should be visible. See figure 1-20. It is not necessary to completely fill a terminal hole, provided that the above requirements are met.

1.6.8 Material Imbedded in Solder Joint

No insulation or other contaminating material shall be imbedded in a solder joint.

1.6.9 Wicking Under Insulation

Solder wicking is the flow of solder along a stranded conductor due to capillary action. Wicking should be held to a minimum.

1.6.10 Soldering to Sockets

Where a solder connection is to be made to the terminals of a receptacle, such as a connector, tube, or crystal socket, the solder shall not interfere with the proper spring action of the receptacle contacts.

1.6.11 Solder Pots

- A Before using a solder pot, the solder shall be completely molten, the solder stirred and dross removed. To prevent contamination of the solder, stainless steel or Teflon shall be used for stirring and removing dross.

The content of the solder pot must be maintained within the composition limits of Federal Spec. QQ-S-571 for type of solder used.

1.7 Solderless Electrical Connections

1.7.1 Mounting of Lugs

- A Stacking of open-end lugs shall be limited to a maximum of two under each nut (or nut, lock washer and flat washer sequence). Stacking of closed-end lugs shall be limited to a maximum of three under each nut (or nut, lock washer and flat washer sequence). When lugs are stacked, they must be positioned in such a manner that seating interference of the lugs does not exist. See figure 1-22.
- B Open-end lugs must be positioned so the slot is fully inserted against the mounting screw to get full benefit of the lug mounting surface.
- C The width of lugs, mounted in a terminal strip with barriers, shall be less than the spacing between barriers.
- D Liquid staking shall not be used for locking hardware where an electrical connection depends on the hardware.
- E Material subject to "cold flow" shall not be used in a hardware application when an electrical connection depends on the hardware pressure.




Figure 1-22. Stacking of Lugs

1.7.2 Crimp Connections

- A Mechanical connection between a crimp type lug and wire is obtained by crimping the lug to the wire as shown in figures 1-23 through 1-27. If the crimping tool and the contact are designed to grip the insulation, the insulation should be securely gripped by the crimp.
- B The mechanical connection of the wire to the contact shall be such that the wire shall neither pull out of a crimp nor break at the crimp before the minimum tensile load specified by the drawing or process specification is exceeded.

1.7.2 C Crimp Tools

Crimp connections shall be made with the proper crimping tool specified by the manufacturer of the connecting device. Each crimping hand tool must be equipped with a fail-proof ratchet device that secures the tool to the wire until sufficient force has been applied.

Crimping tools shall be checked and gauged at the specified intervals.

D Insulated Lug

The stripped end of the wire must be flush to extending visibly beyond the barrel of the lug after the crimping operation but shall not interfere with the lug mounting hardware. Caution must be taken that insulation is firmly gripped and does not enter conductor crimp area.




Figure 1-23. Insulated Lug

E Formed-Type Connector Contacts

The stripped portion of the wire must be visible at each end of the crimped wire barrel. The insulation support or stabilizer should appear rounded after crimp, but need not grip the insulation of the wire.




Figure 1-24. Formed Connector Contact

F Machined Closed-Barrel Contacts

Conductor should be visible in inspection hole.




Figure 1-25. Machined Closed-Barrel Contact

G Two-Piece Uninsulated Ferrule Termination

Shield should be visible but not extend beyond end of ferrule. Inner barrel should not compress conductor insulation after crimp.




Figure 1-26. Two-Piece Uninsulated Ferrule Termination

H One-Piece Ferrule Termination

Shield should be visible through inspection holes. Ground wire should also be visible through hole when inserted as shown in figure 1-27. Inner barrel must not compress insulation after crimp.




Figure 1-27. One-Piece Ferrule Termination

J Wire Variation

Wire other than that specified for a particular crimp device shall not be acceptable without Component Engineering approval. Wire with the same AWG size might be unacceptable because of different wire material; stranding, strand finish, or insulation.

K Fused Wire

Wire preparation for use with crimp devices shall not include fusing or tinning during or after stripping.

L Solid Wire

The use of a crimp device with solid wire is NOT acceptable without approval by the cognizant Quality Standards Committee.

1.8 SLEEVING

1.8.1 Connector Terminals

The use of sleeving on connector terminals shall be limited to the prevention of voltage breakdown and/or support, except when it is required by specification.

1.8.2 Pressure or Abrasive Action

Sleeving shall not be used for electrical protection where constant pressure or abrasive action on the sleeving is present.

1.8.3 Grade and Fit

Sleeving shall be of an electrical grade and shall fit snugly on the connecting wire, connector terminal or object which it is to protect and/or support without damage to the sleeving.

1.8.4 Environmental Requirement

The mechanical and electrical properties of sleeving shall not be impaired by exposure to the temperature or other environmental extremes of the equipment specification.

1.8.5 Cable Covering

When sleeving is used to cover a cable, the sleeving shall be secured at the ends to maintain its intended position.

1.8.6 Tolerance on Length

Standard tolerance on over-all length of sleeving is as follows:

<u>Over-all Length</u>	<u>Tolerance</u>
1/8 inch through 3 inches	±1/32 inch
Over 3 inches	±1/8 inch

Squareness of cut shall be such that no portion of the over-all length shall exceed the specified tolerance.

1.9 COILS

1.9.1 Marking

See paragraphs 2.4.2 and 4.11 for information on marking.

1.9.2 Insulation

- A Enamel insulation on wire should not be damaged between tinned portions to the extent that the base material is exposed.
- B An assembly that has a member within 1/32 inch of another member of a different potential must have one of those members suitably insulated.

1.9.3 Broken Strands

No broken strands are allowed in the wire of a winding or the leads of a coil.

1.9.4 Slipped Turns

Universal-wound coils shall not have any turns which have slipped off the top of the wind during or after the winding operation.

1.9.5 Minimum Inside Diameter

- A No mold release, cement, coil dope, etc., shall be used in such a quantity or manner as to reduce the minimum inside diameter of a coil form after assembly or encapsulation.
- B The minimum inside diameter of a coil form shall be checked by a slip fit, not a press fit, on a plug gauge the size of the minimum ID. The minimum ID of a coil form must be maintained after the coil has been wound on the form.

1.9.6 Coil Coating

A coil winding on a form must be coated with an approved coil dope, cement or epoxy coating unless it is to be encapsulated or potted. The drawing shall specify the coating to be used or shall specify any change from this requirement.

1.9.7 Voids in Potted Assembly

There shall be no undesirable voids in the compound of a potted coil assembly. This may necessitate sectioning a sample potted assembly for inspection from time to time.

1.9.8 Wiring and Soldering

- A The insulated portion of the wire shall not extend into the connections.
- B See paragraph 1.1 for information on insulated wire.
- C See paragraph 1.5 for information on mechanical connections.
- D See paragraph 1.6 for information on soldering.

1.9.9 Similar Coils

Where there are several coils in an equipment that are the same except for a difference in the number of turns, some means must be used to readily distinguish between them.

1.9.10 Securing of Coils, Leads and Terminals

- A See section 3 for general information on fastenings.
- B Windings must not be loose on a coil form. To prevent the unwinding of a coil wire before the coil is connected to terminals, securing of the ends of the coil should not be dependent on coil dope or spot cement only.
- C When mounted on a coil form, ring-type terminals shall be approximately perpendicular to the axis of the form and shall meet the spacing requirements of the drawing or specification. In cases not controlled by the drawing or specification, the terminal shall be not more than 15° from perpendicular.




Figure 1-28. Mounting of Ring Terminals

- D Terminals shall be secured to the coil form with R313, part no. 005-0305-00, cement or equivalent if the terminals will not maintain their specified position on the form during and after winding. Cement used to secure terminals to forms shall not extend into the coil winding area of the form; the cement should be applied to the outside of the terminal rings, rather than between the rings.




Figure 1-29. Cementing Terminals to Coil Form

1.9.11 Resistor Notches for Coil Winding

For wire smaller than no. 18, it may be necessary to grind notches in the ends of a resistor to hold coil leads in place. These notches shall be no deeper than necessary to hold the wire. Under no circumstances shall the depth of these notches exceed .020 inch.




Figure 1-30. Maximum Depth of Resistor Notches for Coil Winding

1.9.12 Damage

Coil forms shall not be chipped, cracked, or otherwise damaged to the extent that the structural strength is affected.

1.9.13 Winding Direction

The drawing should specify the winding direction. Where existing drawings have not been revised to specify the direction, coils should be right-hand wound (regardless of how pictured on the drawing) because most coil winding machines are designed for only right-hand winding.

1.10 STRAY MATERIAL

Care shall be taken during all stages of assembly to prevent the entrance of solder drippings, stray lugs, wire and insulation clippings, excess solder flux, or any other material that could cause a potential short or other malfunction in the equipment.

1.11 CONNECTING 3-WIRE A-C CORD

The connections shown in figure 1-31 offer maximum protection to the operator and to the equipment. It is also the plan approved in the national electrical code.




Figure 1-31. Correct Method of Connecting 3-Wire A-C Cord for 115 Volts

electrical components

2.1 SCOPE

The term "Electrical Components" in this section shall be defined as all items included in an equipment that provide an electrical function with the exception of wiring, cabling, and electromechanical components which are covered in other parts of this manual.

Included in the electrical component category are:

- a. Resistors, potentiometers, thermistors, etc.
- b. Capacitors
- c. Vacuum tubes
- d. Transistors
- e. Crystals
- f. Diodes
- g. Coils (Also see paragraph 1.9)
- h. Chokes, inductors, toroids, etc.
- i. Transformers (r-f, i-f, audio, and power)
- j. Switches (See also paragraph 4.6)
- k. Filters, delay lines, etc.
- l. Pilot lamps, fuses, etc.
- m. Sockets (tube, transistor, and lamp) Also see paragraph 1.5.16.

2.2 STORAGE, HANDLING, AND TRANSPORTATION

2.2.1 Storage

Electrical components shall be packaged and/or stored in such a manner that the surfaces are protected from contaminants such as dust, corrosive elements, and oily compounds. Components shall be stored so as to prevent damage.

Contaminated components shall be cleaned before they are used. Normal oxidation of exposed surfaces is not included in this requirement unless it is detrimental to proper functioning, soldering, or general appearance.

2.2.2 Damage and Contamination by Handling

Care shall be exercised during routine inventory and other actions requiring handling of components to prevent damage by contamination, vibration, and shock.

Examples of careless acts in handling components:

1. Throwing components into a stock bin
2. Dropping components onto hard surfaces
3. Handling components with dirty or oily hands

Electrical Components

2.2.2 (Cont)

Careless handling of assemblies containing delicate components also is undesirable. Such items as vacuum tubes, crystals, mechanical filters, and diodes may be extremely susceptible to damage by mechanical shock.

Components susceptible to shock damage that have been subjected to severe shock forces shall not be used in the assembly of an equipment until it has been ascertained by subsequent inspection or test that no damage had been sustained.

NOTE: A component dropped onto a hard surface, such as a concrete floor, may be subjected to shock exceeding one thousand times the force of gravity.

2.2.3 Damage in Transportation

A reasonable degree of protection shall be provided to prevent mechanical damage in normal handling and transportation.

2.2.4 Bending of Component Leads for Storage

Bending of component leads to accommodate larger volumes of parts in stock bins shall be prohibited. Damage to leads, seals, and internal elements can result.

2.3 COMPONENT DEFECTS

Since all components are not 100% inspected in receiving inspection and since a component may possibly be damaged after inspection, an assembly operator should reject an obviously defective component.

2.3.1 Damage to Insulation

The insulating or sealing material on molded or coated resistors, chokes, etc., shall not be chipped or otherwise damaged to the extent that the reliability of the component is threatened. A component damaged to this extent, though functioning at the time of final test in manufacture, may later fail after a short period of service.

2.3.2 Illegible Component Markings

Markings pertaining to values, tolerances, ratings, etc., placed on the component by the manufacturer as required by specification, shall be intact and legible. This is a requirement of many of our customers to simplify equipment maintenance.

2.3.3 Dents and Chips

Dents or chipped areas in component bodies that threaten the reliability of the parts shall be cause for rejection. A typical component that may exhibit this type of damage is the hermetically sealed capacitor. Such damage can result in short circuiting or leakage within the part.

2.3.4 Cracks

Cracks in electrical component bodies shall be cause for rejection.

2.3.5 Improper Lead Tinning

Component leads shall be clean and free of foreign materials and shall be tinned properly using methods prescribed by Engineering. Subsequent soldering of component leads can be extremely difficult if the leads carry contaminants, or if the wrong proportions of solder elements are present in the tinned surfaces.

NOTE: Intermittents that develop in electrical circuits are many times caused by contaminants in the solder joints.

2.3.6 Lead Defects Reference

Component leads shall be free of defects to the extent specified in paragraph 1.1.3. C.

2.3.7 Bent Leads

Component leads should be reasonably straight and free of sharp kinks to simplify lead forming, maintain mounting rigidity, and provide uniformity of mounting. See paragraph 2.2.4

Care shall be exercised in straightening component leads to prevent undue strain on the component. Some diodes, capacitors, and crystals can be damaged easily by exerting excessive tension on the leads.

2.3.8 Stray Material

A component must not contain loose solder, wire clippings, stray hardware, or other material that may interfere with its operation.

2.4 COMPONENT LEAD FORMING AND SOLDERING

2.4.1 Changes in Ratings Due to Forming

Any process of straightening, cutting, bending, inserting, crimping, or clinching of wire leads which may result in changes in ratings or values, or other damage, shall not be permitted.

Whenever possible when component leads are formed, they shall be supported close to component body and formed beyond the area of support. See paragraphs 2.4.5 and 2.5.

2.4.2 Readability of Markings

Wherever possible, component leads shall be formed in such a manner that the important markings are readable on the most easily visible surfaces when the component is in its mounted position.

2.4.3 Sharp Bends in Component Leads

Sharp bends shall be avoided unless specified in the equipment design requirements. Sharp bends are subject to breakage at the point of the bend in severe vibration environments. (See paragraph 2.5.)

2.4.4 Thermoplastic and Teflon Sleeving

When bending sleeved component leads, proper consideration shall be given the type of sleeving used. Teflon and thermoplastic sleeving, in particular, must not be used where sharp lead bends are employed. Subsequent cold flow of the material can result in exposure of the lead and shorting to adjacent circuitry or chassis surfaces. Generally, Teflon and thermoplastic sleeving shall not be used if a possibility of tension on the material exists.

Bend configurations shall properly accommodate the type of sleeving used, to prevent cracks or breaks in the sleeving material.

2.4.5 Lead Forming

Lead forming is the process of shaping a lead by fingers, tools, or fixtures in order to permit installation. Care must be exercised during forming to prevent damage to the lead, component body, or seal. Therefore, forming shall begin at least two lead diameters away from the component body or seal (see figure 2-1). On "top hat" type tantalum capacitors, the lead shall not be formed between the weld and the capacitor body. Tantalum leads on tubular capacitors may be carefully formed over round-nosed pliers or similar tools which will provide a minimum of two diameters inside radius.

After forming, a bend in the segment of lead within two lead diameters from the component body is acceptable provided that:

- (1) When there is no obvious radius (or a radius less than two lead diameters) in the lead, the lead shall not be bent more than 15 degrees from the normal center line of the lead.
- (2) When there is an obvious radius in the lead, the minimum inside radius of the bend shall be equal to at least two lead diameters.




Figure 2-1. Lead Forming

2.4.6 Soldering on a Welded Area

No portion of a weld shall be included in a solder joint, because solder may not properly bond to a welded area.




Figure 2-2. Examples of Specialized Pliers for Lead Forming

2.5 USE OF TOOLS FOR WIRING

2.5.1 General

Assembly line operators shall be trained in the use of the various types of tools appropriate to their jobs.

2.5.2 Tools with Sharp Edges

The forming of component leads with sharp-edged tools shall not be permitted.

2.5.3 Control of Clippings

Providing method(s) to keep clippings out of electronic equipment is preferable to depending entirely on later removal.

2.6 COMPONENT POSITIONING AND MOUNTING

2.6.1 Positioning Within Boundaries

All components should be mounted in such a manner that they are positioned within the boundaries of the unit in which they are assembled. This will eliminate the undesirable pushing of components into intended positions when closing the unit.

Electrical Components

2.6.2 Neatness in Mounting

Whenever possible, lead-mounted components should be positioned so that the major axis of the component is parallel to any two of the three major planes (sides) of the unit. See figures 2-3 and 2-4. This practice affords a much neater and, in most cases, a more reliable unit assembly.

2.6.3 Crossing of Component Leads

The crossing of component leads shall be avoided if at all possible. When necessary to cross component bodies or leads, it is preferred that components shall be positioned so that the lead of one crosses the body of the other or so that the bodies cross each other. In any case where there would be a potential short, at least one of the leads shall be properly insulated.




Figure 2-3. Section of Metal Terminal Board Assembly

2.6.4 Access to Mounting Holes and Controls

Components shall be positioned to provide clear access to mounting holes and controls.

2.6.5 Centering of Components

Whenever possible, components should be centered between connections. This requirement affords the best weight distribution to the supporting leads and equalizes heat dissipation during the soldering operation.




Figure 2-4. Mounting Layout

2.6.6 Strain Relief

Component leads shall not be stressed between mounting points. Adequate strain relief, as required for the part (considering environmental conditions), shall be provided to prevent damage to the component and solder joints. See figures 2-3, 2-5 and 2-6 for examples. In certain cases, terminal configuration and material may provide the necessary strain relief.




Figure 2-5. Examples of Strain Relief




Figure 2-6. Examples of Mounting Components

2.6.7 Component Support

Components which, due to their size, weight, or shape, may be damaged or cause damage when subjected to vibration and shock shall not depend solely upon their leads for support. A suitable means of additional support, that is, clamps or cementing compounds, shall be provided. Components weighing more than 1/2 ounce should be supported by means other than their leads.

Electrical Components

2.6.8 Misuse of Components for Support

Lead-mounted components shall not be used as a means of support or positioning for wires, cables, or other components. To do so would add strain to the leads and may result in damage to the component. However, when approved by a Quality representative, two components may be "piggy-backed" as shown in figure 1-15. This method could be used when the terminal is too small for the leads from both components when a design change requires an added component and it is impractical to provide a larger terminal.

2.6.9 Clearance from Sharp Edges and Wiring

Mounted components shall properly clear all sharp edges, mounting hardware and wiring.

2.6.10 Vibration

All lead mounted electrical components shall be mounted in a manner that will prevent damage due to vibration. Consideration must be given to such items as component weight, lead length and diameter, and end-item application.

2.6.11 Mounting of Heat Dissipating Components

Components dissipating appreciable heat, such as vacuum tubes and dropping resistors, shall be mounted with sufficient clearance from adjacent components to prevent thermal damage.

2.6.12 Heat Sensitive Components

Special consideration shall be given to mounting heat sensitive components. Heat sensitive components require adequate heat sinks for transferring heat away from the components. Heat sinks must be kept free of rosin.

When feasible, the component arrangements should be made in the final design stage so that sufficient lead length between the component body and solder joint is assured.



Figure 2-7. Examples of Commercially Available Heat Sinks

2.6.13 Mounting of Components into Tubelets

Extreme care shall be exercised when mounting components into tubelets. Lead bend dimensions shall be such that minimum effort is required to position the component properly. Damage due to cracked bodies and seals may result unless these precautionary measures are observed.

2.6.14 Centering of Clip-Mounted Components

Clip-mounted components shall be centered in the clip to prevent possible loosening or shorting from lead to clip during vibration.

Electrical Components

2.6.15 Tightness of Mounting Clips

Component mounting clips shall not be so tight that the bodies of the components are deformed or broken. Capacitors and glass envelope vacuum tubes and diodes require special consideration in this regard.

2.6.16 Positioning of Stud-Mounted Components

Stud-mounted components should have sufficient clearance from adjacent wiring and cables to prevent abrasion damage. See 1.1.4.

2.6.17 Mounting of Components Having Locating Tabs

Components with locating tabs, such as some transistors, shall be prepositioned properly over locating holes prior to the fastening operation. Distorted and damaged component bodies can result from improper locating procedure.

2.6.18 Connections to Fuse Posts

The metal structure which terminates in the cap of a post-type fuse holder shall not be connected to the "hot" side, to avoid a shock hazard.

2.6.19 Twist-Tab Components

Twist-tab mounted components shall be mounted firmly and securely by twisting each tab a minimum of 45° to a maximum of 90° from its original position. Care must be taken to avoid shearing the tabs during the twisting.



Grounding of twist-tab mounted components must not depend on pressure between tab and mounting surface. Grounding must be provided with wire, braid, strap, or some other form of positive electrical connection.

3.1 MACHINE SCREWS

Machine screws are used extensively in preference to permanent fastening, such as rivets, because they permit removal and reassembly many times during the life of an equipment without loss of structural integrity. The use of machine screws facilitates preventive and remedial maintenance; Phillips panhead screws are preferred. The Phillips head retains the screwdriver better than a slotted head, thereby reducing the possibility of screwdriver slippage and resultant damage to the surrounding area.

Head types of machine screws in common use at Collins Radio Company are illustrated below:

PREFERRED



PREFERRED FOR OVERALL MACHINE SCREW USE. (GRADUALLY REPLACING ROUND AND BINDING HEAD SCREWS THROUGHOUT INDUSTRY)

PHILLIPS PAN HEAD

ACCEPTABLE



PHILLIPS FILLISTER HEAD



PHILLIPS FLAT HEAD



PHILLIPS OVAL HEAD

USED IN COUNTERBORES OR OTHER APPLICATIONS REQUIRING REDUCED HEAD DIAMETER.

USED IN COUNTERSUNK HOLES TO OBTAIN FLUSH FIT AT PERIPHERY OF HEAD.

Figure 3-1. Screw Heads in Common Use at Collins

3.1 (Cont)

Heads with other contours and types of drives are commercially available and are sometimes used in Collins equipment in applications where they are uniquely suited. These include slotted and hexagon head machine screws, as well as hexagon and socket head cap screws.


3.1.1 Materials and Finishes

- A Stainless steel screws are preferred for general fastening applications. Although more costly than carbon steel screws, stainless steel screws have adequate strength and do not require plating or other applied finish to provide resistance to corrosion or enhance appearance. Brass screws, nickel plated, are preferred for electrical connections. (Steel screws can be used to secure an electrical connection if the screw is not necessarily part of the conductive path.) Steel fastenings must not be located in an r-f field strong enough to cause appreciable heating. Severe heat may damage the fastening components and/or adjacent parts; brass or other nonferrous fastenings are not similarly affected by an r-f field.
- B Whenever possible, fastener items in each sequence (for example, screw, lock washer, and nut) should be of the same basic material.
- C The ground connection area on any metal surface must be clean and free from any contaminant, paint, or other finish that may reduce the electrical conductivity.


3.1.2 Countersunk Screws (Flat and Oval Heads)

- A The heads of flathead screws should seat flush, or slightly below flush, with the panel or part through which they pass. The self-centering feature of a flathead or oval-head screw in a countersunk hole increases the between-hole tolerance problem. A preferred method of achieving flushness when required is the use of a panhead screw with the head recessed in a counterbore or dimple. This provides top surface flushness while permitting generous clearance holes.

PANHEAD SCREW RECESSED
IN DIMPLE IN THIN SHEET METAL



USING FLATHEAD SCREWS ON A THIN PANEL



- B Whenever the lower portion of the head of a flathead screw passes completely through a panel or part and could interfere with proper seating of the next part in the sequence, one of the following practices should be followed:

1. The latter part countersunk to receive the head.
2. An undercut flathead screw used.

Figure 3-2. Flathead Screws
on a Thin Panel

3.1.2. B (Cont)

Using 100° flathead screws, which have slightly lower head height than 82° screws, minimizes the problem of bottoming out.

3.1.3 Preferred Sizes and Class of Fit

2-56 NC-2A	*10-24 NC-2A
4-40 NC-2A	10-32 NF-2A
6-32 NC-2A	1/4-20 NC-2A
8-32 NC-2A	

*Coarse threads are preferred in soft material.

3.1.4 Minimum Thread Engagement and Thread Inserts

- A The length of usable thread for tapped holes in steel or hard brass shall be at least equal to the nominal thickness of the corresponding standard machine screw nut.

Table of Standard Machine Screw Nut Thickness

<u>Screw Size</u>	<u>Nut Thickness</u>
No. 0	3/64
No. 1	3/64
No. 2	1/16
No. 3	1/16
No. 4	3/32
No. 6	7/64
No. 8	1/8
No. 10	1/8
No. 12	5/32
1/4	3/16
5/16	7/32
3/8	1/4

- B Tapped holes in ceramic parts have brittle threads that are often oversize, thus increasing the danger of stripping. Tapped holes in ceramic parts are to be avoided wherever possible. Screws threaded into ceramic material must have a minimum usable engagement equal to one screw diameter or 3/16 inch, whichever is greater.
- C Tapped holes in aluminum, magnesium, or other soft material are not permitted in applications requiring frequent disassembly and reassembly. When threads in soft material are required, the usable thread engagement should be approximately 50% greater than the engagement for steel.
- D Use of a stainless steel or cadmium plated steel thread insert is required in soft metals where relatively high strength is needed, or when frequent disassembly may occur.

Thread inserts shall be constructed and installed so as to permit firm anchoring in the aluminum alloy or magnesium alloy part. They must be replaceable in case of damage to the threads.

Fastening

- 3.1.4.E Holes tapped directly into aluminum alloy or magnesium alloy materials for the purpose of mounting nameplates or for other nonstructural purposes need not conform strictly to the thread engagement requirements outlined above.

3.1.5 Thread Projection

- A Machine screw standard length tolerances always run to the minus side, never to the plus. Standard screw length tolerances are as follows:

Up to and including 1 inch length +0, -1/32 inch.

Over 1 inch to and including 2 inches +0, -1/16 inch.

Over 2 inches +0, -3/32 inch.

EXAMPLE: A 1/4-inch long screw is not guaranteed to be more than 7/32 inch long.

- B The minimum projection of a screw or threaded stud beyond a machine screw nut, locking nut, or other tapped part should be 1-1/2 threads. To insure adequate thread engagement, a thin nut should not be substituted for a standard nut for the sole purpose of meeting the thread projection requirement. Maximum projection beyond the nut (or other tapped part) shall be limited by the shortest standard screw meeting this requirement.

- C If strength requirements are met, some acceptable reasons for having less than 1-1/2 projecting threads (but not less than flush) are:

1. Where projecting threads would interfere with the placement of another part.
2. Where there is a possibility of arcing or corona discharge from the screw point.
3. Where the tapped part has an engagement of 5 usable threads. (The screw need not protrude at all in this case.)
4. When threads projecting beyond a mounting nut would be unsightly on panel mounted components such as switches and potentiometers.
5. Where an elastic stop nut is used. (An absolute minimum of 1/2 thread is required in this case.)

- D The rules for minimum projection for machine screws shall apply to threaded studs on purchased components, such as transformers. Maximum projection shall be limited by the proximity of other parts.

3.1.6 Tightness

All threaded fastenings must be tight. Torque wrenches or torque screwdrivers often aid in assuring proper tightness of threaded parts and should be used where screw torque is specified. An adequate concept of "tightness" cannot be based on torque alone, however. It must be considered that torque is just the means by which tension is developed in the shank of the tightened screw. This tension must compress the parts being fastened sufficiently to withstand separation forces such as vibration or shock that may occur during the useful life of the

3.1.6 (Cont)

equipment. Over-tightening may result in broken screws, either at initial assembly or at some later date.

Many factors affect the optimum torque required for driving small machine screws to a point where the proper tension is reached but not exceeded. These factors include friction at the bearing surfaces, friction of the mating threads, length of thread engagement, presence or absence of lubrication, type of lock washer or lock nut, and hardness and surface finish of the mating parts.

Most materials commonly fastened by machine screws (including metal) are compressible, and all screws are elastic within narrow limits. A few hours or days after initial tightening, a properly tightened screw is sometimes pronounced slightly loose because of metal fatigue in the stressed screw and/or creep of the compressed material. Repeated tightening in such instances can be more detrimental than beneficial. Reliable locking devices will compensate adequately for this apparent relaxation.

Because of the many variables affecting hand-tightening, it must be stated that no simple chart of tightening torque or easily applied "rule of thumb" has yet been devised that will replace a good assembly operator's judgment and experience. However, when fasteners loosen and cause equipment failure, they usually do so, not because of failure of the locking device, but because of insufficient initial tightening.

3.1.7 Screwhead Imperfections


Slots and recesses in screwheads should present a good appearance free from defects and damage. Damage of slotted screwheads generally occurs from the use of worn screwdriver blades or careless use of the screwdriver. Flat-blade screwdrivers should be reground when necessary, with flat sides parallel or slightly hollow ground and should fit the screw slot.

Apparent defects in Phillips screwheads are of two types:


- a. Obvious damage commonly called "rounding out" of the recess, caused by:
 1. Failure to use sufficient seating force to keep the screwdriver fully engaged.
 2. Use of dull or badly worn drivers.
 3. Use of the wrong size screwdriver. Phillips drivers come in 5 sizes for use as shown below.

<u>Screwdriver Size</u>	<u>for Screw Size</u>
#0	0, 1
#1	2, 3, 4
#2	6, 8, 10
#3	12, 1/4
#4	5/16, 3/8


NOT ACCEPTABLE






LARGE, OPEN FRACTURES
EXTENDING HALFWAY OR
MORE THAN HALFWAY
TO THE RECESS




OPEN, ANGULAR
FRACTURES ON
EDGE OF HEAD




SLIVERS OR LOOSE
FLAKES ON TOP OF
HEAD




ACCEPTABLE




SLIGHT "FRACTURES"
NOT EXTENDING HALF-
WAY TO RECESS AND
NOT AFFECTING
USEABILITY



SLIGHT
HAIRLINES



SLIGHT RECESS
FLOW LINES



SLIGHT TOOL MARKS;
SLIGHT PIN MARKS

Figure 3-3. Screwhead Imperfections

3.1.7 (Cont)

- b. Apparent "cracks" or "fractures" which actually are portions of the head where the metal hasn't flowed freely and fused together during the cold-heading process.

Figure 3 illustrates acceptable and unacceptable imperfections.

3.1.8 Captive Screws

- A Module hold-down screws generally are of special design but should conform to standard screw requirements in all possible details. (See module screw standards in Component Standards Manual.) Module screws are made of 18-8 or 430 stainless steel and are often driven into stainless steel inserts or nuts in the main chassis. Similar metals in screw and nut under high unit load forces, as in a properly tightened threaded assembly, tend to gall and seize, and shall be lubricated with a dry lubricant such as Molycote M-88 (Collins part number 005-0405-00). Grease or oil shall not be used because they pick up dust and also may cause contamination of surrounding surfaces and parts.
- B Screws used for holding parts or subassemblies are often standard screws with a retaining device such as a spring sleeve (Collins part number 340-0641/0643-00) to prevent loss of the screw. Screws with undercut portions or retaining ring grooves are more costly than standard screws and require a special order.

3.2 SETSCREWS

3.2.1 General

Setscrews are used as semipermanent fasteners to secure items such as knobs, collars, sheaves, and gears to shafts or similar parts. Parts that are to be attached permanently to shafts shall not depend on setscrews only.

Setscrew preference will generally be governed by application and ease of assembly, consistent with meeting all design and/or other specified requirements.

Frequently a setscrew is used as an adjustment aid prior to a pinning operation; it should be removed following the installation of the pin.

The holding power of a setscrew to resist rotational, oscillatory, or axial forces is a function of many variables such as screw size, seating torque, plating, shaft hardness, number of setscrews, and screw-point type. These variables, except for seating torque, are fixed by the design of the units. Two screws should be used to secure parts to shafts that are not flatted; they should be spaced not less than 90° nor more than 120° apart. A single setscrew may be adequate in certain low torque applications as in small knobs with tear-drop shaped shaft holes providing three point contact.

The setscrew develops its holding power through the frictional force imparted to the parts being secured to each other. Extensive tests have shown that the torsional holding power of a setscrew is almost directly proportional to the seating torque for cup, flat, and oval point setscrews. The setscrew point, by

Fastening

3.2.1 (Cont)

its penetration, can increase the holding power for a given application. Screws that are cadmium or zinc plated usually provide an increase in holding power since the plating acts as a lubricant and therefore less of the applied tightening force is needed to overcome friction at the mating threads.

3.2.2

Types of Drives

Generally, the preferred setscrew drives at Collins Radio Company are multiple spline (fluted) socket (figure 3-4) and hexagon socket (figure 3-5). Slotted setscrews (figure 3-6) are also used. Design considerations and/or customer specifications govern their individual usage.



SPLINE (FLUTED) SOCKET DRIVE

Figure 3-4. Spline Socket Setscrew



HEXAGON SOCKET DRIVE

Figure 3-5. Hexagon Socket Setscrew



SLOTTED DRIVE

Figure 3-6. Slotted Setscrew

3.2.3

Point Styles



OVAL POINT



CUP POINT



CONE POINT

Figure 3-7. Common Setscrew Points

3.2.3 (Cont)

All set screws tightened on a round shaft may damage the shaft so it is difficult to remove or reposition a part. The oval point design damages the round shaft to a lesser extent than the cup point. On shafts that have a flat area for the set-screw point to seat against, either cup or oval points are satisfactory, since a burr on a flat area will not interfere with removal.

Cone point setscrews are used more often as pivots than for securing parts to shafts. They must always seat in a suitably countersunk hole.

3.2.4 Locking

Setscrews shall be locked in a manner that will not prevent the removal and repair or adversely affect the function of the item being locked. Typical methods of locking setscrews are described in paragraphs 3.7.1 and 3.7.3.

3.3 TAPPING SCREWS

Thread-cutting and thread-forming screws are used where construction is improved by their use. Normally they are not used where loosening or removal is required during operation or maintenance of the equipment. Chips formed by thread-cutting screws shall be removed at a very early stage of assembly (to eliminate entrance of tiny metal particles into relays or other electrical components that are to be assembled to the structure later).

Thread-forming screws may have as little as one thread engaged in steel, stainless steel, or hardened steel. Thread-cutting screws should have a minimum thread engagement approximately equal to that specified for machine screws.

3.3.1 Materials and Finishes

Preferred materials and finishes for tapping screws are:

1. Stainless steel, heat treated, plain finish.
2. Carbon steel, heat treated, cadmium plated, chromate dipped.


3.3.2 Types of Tapping Screws

Figure 3-8. Tapping Screws

NOTE: Head types for tapping screws are the same as for machine screws.

3.4 NUTS

3.4.1 General

The most common type of nut used at Collins Radio Company is the hexagonal shaped American Standard machine screw nut. The internal thread of the nut usually conforms to either the fine or coarse American Standard thread form. The primary use of the nut is for fastening. It also can be used for adjustment and for transmitting motion and/or power with a large mechanical advantage. Materials and finishes used for nuts usually are the same as those used for screws as specified in paragraph 3.1.1. The basic dimensions of the nut are as illustrated below.




Figure 3-9. Nut Size Specifications

Application and installation of all captive nuts (nuts attached to structures by riveting or pressing operations) should be in accordance with the manufacturers' latest recommendations. There is a very great variety of nonlocking, locking, and insert types of nuts. The following paragraphs are descriptive of the most common types used at Collins Radio Company.

3.4.2 Nonlocking Nuts

- A standard machine screw nut is a solid nut with a hexagonal base, with or without a washer face. The six essentially rectangular sides serve as wrenching flats. Above the 1/4-inch size, nuts are available in various dimensional series, such as finished hexagon and regular hexagon, and within each series, three thicknesses: standard, thin (or jam) and thick, as shown in figure 3-10.




Figure 3-10. Nut Thickness

3.4.2. (Cont)

- B The Pem nut is a patented self-clinching nut made of hardened steel. The nut is pressed into a prepared hole. Flow of metal around a tapered shank and into a clinching ring locks the nut in place. Provision must be made in design to allow for edge distortion of sheet metal due to metal displacement. It may be used in applications which require a rapid assembly for either blind or accessible locations in thin metal members. Load must be applied in direction shown.




Figure 3-11. Pem Nut Assembly

- C The hexagon captive nut is used in applications similar to the Pem nut. The load should be applied in the direction shown in figure 3-12; however, informal tests have shown that it is capable of withstanding almost equal loading in the opposite direction. The proper application of this nut in application types 1 and 2 is characterized by having the round section of the nut pressed flush with the bottom surface of the metal. In application type 3, the hexagon portion is pressed flush with the top surface of metal; be careful to avoid distorting the first thread during installation. (Further application data appears in Collins Component Standards Vol. 1.)




Figure 3-12. Hexagon Captive Nuts

- D Angle nuts (angle fasteners) are used in applications where the part to be attached is at right angles to the mounting surface of the nut as shown in figure 3-13. The attachment of the nut requires riveting and this should conform to acceptable riveting standards as set forth in paragraph 3.5.

Care must be exercised in the placement of the body of the nut so that the axis of thread is perpendicular to the mounting hole in the part to be attached to prevent cross threading of the screw within the angle nut. Caution should be employed during the staking operation to prevent distortion of the threads.




Figure 3-13. Typical Angle Nut

3.4.3 Locking Nuts

Vibration, cyclic loading, and special assembly provision are common problems that often require more than ordinary measures in fastening design to achieve a satisfactory solution. To meet these conditions, a number of practical and effective nut designs with special locking features have been developed and the most common used by Collins Radio Company are discussed in the following paragraphs.

A Elastic Stop Nuts

All Elastic Stop Nuts are prevailing torque locknuts, that is, they exert a constant constraining force on the screw threads. Unlike lock washers, prevailing torque lock nuts do not depend on sustained tension in the screw shank for their locking action. The most common types of Elastic Stop Nuts are illustrated in figure 3-14. The metal body contains a compression locking collar built into the top of the nut. The compression collar is a resilient material, usually nylon. CAUTION: Anodized elastic stop nuts must not be used for electrical ground connections.

The collar is deformed when the screw is inserted and the elastic memory of the plastic provides a locking frictional grip on the screw to resist the forces imposed under environmental conditions. For proper operation of the nut, it is essential that the screw threads project a minimum of 1/2 thread beyond the plastic collar.




Figure 3-14. Common Elastic Stop Nuts

(1-1/2 threads minimum is preferred.) The stop collar also provides a liquid seal for applications requiring this function. Elastic Stop Nuts are suitable for use in equipment that operates continuously up to 250°F. Miniature clinch nuts (see figure 3-14) should be of steel, cadmium plated and chromate dipped. Clinch nuts must be supported at the shoulder during installation or the top surface will be deformed resulting in close-in of the elastic collar. Distortion damage of the top surface leads to the use of extremely high screw installation torque, which can result in failure of the nut by twisting it from the sheet metal structure. Inspection after attachment should include an examination of the top surface of the nut for possible installation damage.

B All-Metal Lock Nuts

There are numerous types and forms of all-metal lock nuts. They are suitable for use at temperatures up to 900°F, depending on material and finish.

Some all-metal lock nuts obtain their locking action by the gripping action of a deformed (constricted) section of the nut (figure 3-17); others lock by interference fit of the nut by distorting the threaded section (figures 3-15 and 3-16).

The nuts illustrated in figures 3-15, 3-16 and 3-17 are called prevailing torque lock nuts because they provide a heavy drag or lock on the threads of the screw or bolt whether or not the parts being fastened are drawn up tight.

Another type of all metal lock nut is made by assembling a lock washer and nut into a single unit (figure 3-18). Its locking action depends on, and sustains, tension in the screw or bolt shank. This type of lock nut should be used in applications where external tooth lock washers are satisfactory. (See 3.6.2, D1)




Figure 3-15. Two Lug Anchor
Rivet Type All-Metal
Lock Nut

Figure 3-16. Right Angle
Rivet Type All-Metal
Floating Lock Nut

C Lug Under Lock Nut

If a lug is used under a prevailing torque lock nut, the lug itself shall be checked for tightness.



SLOTTED-
DEFORMED END

Figure 3-17. Slotted Deformed
End Lock Nut



KEPS
(LOCKWASHER-NUT
ASSEMBLY)

Figure 3-18. Keps Lock Washer-
Nut Assembly

3.5 RIVETS AND EYELETS

3.5.1 General

Rivets and eyelets can achieve a desirable fastening means at a favorable in-place assembled cost. Riveted assemblies normally are considered to be of a permanent nature. However, with moderate skill and standard tools, rivets and eyelets can be removed and parts reworked. An electrical connection shall not depend on riveting.

Staking, rolling, etc. are dependent, to a large degree, on the assembly operator's skill, knowledge, and interest. He must have the proper tools at his disposal and understand their use. Rivets and eyelets must be of the proper diameter, length, and type to satisfy the assembly thickness, hole sizes, and all the tolerances associated with the assembly. Rivets and eyelets must be fully seated, properly backed, and perpendicular to the assembly and retained in this attitude while they are upset.

3.5.2 Rivet Types

A Solid Rivets



Figure 3-19. Solid Rivets

Standard head types include oval and 100° included angle flathead rivets.

A solid rivet normally will increase in body diameter and fill a hole as it is upset in an assembly, thereby giving a fastening which is rigid in three planes.

A flathead rivet should be countersunk flush or slightly below the surface. Slight protrusion above the surface is permissible sometimes if interference with another part does not occur or appearance is not degraded (front panels).

3.5.2. A (Cont)


Care must be exercised in backing a flathead rivet which may be recessed so it may be properly seated during riveting.

Oval-head rivets must be backed by a proper die set if the head shape is to be retained during assembly. Also, through the use of a die set and accurately controlled rivet projection length, an oval or similar head may be made on the upset end of the rivet. However, a simple mushrooming of the projected rivet usually is satisfactory and is the preferred, most economical assembly method.

B Semitubular Rivets

Figure 3-20. Semitubular Rivet

Semitubular rivets are low in cost and may be assembled with greater ease and less upsetting pressure than solid types. The length of a semitubular rivet, due to the depth of the hole for roll-over, is extremely important and may be a critical factor in achieving a satisfactory assembly. Figure 3-21 charts the desirable clinch allowances for semitubular rivets. The depth of the hole in the rivet shank is an important consideration when selecting a rivet. The body of the rivet normally does not increase in diameter during assembly, but must rely on friction between the various parts of the assembly to hold the assembled position. Therefore, a semitubular rivet does not produce as much retaining strength as a solid rivet.



SHANK DIAMETER	.060	.065	.088	.098	$\frac{1}{8}$	$\frac{9}{64}$	$\frac{5}{32}$	$\frac{3}{16}$
DIA OF HOLE	.067	.070	.093	.104	.128	.152	.165	.196
* CLINCH ALLOWANCE	.032	.032	.045	.055	.062	.062	.062	.062

*Length of the solid portion of the rivet always must be less than the total thickness of materials being fastened when tolerances are at the worst extremes, even if clinch allowances shown cannot be met.

Figure 3-21. Desired Clinch Allowances

3.5.2.C Eyelets



Figure 3-22. Roll-Flanged Eyelet

An eyelet may be used in an assembly in a manner similar to a tubular rivet but at reduced strength. The large range of diameters and other dimensions give eyelets a high degree of versatility. An eyelet usually is made of thin metal and may be rolled into position with moderate pressure. The hole in the eyelet is often its greatest asset and may be used to advantage in an assembly.

3.5.3 Material and Workmanship

The material and finish of a rivet or eyelet must be compatible with the materials it contacts in an assembly. Normally the rivet, as assembled, should be harder than the material it is fastening.

Rivets and eyelets shall be tight. The staking or rolling shall be uniform and reflect high quality of workmanship. Rivet heads which are not fully seated shall be rejected.



Figure 3-23. Rolled Semitubular Rivet

Cracks or splits in the rolled or flared portion of eyelets shall be permissible with the following limits:

- (1) No single part may have more than one crack or split per end.
- (2) No crack or split shall extend into the shank.

Excessive splitting usually indicates defective tooling or material.

3.6 WASHERS

3.6.1 Flat Washers

Flat washers or dished flat-rim lock washers must be used over slotted holes or holes so large that they do not present sufficient bearing surface for the fastening or part adjacent to them. A lock washer, lock nut, or liquid staking should be used as the locking device when a flat washer is used.

3.6.1 (Cont)

Flat washers or dished flat-rim lock washers must be used adjacent to paint or non-metallic parts, if it is necessary that the finish under and/or around the fastening remain undamaged.

A series of flat washers should not be used in place of a spacer of the necessary length. (This statement does not apply to thin precision shims.)


3.6.2 Lock WashersA Functions and Definitions

Spring lock washers or "split locks" have two functions:

- (1) Spring take-up devices to compensate for developed looseness and the loss of tension between parts of an assembly.
- (2) Hardened thrust bearings to facilitate assembly and disassembly of bolted fastenings by decreasing the frictional resistance between the bolted surface and the bearing face of the bolt head or nut.


Toothed lock washers serve to lock fasteners, such as screws and nuts, to the parts of an assembly; they increase the friction between the fasteners and the assembly.

A dished flat-rim lock washer is an internal tooth lock washer with a conical body and a flat rim. The conical body contributes spring loading to lock the teeth to the mating fastener and helps maintain tension in the screw shank. The washer shall be placed so the flat rim goes against a flat surface.




SPLIT LOCK
WASHER

Figure 3-24




EXTERNAL TOOTH
LOCK WASHER

Figure 3-25



INTERNAL TOOTH
LOCK WASHER

Figure 3-26



DISHED FLAT-RIM
LOCK WASHER

Figure 3-27

Lock washers are unnecessary on fastenings which secure parts that have inherent resiliency that will provide a locking force.

B Lock Washer Location

The proper location of a lock washer on a threaded fastener is:

- (1) Under the head of a screw driven into a tapped hole.
- (2) Under the machine screw nut on a through screw.

3.6.2.C Materials and Finishes

Type 302 stainless steel is the preferred material for split lock washers in general structural use. Silicon bronze (Everdur) is the preferred nonferrous material for split lock washers. Type 410 stainless steel is preferred for toothed washers in general fastening use. Phosphor bronze is the preferred nonferrous material for toothed washers.

3.6.2.D Split Lock Washers

1. Split lock washers generally should be used in mounting items which use a number 8 or larger screw. Split lock washers allow more tension to be developed in the screw shank with a given amount of applied torque. Since heavy components are secured almost always with number 8 or larger screws, the thrust-bearing effect of split lock washers contributes to adequate tightening of these larger fastenings. The torque developed by assembly operators using hand drivers on large screws usually does not develop enough tension in the screw shank to over-stress the screw material. A possible exception to the use of split lock washers for a number 8 or larger screw is when power driving is being utilized. (A toothed lock washer helps to cause the power driver to brake to a halt when a certain torque is developed, thus not over-stressing the screw shank.)

2. Split lock washers may be used adjacent to flat washers, but a dished flat-rim lock washer would take the place of both and be preferred where applicable.

3. Split lock washers may be used adjacent to internal tooth solder lugs; however, external tooth washers are preferred for such electrical connections where the biting action of the teeth contributes to better electrical bonding.

E Toothed Lock Washers

1. External tooth lock washers generally should be used with number 6 or smaller screws. External tooth lock washers shall not be used adjacent to painted surfaces or other finishes the function of which might be harmed by the biting action of the teeth. External tooth lock washers shall not be used where the biting action of the teeth could interfere with wire insulation, or against a part which does not have sufficient surface area for the teeth to seat properly (for example, small pattern nuts and fillister head screws). External tooth lock washers may be used with flat washers, but a dished flat-rim lock washer is preferred and often makes the use of flat washers unnecessary. The biting action of the teeth of external tooth lock washers improves electrical connections and should be utilized in applications such as terminal boards and ground connections. An external tooth washer shall not be used adjacent to the base of a molded insulated standoff (Winchester standoff).

2. Internal tooth lock washers generally should be used in the mounting of single mounting hole components which have a large OD and are secured by a narrow rim chamfered nut. A single mounting hole component can utilize a closer hole clearance, thus affording sufficient surface for the internal tooth washer to seat. Fine toothed, narrow rim washers are preferred, and should generally be placed adjacent to the back side of the panel. An internal tooth solder lug requires the use of an additional locking device because thin phosphor bronze material lacks sufficient spring action for adequate self-locking. An external tooth lock washer is preferred for use against solder lugs.

3. Dished flat-rim lock washers are recommended for use over slotted holes and thermosetting plastic materials. The conical body provides spring loading for locking teeth to protect the unit from loosening due to vibration, or dimensional changes through temperature variation. Split lock washers and external tooth or conventional internal tooth lock washers shall not be used against relatively soft compressible material or brittle material.

3.6.3 Compressible Washers

Compressible washers fall into several categories such as insulating or conducting (both thermal and electrical), ductile and/or resilient, and porous or nonporous. Resilient washers should be used to mount brittle parts (ceramic, etc.) to minimize breakage. Ductile heat-conducting washers are often used to mount components requiring maximum heat transfer.

Resilient nonporous washers are used to mount components where watertightness is involved. Other applications for washers which may be compressible are reducing the effect of shock and vibration, lubrication (felt washers), insulation including isolation of dissimilar metals to prevent galvanic corrosion, and sound deadening. Acetate washers should not be used above 70°C.

GENERAL PROPERTIES OF COMMON COMPRESSIBLE WASHER MATERIALS

	DUCTILE	RESILIENT	INSULATING		CONDUCTING		POROUS	NONPOROUS
			THERMAL	ELEC	THERMAL	ELEC		
Rubber (Dense)		X	X	X				X
Rubber (Cellular)		X	X	X			X	
Cork & Synthetic Rubber Composition		X	X	X			X	
Felt		X	X				X	
Plastic (Thermosetting) (1)		Slightly	X	X				X
Plastic (Thermoplastic) (2)	X	X	X	X				X
Soft Metals (3)	X				X	X		X
Mica (Laminated)		Slightly		X	Slightly		Slightly	
Metal Spring Washers		X			X	X		X
(1) Phenolic, Epoxy, Melamine, etc. (2) Nylon, Teflon, Vinyl, and other cold-flow plastics. (3) Annealed Copper, Lead, Indium, etc.								

3.7 MISCELLANEOUS FASTENING AND LOCKING PROVISIONS

3.7.1 Liquid Staking

Liquid staking can be used to prevent loosening of threaded parts, when it is impractical to use mechanical locking devices. Liquid staking differs from adhesives in that it increases the frictional drag between mating surfaces in addition to an initial adhesive bond. When liquid staking material is used for locking on mechanical devices, extreme care must be used to prevent its contaminating electrical connections or interfering with moving parts. Special electrical and/or mechanical tests may be necessary after assembly to detect such defects. Screws or studs threaded into phenolic or other thermosetting plastic must be secured by a suitable liquid staking compound.

A Glyptal

Blue Glyptal (GE 7526, Collins part no. 005-0133-00) is the most commonly used liquid staking material. It is recommended for general use in securing setscrews and nonmetallic screws, by applying a small amount to the threads of the screw before assembly. Care must be taken to leave the screwhead slot or socket accessible (free of Glyptal). Glyptal presents an undesirable appearance when used in excessive amounts, and can even cause objectionable adhesion between adjacent surfaces. Fastenings secured by Glyptal normally can be removed; however, if these fastenings are reassembled, Glyptal should be reapplied. Red Glyptal is not to be used as liquid staking material. It is primarily intended as a finish or protective coating.

B Loctite

Loctite is available in several grades to allow variations in removal torque depending upon the requirements, screw material, etc. Holding power exceeding 100% can be obtained; that is, a screw can fracture before it will break loose for removal. Loctite differs from Glyptal in that it will not harden in air. Contact with most metal surfaces causes hardening but a special hardening agent is required for cadmium, zinc, or nonmetals. Hardened Loctite is virtually insoluble; therefore, selection of the proper grade for the application is paramount. Commonly used grades are distinguished by color. Colorless grades shall not be used because they impose an inspection problem. Loctite must not be used on paint and thermoplastic materials.

C EC 847 (Collins Part No. 005-9042-00)

EC 847 can be used for liquid staking. Slight thinning with methyl ethyl ketone makes it easier to apply.

3.7.2 Solder Staking

Solder may be used as a staking compound where an electrical connection is made and the locking requirements can be met in no other way.

3.7.3 Self-Locking Screws

Screws with plastic pellets (usually nylon) provide adequate locking in applications where lock nuts, lock washers, or liquid staking are not desirable. Such screws generally are called by a trade name, "Nylok." Locking action occurs through the compressible forces resulting from driving the screw with its projecting pellet into a mating nut or tapped part. The amount of pellet projection above the screw

thread crests may be either the manufacturer's standard or special depending on the degree of locking required in a specific application. Proper usage of Nylok screws requires the presence of an entrance chamfer in the tapped hole of the mating part or nut to keep the pellet from being sheared off as it enters the first thread.

3.7.4 Sheet Spring Nuts

Sheet spring nuts provide engagement of only one usable thread and therefore are not preferred in structural applications where breakage of the nut would allow separation of the assembled parts. Locking action occurs when a screw is tightened securely into a sheet spring nut due to the deflection in the spring members comprising the thread form. These nuts function best when used with hardened screws such as thread-forming screws.

3.7.5 General Locking Requirement

In general, every machine screw assembly must incorporate some locking device or feature to resist loosening. If the fastener is covered with an approved post-coating material, additional locking is generally not required.

3.7.6 Fastening of Resilient or High Expansion Materials

In general, high expansion (usually plastics) and resilient material should be fastened with hardware that is liquid staked or secured with a prevailing torque lock-nut. Flat washers to distribute load are advantageous in many applications. Threaded metal inserts molded into plastic or rubber parts are often desirable. Shouldered screws or metal sleeves can also be used to allow positive mounting of this type part.

The use of resilient parts as structural members is not considered good practice unless the resilience is specifically required, as in flexible couplers and shockmounts.

3.7.7 Electrical Connections

A nut should be used between a nonmetallic material and an electrical connection in a threaded assembly.




Figure 3-28. Nut Added Below Lug

3.8 ADHESIVE BONDING

3.8.1 Structural Adhesive Bonding

Structural adhesive bonding is sometimes preferable to mechanical fastening methods. The use of adhesives in structural applications is most beneficial when long production runs are anticipated. Working out the proper cleaning procedure, application technique, cure cycle, and inspection method usually requires more time and effort than may be justified for short run production. Destructive inspection methods sometimes are necessary and should be specified on the assembly drawing after the Development Engineer and Quality representatives concur on the test and frequency of test.

Structural bonding requires strict adherence to all of the steps specified for the application. It is mandatory that quality be assured at each step of assembly rather than to rely on postassembly inspection. Interim changes in specified processes should be made only after agreement between Industrial Engineer, Development Engineer, Materials Engineer, and Quality representative.

3.8.2 Surface Preparation for Structural Bonding

Surface preparation, including cleaning, rinsing, and drying operations, must be carried out meticulously as specified on drawings or referenced process specifications.

Bonding must be completed as soon as possible after surfaces are prepared. If more than 4 hours will elapse between cleaning and bonding operations, the clean surfaces must be protected suitably against contamination. (Wrapping in plastic film, applying strippable coating, or other suitable storage techniques should be employed.)

3.8.3 Adhesive Bonding, Elastomeric

The bonding of gaskets and other flexible parts to metal with rubber base adhesives usually does not require as stringent control of the process as does the use of structural adhesives. The primary considerations are:

1. The proper adhesive.
2. Clean surfaces.
3. Application to both surfaces when possible.
4. Allowing enough drying time for good "tackiness" to develop before joining parts.

3.9 STRAY HARDWARE

In assembly, care shall be taken to prevent washers, nuts, screws, rivets or any other material from accidentally falling into an equipment. If a small part is accidentally dropped into the equipment, it should be removed at once, before it is forgotten or covered by other parts, to prevent a subsequent possible short or mechanical malfunction.

mechanical and electromechanical requirements

4.1 GENERAL REQUIREMENTS

4.1.1 Minimum Clearance of Moving Parts.

- A Where moving part clearance is required, the minimum clearance shall be not less than .015 inch with the parts in their worst condition unless specifically required by design. Parts must be aligned properly throughout the entire cycle. The proper clearance shall be maintained to preclude interference of parts through wear and stress of operating conditions.
- B All parts or assemblies with movable terminals such as tube sockets and connectors with floating pins, where electrical potential exists, shall be checked for minimum clearance in their worst positions and after soldering. Minimum clearance of .030 inch shall be maintained unless high circuit potentials require more clearance, in which case the drawings shall specify the increased clearance.
- C All parts which, in operation of the equipment, move from their normal position shall be free from binding or other defects which will keep them from functioning properly throughout their entire operation cycle.

4.1.2 Cracks, Chips, or Crazing in Glass or Ceramic Seals, Insulators, Terminal Boards, and Connectors.

A Definitions

Crack - A through break in the glass, ceramic, or board material with or without separation occurring.

Craze (Crazing) - Small breaks or checks existing only on the surface of the insulating material.

Working surface - The entire surface of the insulating material from which the terminal, pin, or lead extends. (See figure 4-1.)

Chip or flake - The area on a working surface from which a small fragment has been dislodged.

- B Cracks will not be allowed in the working surface of a sealed component, or other glass or ceramic seal.
- C Chipping and crazing around a sealed terminal (or on other glass or ceramic insulators) shall not extend more than 1/2 of the way to the nearest terminal (or other conducting surface). The total crazed or chipped distance between such terminals shall not exceed 1/2 the minimum working surface distance between the terminals. Excessive chips and crazing around terminals can cause leakage or voltage breakdown, especially under extreme environmental conditions.




Figure 4-1. Cracks, Chips and Crazing around Sealed Terminals

- 4.1.2.D A sealed device shall not have a defect that destroys the intended seal, even though the defects are within limits of C above.
- E Cracks, crazes, or chips on terminal boards and unsealed connectors shall be within the limits of 4.1.2.C and shall not extend more than $1/2$ the distance:
- (a) from a terminal to the edge of the insulating material,
 - (b) from a terminal to a mounting hole,
 - (c) from a mounting hole to an edge of the board.

Defects above mentioned can seriously affect the strength of a terminal board or connector under service conditions. Note: Refer to section III, paragraph 3.6.3 for the correct method of mounting terminal boards to prevent cracking.




Figure 4-2. Unacceptable Cracks in a Terminal Board

- F The working surfaces of sealed devices or terminal boards shall be free of conducting material such as splatters of solder. They also shall be free of nonconducting material such as rosin that could entrap moisture and thereby cause breakdown during some environmental conditions.

4.1.3 Burrs and Sharp Edges

A Definition

For the purposes of this section a burr is defined as the rough irregular lip or edge of material formed by machining, grinding, shearing, or accidental gouging.

B Drawings shall specify critical areas which must be burr free. However all mechanical parts shall be free of burrs and sharp edges in locations where they would contribute to the following:

1. Abrasions of leads, wires, and cables.
2. Increased possibility of arcing in a high voltage application.
3. Personal injury.
4. Danger of burrs breaking loose and causing shorts, gear malfunction, etc.
5. Poor appearance.
6. Mechanical interference. For example, burrs on mating surfaces of a loaded gear may cause a locking condition.

4.1.4 Handling, Fitting, and Assembling

- A Parts and assemblies shall be protected adequately during assembly, handling, and storage to prevent damage to dimension, finish, or function. Rough or careless handling shall not be tolerated.
- B Severe distortion or bending shall not be used to achieve alignment or fit of parts since it can reflect poor workmanship or cause interchangeability problems or residual stress.
- C Care shall be used during the assembly of mechanical parts, especially staking, riveting, or pressing, that none of the critical dimensions of the associated parts are changed or distorted beyond tolerance. The term critical dimension is used here to denote those dimensions that would affect the subsequent use, fit or reliability of the part or assembly.

4.2 GEARS

4.2.1 Definitions

Alignment - The lateral (width of tooth) engagement of mating gear teeth.




Figure 4-3. Gear Alignment

4.2.1 (Cont)

Loading - The use of spring device to eliminate backlash.

Mesh - Depth of tooth engagement of mating gear teeth. See figure 4-4.




Figure 4-4. Gear Mesh

Toothiness - The irregular or rough feel of a gear train due to lack of clearance between teeth or mismatch of engaging tooth contours.

Backlash - The play or lost motion between two or more gears caused by the clearance between mating gear teeth.

Runout - The wobble evident during the rotation of a gear.

4.2.2 Gear Alignment

A Spur Gears

The width of tooth contact between mating gears shall be not less than 75% of the tooth width of the thinner gear, except that a gear thinner than .030 inch must have full width of tooth contact with a thicker gear. These requirements apply to the worst position in the gear's rotation, including allowable end play and runout and are necessary to assure a satisfactory transfer of power and proper gear life.

B Bevel Gears

Bevel gear alignment requirements are the same as for spur gears except that at least 90% of the face width must engage.




Figure 4-5. Alignment Limits for Spur Gears and for Bevel Gears

4.2.3 Gear Lubrication

Drawings of assemblies that include moving parts shall specify the type and quantity of lubrication. All gear trains shall be lubricated as called out on drawings. Where absence of lubrication on a bearing surface is intended, this shall be so specified. See also paragraph 4.9.

4.2.4 Gear Mesh

- A The contacting action of the gear teeth shall be smooth and free from any interference due to improper tooth contour or lack of clearance. The action shall be uniform throughout a complete revolution of the larger gear and free of excessive irregular movements, or "toothy" effect. (Note - some toothiness is normal in a loaded gear.) These requirements are to eliminate unnecessary noise in operation, to reduce power required, to provide for smooth operation of dials and indicators, and to assure that gears can be reset accurately.

B Amount of Gear Mesh

In most applications, the degree or depth of gear mesh will be governed by specific design requirements; however, there shall be a minimum of 60% of full depth tooth engagement to assure adequate life and reliability of equipment.

C Backlash

Backlash will be cause for rejection when it results in excessive positioning inaccuracies or poor repeatability of function in either direction of gear train rotation. Backlash should be checked throughout the entire cycle of gear operation.

4.2.5 Gear Loading

- A Loaded gears should be checked for proper amount of load as specified on assembly drawings. Excessive loading will cause accelerated wear and possible early failure. In no case shall a loading spring be fully compressed or stressed to the point of mechanical bind. Too little loading will result in backlash and inaccuracy of precision gear trains. A loaded gear shall not be meshed with more than one solid faced gear as such condition will nullify the effect of the loaded gear.
- B Binding in a loaded gear assembly caused by lack of hub clearance, lack of clearance between sections, or burrs on adjacent gear teeth shall not be permitted as it may cause the loading to be ineffective.
- C Direction of loading in a gear assembly shall be consistent with the design of the loading spring and call-out on the assembly drawing.
- D Any separation of the sections of a loaded gear to the extent that the loading spring could become disengaged shall be cause for rejection. Maximum unintentional separation between sections of a loaded gear shall be not more than 1/2 the face width of the thinner section as observed in normal rotation.




Figure 4-6. Separation of Sections of Loaded Gears

4.2.6 Clamping Adjustable Gears

On gears utilizing split hubs for the purpose of adjustment in a gear train, there are two common methods employed to tighten them to shafts: (1) a collar with two or more set screws, or (2) a split clamp with one screw. In all cases where an appreciable amount of torque is involved, method (2) should be employed. The screw through the clamp must be lubricated to prevent a false indication of tightness. It is preferable to specify a tightening torque on all such clamps. After tightening, the "lips" of the clamp must not be touching. The set screws or clamp screws should be accessible at the point of normal adjustment. Where method (1) is employed, care should be used that the screws do not engage the slot of the split hub.

4.3 DETENTS

4.3.1 Detent Action

Where detent action is involved, the detent shall snap into position with sufficient force so that it leaves no doubt as to whether or not the selected position has been reached. Action shall be checked in both directions. The combination of knob setting, panel markings and detent pitch should leave no doubt as to the selected position. Torque requirements, when considered critical, will be specified on assembly drawings.

4.3.2 Binding or Galling

Travel between selected positions shall be generally smooth and free from galling or excessive friction.

4.4 BEARINGS

4.4.1 General

A Proper Seating

Sleeve bearings should seat completely against the panel to which they are assembled. A slight chamfer of the bearing is acceptable providing the bearing is completely seated.

4.4.1A (Cont)

- a- Acceptable The bearing is completely seated and square with the plate.
- b- Acceptable The bearing flange is chamfered, but the bearing is completely seated and square with the plate.



ACCEPTABLE

Figure 4-7. Sleeve Bearings, Properly Seated

- c- Not Acceptable The bearing is not square with the plate.
- d- Not Acceptable The bearing is not completely seated.



NOT ACCEPTABLE

Figure 4-8. Bearings not Properly Seated

Sleeve bearings shall be installed with enough press so that they cannot be moved or removed by finger pressure.

B Bearings shall not exhibit objectionable roughness, noise, or excessive torque.

C Handling and Storage

Special care shall be exercised in the handling and storage of all bearings to prevent damage or contamination. Prior to assembly, lubricated bearings should be stored in the manufacturer's original containers.

Subassemblies containing exposed lubricated bearings shall be handled and/or packaged in a manner to prevent contamination of the bearings or absorption of the lubricant.

4.4.2 Ball Bearings




A Assembly

A major force should never be applied through the ball complement when mounting ball bearings (figure 4-9).

The proper procedure is:

1. When installing a bearing on a shaft, apply pressure to the inner race (figure 4-10).
2. When installing a bearing in a housing, apply pressure to the outer race, (figure 4-11).

Applying assembly force through the ball complement may cause overstressing (Brinelling) of the bearing material and subsequent malfunction or early failure.



NOT ACCEPTABLE

Figure 4-9. Incorrect Method of Mounting Bearing

Figure 4-10. Correct Method of Mounting Bearing on a Shaft

Figure 4-11. Correct Method of Mounting Bearing in a Housing

B Removal of Ball Bearings

When excessive force is applied through the ball complement in removing a bearing, the bearing shall not be reused without reinspection.

C Thrust Loading

Ball bearings with filling notches in the races shall not be used where the thrust load is sufficient to cause bearing balls to hit notches during bearing rotation. Thrust loading this type of ball bearing may cause objectionable noise, rough running, and early failure. See figure 4-12.

4.4.2 (Cont)




Figure 4-12. Improper Application of Ball Bearing with Filling Notches

D Shields and Seals

Ball bearings which may be subjected to excessive dust, moisture, or similar detrimental environments should be shielded or sealed to prevent contamination of the bearings and the lubricant.





Figure 4-13. Typical Ball Bearing Constructions

E Retaining Methods


Ball bearings should be restricted from excessive axial movement, both on the shaft and in the housing bore. The device used to retain a ball bearing must not contact both inner and outer race, nor inner race and dirt shield of the bearings. See figures 4-14 and 4-15.

4.4.2E (Cont)



ACCEPTABLE

Figure 4-14. Method of Retaining Ball Bearing in Housing



NOT ACCEPTABLE

Figure 4-15. Incorrect Method for Retention of Ball Bearing on Shaft

Miniature ball bearings usually are assembled with a slight clearance fit and therefore must be suitably retained.

Staking, spinning, bonding, and heavy press fit are not recommended means of retaining miniature ball bearings because of the possibility of damaging the bearing.

F Axial Play

Unless purposely preloaded, single row, radial ball bearings must have a perceptible amount of axial play after assembly. This play will ensure that the bearing is not overloaded.

G Rotation

Perceptible continuous rotation of outer race in housing or of shaft in inner race is not permitted. Intermittent creep is acceptable provided it is not caused by a defective bearing, and will not affect the intended function of the device.

4.4.3 Porous Self-Lubricating Bearings

A Sizing

Porous self-lubricating (Oilite) bearings may be sized by one of the following methods without destroying porosity.

1. These bearings may be reamed by taking a light, fast cut with a very sharp cutting tool using no cutting oil. Reaming, however, is not recommended for volume production unless carbide cutting edges are employed. A dull cutting tool will smear the bearing surface closing some of the pores and reducing the self-lubricating qualities of the bearing.

4.4.3A (Cont)

2. For volume production, a button burnisher (see figure 4-16 below) is recommended.



Figure 4-16. Button Burnisher for Sizing Oilite Bearings

4.4.4 Plastic Sleeve Bearings

Plastic sleeve bearings are not recommended for high speeds or extreme environmental conditions because of poor dissipation of heat generated by high speeds and dimensional changes caused by temperature and humidity conditions. When doubt exists relative to use of plastic bearings, contact the Materials Engineering Group.

4.5 TUNING SLUG RACKS

4.5.1 Alignment with Cam

Slug table rollers should ride on the cam and turn freely throughout the entire travel. A minimum of 75% of the cam thickness shall make contact with the roller when they are in their worst relative position including runout and end play. In cases where the table rides directly on the cam, with no roller, the same requirement for engagement shall apply.

4.5.2 Travel

Both ends of a slug table should start to rise at the same time and retain an equal amount of rise throughout the cycle. Movement shall be smooth with no evidence of sticking or binding.

4.5.3 Slug Positioning

Slugs shall not bind inside the sleeve. Care should be exercised in the use of varnish, liquid staking, and other assembly materials that may flow into the bore of a coil form and interfere with the intended action.

4.5.4 Slug Stud Retainers

Slug stud retaining devices must have sufficient tension to prevent movement when the equipment is subjected to vibration specified for the equipment. The retaining device must be installed in such a way that it will remain in place during, and yet not hinder adjustment. Liquid staking of slug adjustments shall not be permitted.

4.6 SWITCHES AND RELAYS

4.6.1 General

- A Switch or relay contact supporting parts shall not be subjected to any stress which could be detrimental to free action or alignment. On a long rotary switch stack-up, some means shall be employed to ensure proper rigidity and radial alignment of all sections throughout the entire operation cycle.

B Contamination of Contacts

All contacts must be free of solder or other foreign material. Care shall be exercised during soldering and in the use of liquid staking, solder flux, antifungus varnish, or other materials that could flow or fume into the contact area under heat or other environmental conditions. Note: Contamination of contacts is recognized as one of the greatest causes of relay and switch failure.

C Pitting

Switch or relay contacts which are burned to the extent that they have become pitted are not acceptable. These pits can trap dirt and foreign material, causing contact failure.

D Tight Leads

Switch or relay contacts shall not be moved from their intended position due to stress from tight or stiff leads or improper installation, etc.

E Cleaning

When cleaning is necessary, switch or relay contacts must be cleaned only with burnishing tools or liquids made for this purpose. Caution: Heavy burnishing can damage contacts.

F Contact Arm Damage

Contact arms must be free of kinks or nicks which may cause stress concentrations and subsequent breakage or malfunction.

G Contact Alignment

Switch or relay contacts shall align so that in their worst relative position more than 50% of the smaller contact diameter is engaged. See illustrations below for low current applications. See also paragraph 4.6.2.D regarding disc-type rotary switch contacts.




Figure 4-17. Contact Alignment for Low Current Applications

Note: In high current applications, flat button contacts must have 75% of area contacting and shall be parallel to each other.

4.6.2 Switches

A Binding

Switches shall be free from binding or other defects which may keep them from functioning properly throughout the entire operation cycle. Torque requirements, where critical, shall be specified on the drawing or specification.

B Alignment

The locating tabs of rotary switches shall be placed in the holes provided.

C Soldering

Where a solder connection is made on the terminals of a wafer switch, the solder must not flow beyond the center of the eyelet that secures the switch contact, as this may interfere with the proper spring action. See figure 4-18.




Figure 4-18. Wafer Switch Soldering and Contact Areas

4.6.2.D Rotary Switch Contact

The rotor blade of rotary disc-type switches shall engage more than 50% of the clip contact area in the worst detented position. This will ensure that the dimple in the contact clip rests on the blade and also gives some allowance for wear. See figure 4-18.

E Lubrication

Rotary switches shall not be lubricated except as specified on the assembly drawing.

F Wafer Designation

In a wafer switch, the wafer next to the knob or driven end is designated A.

4.6.3 Relays

A Adjustment of Relay and Leaf-Type Switch Contacts

Properly adjusted relay contacts will have a noticeable amount of follow-through action in the closed position. This is necessary to ensure sufficient contact pressure and wiping action for self-cleaning. There may be certain relay designs where it is desirable to minimize wiping action. If doubt relative to wiping action arises, contact the Component Application Engineer.




Figure 4-19. Exaggerated Wiping Action of Relay Contacts

B Contact Clearance

Open contacts must have sufficient clearance to prevent closure during vibration as specified for the equipment.

C Contact Adjustment

Normally, relay contacts should not need adjustment. If necessary, a proper bending tool shall be used which will not kink or nick the contact arm. (See 4.6.1.F.)

D Sealed Relays

Many sealed relays use solder terminals for mechanical support of contacts and contact arms; see figure 4-20. Terminals on sealed relays, therefore, shall not be bent or twisted as this may cause a break in a hermetic seal, internal breakage or an electrical short within the relay. See also general requirements for sealed electromechanical devices (4.1.2).




Figure 4-20. Construction of a Sealed Relay

4.7 RETAINING RINGS

4.7.1 Seating

As intended by the design of the ring, an external ring must be seated in its groove throughout its inner periphery, and an internal ring must be seated throughout its outer periphery. An "E" ring should be seated in the groove at all three points.

4.7.2 Installation

Only the chamfered (smooth) side of a retaining ring, bowed or flat, shall be installed to run against a bearing surface. The burred side (if any) could score the bearing surface and cause metal particles to drop into the mechanism. The burred side of a bowed retaining ring is the concave side.

4.7.3 Distortion

Visible distortion of a retaining ring shall not be permitted. Distortion of the retaining ring is likely to occur during assembly or disassembly. Special plier or assembly tools shall be used as recommended by the manufacturer.

4.8 PINNED ASSEMBLIES

4.8.1 Engagement with Hub

Where a hub is attached to a shaft by means of a pin, each end of the pin must engage at least 50% of the wall thickness of the hub. If the hub wall thickness is 1/16 inch or less, the engagement must be no less than 1/32 inch, or the full wall thickness on hubs of 1/32 inch or less wall thickness. See figure 4-21.

4.8.2 Protrusion from Hub

Protruding ends of pins in shaft assemblies must not interfere with other parts and must also meet clearance requirement of 4.1.1.A. This does not apply to pins whose function is to serve as a stop or actuator.




Figure 4-21. Pin Engagement and Clearance Checks

4.8.3 Tightness of Pins

Unless clearance is intended by design, the pin must be tight in both parts of the pinned assembly, as looseness can cause early failure due to excessive wear. Peening or distorting the hole or bending or flattening the pin to achieve a tight fit is not permitted.

4.8.4 Distortion by Pinning

In a pinning operation, the associated parts shall not be distorted beyond the tolerances of the individual parts where the distortion will affect the fit in further assembly, or the reliability of the end equipment.




Figure 4-22. Distortion Caused by Improper Pinning

4.9 LUBRICATION REQUIREMENTS

4.9.1 General

- A All assembly drawings shall specify lubrication requirements or absence of such requirements on wear surfaces.
- B Electronic equipments shall be designed to use as few types of lubricants as possible.

4.9.2 Absence of Requirements

When obvious wear points exist and no specification for lubrication appears on the drawing or specification, Development Engineering must be contacted so that proper lubrication or omission of lubrication will be specified.

4.9.3 Lubrication Instruction Plates

Where lubrication instruction plates are specified, they shall indicate lubrication intervals, specifications for lubricant, amount to be applied, and any necessary precaution.

4.9.4 Application, Quantity and Protection

All lubrication shall be applied in a neat, consistent manner. The proper amount should be used to lubricate only the actual friction surfaces. Excessive quantities of lubricant hanging on gear trains and assemblies will not be acceptable. If the lubricant is applied with a brush, care must be used to prevent a broken bristle from remaining on such parts as gear trains. A single bristle could cause a serious malfunction. All lubricants shall be kept in closed containers to protect them from contamination. The containers (not merely the cover) shall be marked as to the type of lubricant. Special caution shall be used to avoid adding to or mixing lubricants without knowing whether they are compatible. When there is a question, old lubricant shall be cleaned out and the part relubricated. This requirement shall pertain to the lubricants in containers as well as in the bearings of equipment. Lubricated bearings should be protected per paragraph 4.4.1.C.

4.10 APPEARANCE AND CLEANLINESS

4.10.1 General Requirements

Appearance items (those which could not reduce the usability of the product) are not to be considered defects if they require concentrated study to detect. Plated surfaces shall show no evidence of chipped, peeled, or blistered plating or other indications of lack of adhesion. There shall be no evidence of bleeding or corrosion due to entrapment of plating or cleaning solution. Other surface coatings shall be free of severe scratches, nicks, gouges, or other abrasions. Extreme mismatch of finishes, unless indicated in the design, shall not be allowed on panels, covers and racks. All finishes shall withstand normal handling in service without being marred. Screws or other fastening devices may contain minor tool marks but must not present an obviously damaged appearance. Refer to paragraph 3.1.7.

4.10.2 External Appearance

Front panels or sides of equipment, normally in view, must be free of blisters, scratches, dents, fractures or other unsightly defects when viewing from any angle at a distance of eighteen inches with normal vision. Portions of equipment subject to frequent scrutiny during operation or items added solely for styling and/or appearance will require tighter control of the finish, alignment, and general workmanship. Rear panels, sides not normally exposed, bottom plates, or other areas of similar exposure may have surface defects provided they do not expose bare metal. Where the design permits, panels shall present a balanced appearance, with alignment of controls and indicators uniform.

4.10.3 Internal Appearance

Severe removal of the protective finish on a part or assembly (not affecting the product usability) shall be considered a defect. However, if such items receive a sealing application, such as potting, foaming, or post-coating as part of the normal assembly process, these items may be considered acceptable.

4.10.4 Loose Foreign Material

All equipments shall be clean and free of all loose material (or material which could become loose during equipment usage) which could cause potential shorts, mechanical failure, or unsightly appearance. These include: stray hardware, solder splatters, wire strands, insulation clippings, filings, slivers, chips, and excess solder flux.

4.11 MARKINGS

4.11.1 General

Some of the methods of marking are:

Silk Screen	Etching
Rubber Stamp	Engraving
Impression Stamping	Decalcomania
Cast Marking	Tape Code
A. Raised	Stencil
B. Depressed	Self-Adhesive Label

The application of the marking shall not damage the surface to which it is applied. All marking shall be neat and legible, and shall be durable enough to withstand normal handling of the finished product and all specified environmental conditions.

Whenever the assembly permits, the identification marking should be adjacent to the referenced item, and visible in the finished assembly.

Careless marking can impart an impression of poor quality to an otherwise high quality product.

4.11.2 Decalcomanias (Decals) and Self-Adhesive Labels

A Application

In applying decals, process specification 580-5002-00 should be followed to ensure proper adhesion.

B Appearance

Decals, when cured, should be smooth and undamaged and free of air bubbles. Unless otherwise specified, an edge of the decal shall appear parallel with the chassis or panel edge.

C Adhesion

Twenty-four hours after application, the decal shall adhere sufficiently to the surface to withstand normal handling. The decal must not tear, peel, or show visible evidence of becoming loose when the adhesive side of pressure sensitive tape is applied to the face and edges of the decal with light finger pressure, using quick contact and removal motions of the hand and fingers. Minnesota Mining Scotch Brand tape No. 213 or equivalent approved by Materials Engineering shall be used.

4.11.3 Ink Stamping

A Appearance

All stamping must be neat and legible. The lines forming a letter must be complete, although the lines forming the letter need not be the same weight throughout. Ink must not peel or flake easily from the surface.

B Protection of Stamping

To ensure lasting legibility and durability for the service life of the equipment, ink stamping that is likely to be subjected to abrasion or handling damage shall be suitably protected with lacquer or varnish.

All ink stamping on equipments required to be fungus resistant shall be coated with a fungus resistant material, unless the stamping ink is fungus resistant. Metal etching inks may need no extra protection.

4.11.4 Cable Marking Bands

Cable marking bands, metal or otherwise, shall be applied with proper tools and must be free of burrs and sharp edges that can damage the cable. When metal bands are used, care should be used to ensure against electrical shorts.

4.11.5 Tape Code Labels

Tape code labels may be used only as an assembly aid and must be removed from the equipment prior to shipment.

This type of marking may deteriorate with age depending upon environmental conditions, and in coming loose may cause mechanical malfunction and poor appearance.

4.11.6 Nameplates

Since the primary function of a nameplate is to supply information to the customer, it is important that all markings are clearly legible and correct in content and spelling.

Background paint or finish is of secondary importance unless the nameplate is to be mounted on the front of the unit or some other conspicuous location. The background color, if any, of Collins commercial nameplates shall be of a standard Collins color.

Markings or finish that are obviously the result of poor or careless workmanship will not be acceptable.

Approval status (ARINC, TSO, etc.) shall be stamped on the nameplate where there is space provided for it.

4.12 LATENT CONTAMINATION

Some processes, such as those involving a gas or liquid, may result in chemical action harmful to parts or material in equipment. Harmful effects may not be evident during factory inspection but may occur after the equipment is in service. Control, therefore, must be accomplished by strict adherence to process specifications.

printed circuit board assembly requirements

5.1 PRINTED CIRCUIT BOARD SPECIFICATIONS

Process Specifications set forth the level of quality which must be maintained at the various stages of manufacture of printed circuit boards (including switches) intended for use in Collins electronic equipments. It is recommended that Process Specifications be used in reference in matters involving requirements in the following categories.

- (a) Printed circuit board fabrication
- (b) Dimensions
- (c) Plating and solderability
- (d) Plated-thru holes
- (e) Inspection and test methods
- (f) Protective coatings
- (g) Warp and twist

In the event of conflict between the requirements of this document and the referenced Process Specifications, the Process Specifications shall be the controlling documents.

5.2 EYELETS, TUBELETS, TERMINALS, AND PLATED-THRU HOLES

5.2.1 Definitions

- A The term "eyelet" shall be used herein to define a tubular metal piece having one end headed or rolled over. The second end would be similarly formed during installation in a material.
- B The term "tubelet" shall be used herein to define a type of eyelet having one end formed in a conical flare of approximately 90 degrees included angle. The opposite end would be similarly formed during installation.
- C The term "terminal" shall be used in this section 5 to define a cylindrical piece of metal, of two or more diameters, which can be flared into a board for the purpose of connecting component leads or external wires to the board circuitry.
- D The term "plated-thru hole" shall be used to define an electroplated side-to-side connection for circuit boards where the thru-hole connection is an integral part of the circuitry.

- E The term "intentionally-split tubelet" is defined as the result of a process by which a forming tool radially splits a tubelet. This is done to improve the flow of solder.

5.2.2 Installation and Application

- A Roll flange eyelets shall not be used in boards having circuitry on both sides where circuit continuity from one side of the board to the other is dependent upon them.

Roll flange eyelets may be used in boards as mechanical fasteners and where ground connections are used in conjunction with mechanical mounting.

- B Terminals shall be flared (see figure 5-1) with a 90-degree ± 20 -degree included angle.




Figure 5-1. Eyelet, Tubelet, Terminal and Plated-Thru Hole on a Board




Figure 5-2. Intentionally Split Tubelets

- C Tubelets in boards having circuitry on both sides shall be installed so that both the head and flared end have a 90-degree ± 20 -degree included angle after installation.
- D Eyelets, tubelets, and terminals in boards having circuitry on one side only may be installed by rolling or flaring on the noncircuit side.
- E Intentionally split tubelets shall be installed so the split end is on the component side of the circuit board.

5.2.3 Other Quality Requirements

- A Cracks or splits in the rolled or flared portions of eyelets, tubelets, and terminals after installation shall be permissible with the following limitations:
- (1) No single part may have more than one crack or split per side of the board. Intentional splitting of tubelets in accordance with a Collins specification is acceptable. No circumferential tears are permitted.
 - (2) No crack or split on a part may extend past the surface of the board into the hole.

Unintentional cracks or tears may indicate defective tooling or material.

- B All tubelets, eyelets, split tubelets and terminals installed in a printed wiring board shall be attached firmly to the board so that they cannot be moved or rotated by finger pressure before soldering.
- C The inner diameter of tubelets and eyelets after flaring or rolling shall be not less than 95% of the calculated minimum inner diameter of the part before installation.

Example:	Tubelet	542-0811-003
	Inner Dia	.058 inch \pm .003 inch
	Minimum ID	.058 inch $-$.003 inch = .055 inch
	Minimum Acceptable ID after Installation	.055 inch \times .95 = .05225 inch or .052 inch

- D Eyelets, tubelets and terminals must be seated perpendicular to the board and contact the copper cladding.

5.3 COMPONENT ATTACHMENT

5.3.1 Components with Wire Leads

Electrical components with wire leads shall be prepared, inserted and clinched according to the following requirements:

- a. Component lead wires shall be reasonably straight, free of kinks, and properly cleaned and tinned before installation on printed wiring boards. Strain relief bends with one wire diameter (min) radius are not kinks.
- b. All wire leads which are inserted into circuit boards shall be clinched over on the side opposite to insertion, in the direction of circuit paths where applicable. The length of the clinched end shall be not less than 1/16 inch or more than 1/8 inch, measured from the center line of the hole from which the lead emerges to the cut end. In no case shall a clinched wire end on a board be closer to a nonconnected circuit path than the minimum spacing maintained between nonconnected circuit paths on that board. The clinch shall be such that it holds the component lead perpendicular to the board. The clinched




Figure 5-3. Assembled Printed Circuit Board

lead shall contact the tubelet through which the lead is projected, so that the lead is mechanically secure during the soldering operation. Component tab, pin or lead terminals not designed to be bent shall not be bent.

- c. No process of straightening, cutting, bending, inserting, or clinching wire leads of electrical components shall be permitted which could result in internal damage, change of rating, or change of value of those components.
- d. Markings pertaining to values, tolerance, ratings, etc., shall be intact, legible, and readable from the most visible angle.
- e. Sharp bends in component leads shall be avoided. See paragraph 2.5.
- f. Component lead bends shall not be positioned so close to the integral body of the component (welds, solder beads, plastic seal fillets, etc., included) that fracturing or other damage could result. (See paragraph 2.4.5.)

- g. Component leads shall be free of large indentations and fractures, cuts and nicks as specified in paragraph 1.1.3.C.
- h. Whenever possible, components should be centered between mounting points.
- i. Component leads shall not be stressed tight between mounting points. Adequate strain relief shall be provided to prevent damage to the component and solder joint. See figures 2-4 and 2-5.




Figure 5-4. Lead Clinch
and Cut-Off

5.3.2 Hardware Mounted Components

Electrical components, clamps, connectors, brackets, etc., which are to be mounted with threaded hardware shall be fastened in accordance with the requirements described in section 3 of this manual. If the fastener is covered with an approved post-coating material, no additional locking is required.

5.3.3 "Snap-In" Components

"Snap-in" components, such as tube sockets, transistor sockets, etc., shall be oriented and seated in the board properly. All metal tabs, spring leads, etc., which are intended for electrical connection to circuitry by soldering, shall be in contact with the circuit to which they are to be soldered.

5.4 QUALITY REQUIREMENTS FOR PRINTED CIRCUIT BOARD ASSEMBLIES

5.4.1 Component Bodies and Wire Leads

Failure to meet the requirements of paragraphs 5.3.1 through 5.3.3, or presence of any of the following defects shall be cause for rejection of the board assembly:

- a. Chipped or cracked components per paragraph 2.3.
- b. Wire leads which are fractured, broken, collapsed, or otherwise improperly inserted.

5.4.2 Printed Circuitry Separation

A lifted, separated or unbonded circuit may be identified easily by viewing the circuitry from the opposite side of the translucent laminate. An unbonded circuit will not be visible when viewed as described.

Printed Circuit Board Assembly Requirements

- A Unbonded circuitry less than 1/2 inch in length (see figure 5-5) may be made acceptable by rebonding the circuitry to the laminate with currently approved epoxy bonding materials. Bonding material shall be applied all over and beyond the lifted area for a distance of approximately 1/16 inch all around. No one printed wiring path shall exhibit more than two such rebonded areas in its length.
- B Any board on which a circuit path shows lifting exceeding 1/2 inch of continuous length shall be rejected.
- C There shall be no allowable separation of the cladding from the base laminate in the contact area on printed switches. Separation detectable by the unaided eye is cause for rejection.

5.4.3 Base Laminate

A scratch in the base laminate deep enough to expose the base filler material shall be repaired if it is closer than 1/32 inch to adjacent circuits. Post-coating will accomplish this repair.




Figure 5-5. Lifted Circuitry Repairable Maximum

5.4.4 Repair of Printed Circuit

Limited damage to circuitry may be repaired by connecting wire from tubelet to tubelet.

5.5 SOLDERING ON PRINTED BOARDS

5.5.1 Preparation

- A Surfaces to be soldered shall be free of grease, dirt, oxide, scale, or other foreign materials.
- B All wires, component leads, and terminals which do not have an easily solderable coating shall be tinned before soldering.
- C All forming and trimming of leads shall be done prior to soldering.

5.5.2 Fluxes

- A Only currently approved solder fluxes shall be used.
- B Corrosive (chloride) fluxes shall not be used on printed wiring boards.
- C Flux may be applied to boards by spraying, dipping, or brushing. All surfaces to be soldered must be covered with flux.

5.5.3 Hand Soldering

- A In making a proper solder joint, it is necessary that there be no movement of the members until the solder has hardened completely. Movement during the soldering operation could result in a fracture or weakened joint which eventually may break under strain. Prevention of movement of members is the reason for making the wire mechanically secure to the terminal prior to soldering.
- B In the soldering operation, the members to be soldered must be hot enough to maintain the solder in a melted condition until the necessary "wetting" action takes place. It is important that the soldering iron or other source of heat be of adequate capacity to maintain the metal being soldered at the proper fusion temperature.
- C The soldering iron tip shall be kept tight within the iron and excess oxidation shall be removed at frequent intervals to ensure maximum transfer of heat from the heating element to the tip. A bright, clean, well-tinned, smooth face shall be kept on the tip. The tinned portion should extend a minimum of 1/2 inch back from the pointed end.
- D Heat sinks shall be used on the leads of all components that could be damaged by the heat of normal soldering.
- E If a solder connection is to be reheated, the old solder should be removed and the new solder applied, unless the reason is insufficient solder, in which case additional solder would be applied. Removal of solder from a joint shall be accomplished by a method that minimizes heat transfer to the component, such as the use of wire braid to soak up molten solder.
- F Only enough solder should be applied to allow adequate alloying action to take place but the solder shall be plainly visible. The general outline of the members should be visible. See figure 1-20.
- G Insulation or foreign material shall not be imbedded in a solder joint.
- H Cored solder having an approved flux or a solid wire solder used with a separate approved flux shall be used in hand-soldering. 63/37 solder is preferred (60/40 solder is also acceptable) unless otherwise specified.

5.5.4 Dip Soldering

- A Circuitry other than contact areas and plated areas must be coated with solder.

Printed Circuit Board Assembly Requirements

- B The composition of solder for dip-soldering printed circuit assemblies shall be 63% tin, 37% lead, unless otherwise specified.
- C The temperature of the molten solder for dip-soldering shall be maintained so that complete fusion of the alloy to the metal to be soldered shall result. All metal to be soldered shall be covered completely after soldering and well tinned with concave fillets (radii) in evidence.
- D All tubelets, eyelets, plated-thru holes, or any other surfaces which are not to be soldered during a dip solder operation shall be suitably masked, covered, or plugged.

5.5.5 Removal of Flux Residues

- A - All residues shall be removed from board surfaces and parts after soldering, using suitable cleaning agents or processes.
- B The cleaning agents or processes must not attack or degrade the board materials, component materials, color codings or silk-screened paint markings of the assembly. They shall be noncorrosive.

5.5.6 Workmanship Standards - Dip-Soldered Boards

- A The completed printed wiring board assembly shall conform to all the requirements stated. Spare parts, subassemblies, or other printed boards containing only tubelets, eyelets, and terminals also shall conform. Presence of the following defects shall be cause for rejection:
 - a. Incomplete coverage by solder of metal surfaces, component leads, tubelets, or terminals which are to be soldered.
 - b. "Cold" or fractured solder joints or nonadherence of solder to metal.
 - c. Excess solder globules, peaks, strings, or bridging of solder between adjacent parts or circuits.
 - d. Burned, scorched, or otherwise heat-damaged boards or components.
 - e. Corroded metal parts or circuits.
 - f. Flux residues, oils, greases, or foreign materials on assembly.
 - g. Substantial damage to color codes or nomenclature of electrical components, silk-screened paint, component materials, or board materials.
- B Solder joints and solder coatings must not reduce the spacing of conductors to less than $\frac{2}{3}$ of the nominal spacing; where greater spacing is necessary due to high voltage, etc., the minimum spacing should be specified on the drawing. Excessive solder globules, bumps, or peaks must be removed. There must be visible evidence of the lead under the solder coating, on the side of the board opposite the component.

5.6 POST-COATING

When specified on the drawing, printed wiring boards shall be given a resinous coating on completion of the component assembly and soldering operations. The coating must protect the board surface from contamination, mechanical damage, and moisture.

5.6.1 Cleaning

Immediately before applying the coating, the surface of the printed board shall be free of any moisture, grease or residue which would lower the surface resistivity of the printed board or reduce the adhesion of the coating.

5.6.2 Masking

Terminals, sockets, connectors, and portions of the metallic pattern such as switch pads which are to be used for electrical connection, shall be suitably masked so that they do not become coated.

5.6.3 Cured Coating Requirements

The cured coating shall meet the following requirements:

- a. It shall be smooth and uniform, without excessive globules or bare spots.
- b. It shall be substantially free from bubbles.
- c. There shall be no blisters or cracks.

5.7 HANDLING AND PACKAGING

The fabricated boards shall be handled and packaged carefully to avoid scratching, chipping, or other damage during shipment, assembly, or storage.

resistance welding of circuitry

6.1 CONDUCTORS

6.1.1 Surface Conditions

All surfaces to be welded shall be free from oil, wax, dirt, grease, oxides, paint, or other foreign material which may be detrimental to the achievement of an acceptable weld. Surface coatings detrimental to the welding process shall be removed by methods that will not create the conductor imperfections described in paragraph 6.1.4. If resistance welded connections are used adjacent to soldered connections on a single terminal, the completed termination must be cleaned with a solvent which will not increase the rate of corrosion.

6.1.2 Bending of Component Leads and Nickel Wire (before welding)

Kinking of component leads (prior to assembly) or bending not required for lead forming shall not be permitted. All bends of component leads and nickel wire shall be clearly separated from the weld location. The beginning of curvature must be at least $1/2 E + 0.020$ inch from the center of the weld, as shown in figure 6-1. Bending of component leads is to be avoided whenever possible. Nickel wire or ribbon may be bent in any direction.




Figure 6-1. Forming of Conductor Before Welding

6.1.3 Permissible Weld Combinations

The combinations of materials or alloys to be welded shall be as indicated in an approved weld schedule.

6.1.4 Conductor Imperfections

Conductor imperfections shall be classified as follows and will be limited as described:

(1) Abrasions

An abrasion is a scraped or roughened surface finish of a conductor. It is identified by its lack of definite outline, shallowness and the fact that it may

extend for a relatively long distance along the conductor. Abrasions do not create any critical stress points and are acceptable unless extensive enough to be considered nicks or indentations, or result in exposure of the base material as defined below.

(2) Indentations

An indentation is a deformation of the surface of the conductor by a dull or blunt instrument. In either conductor, indentations with depths exceeding $1/4$ the diameter of the conductor shall not be allowed.

(3) Nicks

A nick is a partial severance of the conductor by a sharp instrument. No nick in either conductor shall be allowed.

(4) Exposure of Base Material

Any single or multiple exposure of the base material shall not exceed $1/4$ of the diameter of the conductor, as shown in figure 6-1A.




Figure 6-1A. Exposure of Base Material

6.2 STRANDED WIRE WELDING

Weld connections of stranded wire shall not be permitted without the written approval of the cognizant welding Application Engineer.

6.3 SPACING FROM COMPONENT BODY TO TERMINAL

Spacing from the component body to the terminal center line shall be measured from the point at which the component lead is weldable. The minimum spacing is 0.050 inch. The recommended spacing is one-half the welding electrode diameter, dimension D in figure 6-2, plus 0.020 inch. Spacing shall provide for centering components where possible.




Figure 6-2. Spacing from Component to Terminal

6.4 ANGLE OF CONDUCTORS

6.4.1 Cylindrical Conductors

The angle of welded connections of cylindrical conductors shall be 90 ± 45 degrees. See Figure 6-3. This requirement does not apply to butt welds; refer to paragraph 6.16 for butt welding requirements.




Figure 6-3. Angle Between Lead and Terminal

6.4.2 Ribbon Conductors

The angle of welded connections using ribbon conductors or ribbon and cylindrical conductors shall be 90 ± 10 degrees.

6.5 SPACING BETWEEN WELDS ON A TERMINAL

Where several conductors are welded to one terminal, the following limitations, which are illustrated in figure 6-4, shall be observed:




Figure 6-4. Spacing Between Welds

(1) Preferred Spacing

The preferred spacing between adjacent welded conductors on the terminal is $\frac{1}{2}$ the electrode face dimension plus 0.015 inch.

(2) Acceptable Spacing

If closer spacing than the preferred dimension is required, the minimum acceptable spacing shall equal one diameter of the adjacent conductor.

(3) Minimum Terminal Remainder

The minimum distance remaining from the top of the upper conductor to the top of the terminal shall equal one diameter of the upper conductor below the radiused or chamfered portion of the terminal top.

6.6 STACKING OF COMPONENTS ON TERMINALS

The components must be welded in the order specified by the assembly drawings and/or approved assembly methods.

6.7 CONNECTING TRANSISTORS - Deleted

Figure 6-5. Transistor Lead Extension - Deleted

6.8 CLEARANCE

A 0.030-inch minimum clearance is required between an uninsulated lead (or ribbon) and a terminal or other conductor operating at a different voltage, unless high circuit potentials require more clearance, in which case the drawings shall specify the increased clearance. See figure 6-6.




Figure 6-6. Minimum Clearance

6.9 MULTIPLE TERMINAL CONNECTIONS

When more than two terminals are to be connected by bus wire, the bus shall be bent and welded on the far side of the center terminals (concave side of bus wire) to reduce stresses on the weld, as shown in figure 6-7. If necessary, the wire can be welded on the inside of the terminal (convex side of wire) if the weld is made on a straight section of wire. (See figure 6-1.) If the wire is to be bent after the weld is made, the beginning of curvature shall be a minimum of 0.040 inch from the edge of the weld.




Figure 6-7. Position of Terminal

6.10 CLIPPING

- A. All bus wires and component leads shall be clipped no more than 1/16 inch from the conductors to which they are welded. See figure 6-8.
- B. The minimum clearance between a clipped wire or lead and an insulated lead is 0.030 inch. Clipped bus wire has sharp edges and will cut insulation. All wires should be routed and secured away from contact with a clipped wire or lead end.




Figure 6-8. Clipped Wire Dimension and Clearance

6.11 SLEEVING

All sleeving must conform to the requirements of paragraph 1.8 of this manual. Sleeving shall be required on all component leads and on other bare conductors longer than $\frac{3}{4}$ inch. During welding, such sleeving shall not be permitted closer than $\frac{1}{16}$ inch from the edge of the terminal.

6.12 WELD STANDARDS

6.12.1 Acceptable Welds

A good weld is indicated by the following items:

- (1) The correct quantity of melt between the two materials being welded.
- (2) The proper "set-down" (indentation) of the material at the weld location.

There must be an indication that the base or core material (not just the tinning or coating) is fused.




Figure 6-9. Good Weld

6.12.2 Defective Welds

Welds shall be rejected if any of the following defects are present:

a. Weld Splatter

Whiskers of metal with length over .010 inch protruding from the weld in an irregular manner. Such whiskers are the result of an improper weld and removal of the whiskers will not make the weld acceptable.


WELD SPLATTER

Figure 6-10. Weld Splatter

b. Crack

A crack in or adjacent to the weld area. See figure 6-11.


CRACKED WELD

Figure 6-11. Cracked Weld

c. Blow Hole

Any hole greater than .003 inch diameter in the fused area between the welded parts.




Figure 6-12. Blow Hole

d. Burned Weld

Any welded member which is reduced by heat (and pressure) more than 50 percent of its original dimension.




Figure 6-13. Burned Weld

e. Burned Hole

A hole of any size through either of the welded members.

BURNED HOLE




Figure 6-14. Burned Hole

f. Insufficient Weld

Absence of flow of melt around weld joint indicating lack of fusion between elements of the welded joint. If this condition is peculiar to the combination of materials and is noted on the weld schedule, it is an acceptable weld.

INSUFFICIENT WELD




Figure 6-15. Insufficient Weld

g. Electrode Sticking

A particle of electrode material on either member of the weld joint, or evidence of lead damage due to sticking.

h. Deformation

Depression or flattening of either joint member exceeding 30 percent of the original dimension of the member at the electrode contact point. If noted on the weld schedule, deformation greater than 30 percent shall be acceptable as a condition peculiar to the combination of materials.

DEFORMATION




Figure 6-16. Deformation

i. Indentation by Electrode

Maximum depth of indentation (caused by the miscentering of the leads with respect to the center of the electrode face) shall not exceed 10 percent of the original cross section of the indented lead.

MIS-CENTERED LEADS ON ELECTRODES




Figure 6-17. Miscentered Leads
on Electrodes

6.12.3 Discoloration

The presence of discoloration at the weld joint is not a cause for rejection. However, a distinct change in characteristic color of a given combination usually means that one of the defects listed in paragraph 6.12.2 is present.

6.13 REPAIR OF REJECTED WELDING

If a weld is defective, the conductor shall be cut as close to the weld joint as possible. The bit of material left in the weld area can remain in place if it proves to be secure during a reasonable amount of probing. The following criteria shall govern the replacement of a rejected weld:

- (1) Sufficient conductor length shall remain for the required weld.
- (2) The weld shall be separated from the original location of the rejected weld as in paragraph 6.5. In no case shall a repair be done on the same spot as the original weld; or at a location on the same cross sectional plane.
- (3) Terminal diameter shall not be reduced below the limits of paragraph 6.12.2, d or h.

6.14 SOLDER BEADS ON "TIN" DIPPED CONDUCTORS

Tinned (dipped) conductor materials, such as some resistor leads, will intermittently produce small solder beads when welded to a high resistivity terminal material. In such cases, the following steps must be taken:

- (1) Probe each bead and remove it if it is loose.
- (2) Remove bead if it presents an objectionable appearance to the naked eye.
- (3) Remove bead if it makes a potential short.

6.15 INSPECTION

6.15.1 Inspector Qualification




All welding inspection shall be performed by qualified inspectors who have demonstrated their ability to recognize the conditions described in this section, and their understanding of the resistance welding process.

appendix A

Mica Capacitor Color Code

EIA STANDARD RS-153

MIL-C-10950



Color	Digits of Capacitance (μmf)			Multiplier D	Tolerance % E	Characteristic See table below F
	A	B	C			
Black	0	0	0	1	± 20	A
Brown	1	1	1	10	± 1	B
Red	2	2	2	100	± 2	C
Orange	3	3	3	1,000	± 3	D
Yellow	4	4	4	10,000*	—	E
Green	5	5	5	—	± 5	—
Blue	6	6	6	—	—	—
Violet	7	7	7	—	—	—
Gray	8	8	8	—	—	—
White	9	9	9	—	—	—
Gold	—	—	—	0.1	—	—
Silver	—	—	—	0.01	± 10	—

DESCRIPTION OF CHARACTERISTIC

Characteristic	Temperature Coefficient (parts per million per $^{\circ}\text{C}$)	Maximum Capacitance Drift	Minimum Insulation Resistance (megohms)
A	± 1000	$\pm (5\% + 1 \mu\text{mf})$	3000
B	± 500	$\pm (3\% + 1 \mu\text{mf})$	6000
C	± 200	$\pm (0.5\% + 0.5 \mu\text{mf})$	6000
D	± 100	$\pm (0.3\% + 0.1 \mu\text{mf})$	6000
E	+100 -20	$\pm (0.1\% + 0.1 \mu\text{mf})$	6000
I	+150 -50	$\pm (0.3\% + 0.2 \mu\text{mf})$	6000
J	+100 -50	$\pm (0.2\% + 0.2 \mu\text{mf})$	6000





VOLTAGE RATING

(Indicated by dimensions rather than color coding)

Maximum Inches			Style	Capacitance (μmf)	Rating (v d-c)
Long	Wide	Thick			
$5\frac{1}{64}$	$1\frac{5}{32}$	$\frac{7}{32}$	20	5-510 560-1000	500 300
$1\frac{7}{64}$	$1\frac{5}{32}$	$\frac{7}{32}$	25	5-1000 1100-1500	500 300
$5\frac{3}{64}$	$5\frac{3}{64}$	$\frac{9}{32}$	30	470-6200 Over 6200	500 300
$5\frac{3}{64}$	$5\frac{3}{64}$	$\frac{3}{8}$	35	3300-6200 Over 6200	500 300
$1\frac{1}{32}$	$4\frac{1}{64}$	$1\frac{1}{32}$	40	100-2400 2700-7500 Over 7500	1000 500 300

Mica Capacitor Color Code





Obsolete Style



Dot Color	Digits of Capacitance (μmf)			Multiplier D	Tolerance % E	Voltage Rating (v d-c) F
	A	B	C			
Black	0	0	0	1	± 20	—
Brown	1	1	1	10	± 1	100
Red	2	2	2	100	± 2	200
Orange	3	3	3	1,000	± 3	300
Yellow	4	4	4	10,000	± 4	400
Green	5	5	5	100,000	± 5	500
Blue	6	6	6	1,000,000	± 6	600
Violet	7	7	7	10,000,000	± 7	700
Gray	8	8	8	100,000,000	± 8	800
White	9	9	9	1,000,000,000	± 9	900
Gold	—	—	—	0.1	± 5	1,000
Silver	—	—	—	0.01	± 10	2,000
No Color	—	—	—	—	± 20	500

Resistor Color Code

RETMA STANDARD RS-172, REC-117 MILITARY STANDARD MIL-STD-221A



Color	1st Digit A	2nd Digit B	Multiplier C	Tolerance D
Black	0	0	1	—
Brown	1	1	10	—
Red	2	2	100	—
Orange	3	3	1,000	—
Yellow	4	4	10,000	—
Green	5	5	100,000	—
Blue	6	6	1,000,000	—
Violet	7	7	10,000,000	—
Gray	8	8	100,000,000	—
White	9	9	—	—
Gold	—	—	0.1	± 5%
Silver	—	—	0.01	± 10%
No Color	—	—	—	± 20%

OLD INSULATION CODING


RETMA: Insulated resistors with axial leads are designated by a background of any color except black. The usual color is natural tan. Noninsulated resistors with axial leads are designated by a black background color.

MILITARY (MIL): Same as RETMA with the addition of: Noninsulated resistors with radial leads designated by a black background color or by a background the same color as the first significant figure of the resistance value.

Mica Capacitor Color Code MILITARY STANDARD

SEE MIL-C-5A, -5B

BLACK MEANS
MIL MICA



Color	Digits of Capacitance (μf)		Multiplier C	Tolerance % D	Characteristic. See table below E
	A	B			
Black	0	0	1	± 20	—
Brown	1	1	10	—	—
Red	2	2	100	± 2	—
Orange	3	3	1,000	—	—
Yellow	4	4	—	—	—
Green	5	5	—	—	—
Blue	6	6	—	—	—
Violet	7	7	—	—	—
Gray	8	8	—	—	—
White	9	9	—	—	—
Gold	—	—	0.1	± 5	—
Silver	—	—	0.01	± 10	—

DESCRIPTION OF CHARACTERISTIC

Characteristic	Temperature Coefficient (parts per million per °C)	Maximum Capacitance Drift	Minimum Insulation Resistance (megohms)
B	Not specified	Not specified	7500
C	± 200	± 0.5%	7500
D	± 100	± 0.3%	7500
E	+100 -20	± (0.1% + 0.1 μf)	7500
F	+70	± (0.05% + 0.1 μf)	7500

VOLTAGE RATING


(If indicated by dimensions rather than color coding)

Maximum Inches			Style CM	Capacitance (μf)	Rating (v d-c)
Long	Wide	Thick			
$\frac{35}{64}$	$\frac{5}{16}$	$\frac{7}{32}$	15	5-510	300/500
$\frac{51}{64}$	$\frac{15}{32}$	$\frac{7}{32}$	20	5-510 560-1000	500 300/500
$\frac{17}{32}$	$\frac{15}{32}$	$\frac{7}{32}$	25	51-1000	500
$\frac{53}{64}$	$\frac{53}{64}$	$\frac{9}{32}$	30	560-3300	500
$\frac{53}{64}$	$\frac{53}{64}$	$\frac{11}{32}$	35	3600-6200 6800-10,000	500 300
$\frac{11}{32}$	$\frac{41}{64}$	$\frac{11}{32}$	40	3300-8200 9100-10,000	500 300


Paper Capacitor Color Code

MILITARY STANDARD MIL-C-91A

(Commercial codes are same except as noted)



**Tubular Capacitors
(Commercial Only)**



Rectangular Capacitors

Color	Digits of Capacitance ($\mu\mu\text{f}$)		Multiplier C	Tolerance % D	Tubular Voltage Rating (v d-c) E	Temp. Rating $^{\circ}\text{C}$ and Characteristic F
	A	B				
Black	0	0	1	± 20	—	85-A
Brown	1	1	10	—	100	85-E
Red	2	2	100	—	200	—
Orange	3	3	1,000	± 30	300	—
Yellow	4	4	10,000	—	400	—
Green	5	5	—	—	500	—
Blue	6	6	—	—	600	—
Violet	7	7	—	—	700	—
Gray	8	8	—	—	800	—
White	9	9	—	—	900	—
Gold	—	—	—	—	1,000	—
Silver	—	—	—	± 10	—	—

VOLTAGE RATING FOR RECTANGULAR CAPACITORS

(Indicated by dimensions rather than color coding)

Maximum Dimensions (inches)			Style CN	Capacitance ($\mu\mu\text{f}$)	Voltage Rating (v d-c)
Length	Width	Thick- ness			
$5\frac{1}{64}$	$1\frac{5}{32}$	$\frac{7}{32}$	20	1000 2000-6000 10,000	400 200 120
$5\frac{7}{64}$	$3\frac{7}{64}$	$1\frac{7}{64}$	22	2000-3000 6000-10,000 20,000	400 300 120
$5\frac{3}{64}$	$5\frac{3}{64}$	$\frac{9}{32}$	30	1000-2000 3000 6000-10,000 20,000	800 600 400 120
$5\frac{3}{64}$	$5\frac{3}{64}$	$1\frac{1}{32}$	35	3000 6000-10,000 20,000	800 600 300
$1\frac{1}{4}$	$4\frac{1}{64}$	$\frac{9}{32}$	41	3000-6000 10,000 20,000 30,000	600 400 300 120
$1\frac{15}{32}$	$4\frac{9}{64}$	$1\frac{1}{32}$	42	1000-6000 10,000-20,000 30,000 50,000 100,000	1000 600 400 300 120
$1\frac{15}{32}$	$4\frac{9}{64}$	$1\frac{5}{32}$	43	10,000 20,000-30,000 50,000-100,000 200,000	1000 600 400 120


Ceramic Capacitor Color Code

SEE EIA STANDARD RS-198


MILITARY STANDARD MIL-C-11015B,

MIL-C-20C


INNER-ELECTRODE
END




Tubular Capacitors
(Voltage rating is always 500 v.)



Tubular Capacitors
(Old RMA)




Stand-Off Capacitors
(RETMA ONLY)




3-Dot Button Capacitors
RETMA ONLY


5-Dot
System




RADIAL LEAD



Feed Through Capacitors



5-Dot Disc Capacitors
(EIA)
(Voltage rating is
500 v. or as marked)



6-Dot Disc Capacitors
(Voltage rating is always 500 v.)

Color	Digits of Capacitance ($\mu\mu\text{f}$)			Multiplier E	Tolerance F		Temp. Coef. A (Parts per million per $^{\circ}\text{C}.$)	
	B	C	D		10 $\mu\mu\text{f}$ or less ($\mu\mu\text{f}$)	Over 10 $\mu\mu\text{f}$ (%)	EIA	MILITARY
Black	0	0	0	1	± 2.0	$\pm 20^*$	0	0
Brown	1	1	1	10	$\pm 0.1^*$	± 1	— 33	— 30
Red	2	2	2	100	$\pm 0.25^{**}$	± 2	— 75	— 80
Orange	3	3	3	1,000	—	$\pm 3^*$	— 150	— 150
Yellow	4	4	4	10,000*	—	+100.0*	— 220	— 220
Green	5	5	5	—	± 0.5	± 5	— 330	— 330
Blue	6	6	6	—	—	—	— 470	— 470
Violet	7	7	7	—	—	—	— 750	— 750
Gray	8	8	8	0.01	$\pm 0.25^*$	+80 -20*	+150 to — 1500	+ 30
White	9	9	9	0.1	± 1.0	± 10	+100 to — 750	+330*
Gold	—	—	—	—	—	—	—	+100



* EIA (formerly RETMA) ** MIL-C-20C

COLOR CODING MOLDED CHOKE COILS
MIL-C-15305B

A silver band, greater in width than the other bands, near one end of the coil is the MIL identifier. The inductance value in microhenries is indicated by three additional bands. For inductance values of 10 microhenries or more, the color code is the same as for resistors. When either the first or second of the three bands is gold, the gold band represents the decimal point for inductance values less than 10. The other two colors represent the significant figures using the same digit values as for resistors.

For small chokes, dots may be used instead of bands as above.

EXAMPLES



It is significant to note that there have been isolated instances when, for no apparent reason, the manufacturer has not followed this marking code. If there is any question or doubt about the value of a choke, it should be checked by actual measurement on a suitable bridge.

1N DIODE TYPE AND POLARITY PER EIA STANDARD RS 236, etc.


Types are identified by number or by colored bands which designate the JEDEC type number. Reading from the cathode end, the digits are represented by the same colors as in the resistor color code. If necessary to show a suffix letter, a band will follow the type number as follows:

Brown	A	Yellow	D
Red	B	Green	E
Orange	C	Blue	F

Four-digit type numbers are shown by four bands followed by a fifth, black, band. If a suffix letter is required, it will be indicated as the fifth band in place of the black band.

The cathode end is indicated by a double-width band as the first band; or bands should be grouped toward the cathode end. The cathode end may be indicated by a single band or by the bar of the diode symbol: Cathode \rightarrow \blacktriangleleft Anode.


Examples 2 or 3 DIGIT TYPES OF DIODES




4 DIGIT TYPES OF DIODES

EIA Type	1st Band	2nd Band	3rd Band	4th Band	5th Band
1N1234A	Brown - 1	Red - 2	Orange - 3	Yellow - 4	Brown - A
1N1695	Brown - 1	Blue - 6	White - 9	Green - 5	Black - 0

TYPICAL DIODE POLARITY GUIDE



TRANSISTOR BASE DIAGRAMS



NOTE: MANY MANUFACTURERS CONNECT ONE OR ANOTHER OF THE LEADS TO THE CASE STRUCTURE, SO THE INDIVIDUAL TRANSISTOR SPECIFICATION SHEET SHOULD BE REFERRED TO BEFORE CONNECTING THE TRANSISTOR INTO A CIRCUIT, ESPECIALLY FOR BASE DIAGRAMS B, G, & H.

PART AND ASSEMBLY DESIGNATIONS

Alphabetically by Letters

General classes of parts are marked with an asterisk (*) to facilitate designation of parts not specifically included in this list. In case of doubt, a letter or letters already assigned to the class most similar in function should be used. Certain item names may apply to either a part or a subassembly. When the item is a subassembly, the letter "A" shall be used in lieu of the letters listed except in the case of wire and cable.

*A Assembly; subassembly.	G Exciter; generator; magneto; rotating amplifier; vibrator (interrupting), chopper.
AT Attenuator; pad; resistive termination.	*H Hardware; bolts; nuts; screws; etc.
*B Blower; fan; motor; prime mover; resolver; synchro.	HR Heater (element for thermostat, oven, etc.), heating lamp.
BT Battery.	HS Handset.
C Capacitor, capacitance bushing, silicon diode voltage variable capacitor.	HX Heat exchanger.
CB Circuit breaker.	HT Headset; hearing aid; telephone receiver.
CP Coupling (aperture, loop, or probe); coaxial or waveguide junction (tee or wye); adapter, connector.	HY Hybrid coil; hybrid junction.
CR Crystal detector; crystal diode; crystal unit; crystal, contact or metallic rectifier; selenium cell; varistor, asymmetrical.	J Connector, receptacle, electrical (with male, female, or male and female contacts and designed to be mounted on a bulkhead, wall, chassis or panel); jack; receptacle.
D Dynamotor, converter, inverter.	K Relay (electrically operated contactor or switch).
DC Directional coupler.	L Choke; inductor; loading coil; relay operating coil; retardation coil; solenoid; tuning coil; winding; reactor, filter; ferrite bead.
DL Delay line.	LS Loudspeaker; horn; howler; siren; speaker.
DP Diaphragm.	*M Meter; clock; counter (indicating device); elapsed time recorder; gauge; instrument; message register; oscillograph; oscilloscope; thermometer; timer.
*DS ... Indicator; miscellaneous illuminating or indicating device (except meter or thermometer) such as: alarm, annunciator; audible or visual signalling device; bell; buzzer; drop; flasher; pilot, illuminating or signal lamp; telegraph sounder; telephone set ringer; vibrator (indicating) dials.	MG Motor-generator.
*E Miscellaneous electrical part such as: aerial; aluminum or electrolytic cell; antenna; armature assy, bimetallic strip; binding post; brush; carbon block; clips; cord tip; counterpoise; dipole antenna; electrical shield; electric contact; gap; individual terminal; insulator; lightning arrester; loop antenna; magnet; printed circuit boards; protector; resonator; short; slip ring; rotor; solenoid.	MK Microphone; telephone transmitter.
EQ Equalizer.	*MP ... Miscellaneous mechanical part such as: bearing; coupling; gear; mechanical interlock; shaft; vibrator reed; gyroscope; structural part; window, observation; mounting (not in electrical circuit and not a socket); air filter.
F Fuse; fuse cutout.	MR Magnetic reactor.
FL Filter.	MT Mode transducer.
	N Plate, identification; chart; name-plate; etc.
	O Knob.

PART AND ASSEMBLY DESIGNATIONS (Cont)

P Connector, plug, electrical (with male, female, or male and female contacts, constructed to be affixed to the end of a cable, conduit, coaxial line, cord or wire).

PU Pickup; erasing head; recording head; reproducing head.

Q Transistor.

R Resistor; shunt; resistor, variable; potentiometer; rheostat, dummy load.

RP Repeater.

RT Current regulating resistor; ballast tube; ballast lamp; resistance lamp; thermistor.

RV Symmetrical varistor.

S Switch (mechanically or thermally operated); contactor; disconnecting device; dial (circuit interrupter); electrical safety interlock; governor switch; speed regulator; telegraph key; thermal cutout; thermostat.

T Transformer; autotransformer; IF transformer; repeating coil (telephone usage); transformer; waveguide or coaxial taper; induction coil (telephone usage).

TB Terminal board; connecting block; group of individual terminals on its own mounting; terminal strip; test block.

TC Thermocouple.

**TP Test point.

*U Hydraulic part.

V Electron tube; barrier photocell; blocking layer cell; light-sensitive cell; photoemissive cell; phototube, photoconductive cell.

VR Voltage regulator (except an electron tube).

*W Cable; coaxial cable; guided transmission path; waveguide; wire.

X Socket; fuseholder (see note 2) lampholder.

Y Oscillator (excluding electron tube used as an oscillator); piezoelectric crystal; magnetostriction oscillator.

Z Artificial line; discontinuity; tuned cavity; tuned circuit; network; mode suppressor.

Note 1. TERMINALS. The letter "E" shall not be used to identify terminals of such parts as sockets, terminal boards, transformers, etc., where terminal numbers are assigned and no confusion will result.

Note 2. SOCKETS. A socket or fuseholder which is always associated with a single particular part or subassembly, such as an electron tube, fuse, or printed circuit board (not containing a separate electrical connector), shall be identified by a composite reference designation which includes the class letter "X" and the letter (s) and number which identify the associated part. For example, the fuse holder for fuse F7 would be identified XF7, and the socket for electron tube 10V3 would be identified 10XV3, etc.

Note 3. CONNECTORS. When reference designations are required to identify cables and connectors, the reference designations of the movable connector and adapter shall be included in parentheses on drawings and diagrams, at the stationary connector marking. Whenever possible, the item number shall be the same for the stationary and the movable connectors.

Note 4. POTTED, EMBEDDED, OR HERMETICALLY SEALED SUBASSEMBLIES. A potted, embedded, or hermetically sealed subassembly ordinarily replaced as a single item of supply shall be treated as a subassembly for reference designation marking purposes.

**Not a reference designation, but included in this listing to permit usage in connection with reference designations, where required.

CONVERSION TABLES

To Convert	Into	Multiply By	Conversely Multiply By
Calories	Btu	3.97×10^{-3}	252
Calories (mean)	Watt-seconds	4.186	0.2389
Centigrade	Fahrenheit	$\times 9/5$, add 32°	Sub. 32° , $\times 5/9$
Chains	Feet	66	1.515×10^{-2}
Cubic feet	Gallons (U.S.)	7.481	0.1337
Cubic inches	Gallons (U.S.)	4.329×10^{-3}	231
Gallons (U.S.)	Gallons (Brit)	0.8327	1.201
Grains (for humidity)	Pounds (Avoir)	1.429×10^{-4}	7000
Grams	Grains	15.43	6.481×10^{-2}
Grams	Ounces (Avoir)	3.527×10^{-2}	28.35
Inches	Centimeters	2.540	0.3937
Kilowatt-hours	Btu	3413	3.930×10^{-4}
Knots	Miles per hour	1.1508	0.8690
Meters	Yards	1.094	0.9144
Miles per hour	Feet per minute	88	1.136×10^{-2}
Ounces (fluid)	Quarts	3.125×10^{-2}	32
Ounces (avoir)	Pounds	6.25×10^{-2}	16
Pounds of water	Gallons	0.1198	8.347
Watts	Horsepower	1.341×10^{-3}	745.7

INCANDESCENT LAMPS FOR INDICATOR LIGHTS

Size	Base Type	Commercial Number	Voltage (D. C.)	Current (Amps)
T-1	Wire Leads	680	5.0	0.060
T-1	Wire Leads	683	5.0	0.060
T-1	Wire Leads	715	5.0	0.115
T-1	Wire Leads	683AS15	5.0	0.060
T-1	Wire Leads	715AS15	5.0	0.115
T-1	Flange	682	5.0	0.060
T-1	Flange	685	5.0	0.060
T-1	Flange	718	5.0	0.115
T-1	Flange	685AS15	5.0	0.060
T-1	Flange	718AS15	5.0	0.115
T-1-3/4	Flange	338	2.7	0.060
T-1-3/4	Flange	328	6.0	0.200
T-1-3/4	Flange	330	14.0	0.080
T-1-3/4	Flange	327	28.0	0.040
T-1-3/4	Flange	328AS15	6.0	0.200
T-1-3/4	Flange	327AS15	28.0	0.040
T-2	Flange	6C	6.0	0.045
T-2	Flange	12A	12.0	0.120
T-2	Flange	24A	24.0	0.035
T-2	Flange	48C	48.0	0.042
T-3-1/4	Bayonet	48	2.0	0.060
T-3-1/4	Bayonet	47	6.3	0.150
T-3-1/4	Bayonet	1816	13.0	0.330
T-3-1/4	Bayonet	313	28.0	0.170
T-3-1/4	Bayonet	1822	36.0	0.100
T-3-1/4	Bayonet	1835	55.0	0.050
S-6	Bayonet	6S6/1DC	120	0.050
S-6	Screw	6S6/3	120	0.050

GAS FILLED GLOW LAMPS

Base Type	Commercial Number	Voltage (RMS)	External Resistance Required	Watts
Wire Leads	NE-2A	115	200,000	1/25
		230	560,000	
Wire Leads	NE-2H	115	25,000	1/4
		230	90,000	
Flange	NE-2D	115	100,000	1/25
Flange	NE-2J	115	35,000	1/4
Bayonet	NE-51	115	200,000	1/25
Bayonet	NE-51H	115	25,000	1/4

Further information may be found in Collins Component Standards.

STANDARD METAL GAUGES

Gauge No.	American or B & S ¹	U.S. Standard ²	Birmingham or Stubs ³
1	.2893 inch	.28125 inch	.300 inch
2	.2576	.265625	.284
3	.2294	.25	.259
4	.2043	.234375	.238
5	.1819	.21875	.220
6	.1620	.203125	.203
7	.1443	.1875	.180
8	.1285	.171875	.165
9	.1144	.15625	.148
10	.1019	.140625	.134
11	.09074	.125	.120
12	.08081	.109375	.109
13	.07196	.09375	.095
14	.06408	.078125	.083
15	.05707	.0703125	.072
16	.05082	.0625	.065
17	.04526	.05625	.058
18	.04030	.05	.049
19	.03589	.04375	.042
20	.03196	.0375	.035
21	.0284	.034375	.032
22	.02535	.03125	.028
23	.02257	.028125	.025
24	.02010	.025	.022
25	.01790	.021875	.020
26	.01594	.01875	.018
27	.01420	.0171875	.016
28	.01264	.015625	.014
29	.01126	.0140625	.013
30	.01003	.0125	.012
31	.008928	.0109375	.010
32	.007950	.01015625	.009
33	.007080	.009375	.008
34	.006350	.00859375	.007
35	.005615	.0078125	.005
36	.005000	.00703125	.004
37	.004453	.006640626	--
38	.003965	.00625	--
39	.003531	---	--
40	.003145	---	--

¹ Used for copper, brass and nonferrous alloy sheets, wire and rods.

² Used for iron, steel, nickel and ferrous alloy sheets, wire and rods.

³ Used for seamless tubes; also, by some manufacturers for copper and brass.

OHM'S LAW AND ELECTRICAL POWER

$$1. I \text{ (amperes)} = \frac{E \text{ (volts)}}{R \text{ (ohms)}}$$

$$2. E = IR$$

$$3. R = \frac{E}{I}$$

$$4. P \text{ (power)} = \frac{E^2}{R}$$

$$5. P = I^2 R$$

NUMBERED DRILL SIZES


Number	Diameter (mils)	Will Clear Screw	Use for Tapping Iron, Steel, or Brass*
1	228.0	-	-
2	221.0	12-24	-
3	213.0	-	14-24
4	209.0	12-20	-
5	205.0	-	-
6	204.0	-	-
7	201.0	-	-
8	199.0	-	-
9	196.0	-	-
10	193.5	10-32	-
11	191.0	10-24	-
12	189.0	-	-
13	185.0	-	-
14	182.0	-	-
15	180.0	-	-
16	177.0	-	12-24
17	173.0	-	-
18	169.5	8-32	-
19	166.0	-	12-20
20	161.0	-	-
21	159.0	-	10-32
22	157.0	-	-
23	154.0	-	-
24	152.0	-	-
25	149.5	-	10-24
26	147.0	-	-
27	144.0	-	-
28	140.0	6-32	-
29	136.0	-	8-32
30	128.5	-	-
31	120.0	-	-
32	116.0	-	-
33	113.0	4-36, 4-40	-
34	111.0	-	-
35	110.0	-	6-32
36	106.5	-	-

* Use one size larger for tapping Bakelite and hard rubber.

NUMBERED DRILL SIZES (Cont)

Number	Diameter (mils)	Will Clear Screw	Use for Tapping Iron, Steel, or Brass*
37	104.0	-	-
38	101.5	-	-
39	099.5	3-48	-
40	098.0	-	-
41	096.0	-	-
42	093.5	-	4-36, 4-40
43	089.0	2-56	-
44	086.0	-	-
45	082.0	-	3-48
46	081.0	-	-
47	078.5	-	-
48	076.0	-	-
49	073.0	-	2-56
50	070.0	-	-
51	067.0	-	-
52	063.5	-	-
53	059.5	-	-
54	055.0	-	-

* Use one size larger for tapping Bakelite and hard rubber.



TIN-LEAD FUSION DIAGRAM

TYPICAL DIELECTRIC CONSTANTS AND BREAKDOWN VOLTAGES

Material	Dielectric Constant at 1 Mc	Puncture Voltage*
Air	1.0	240
Alsimag 196	5.7	300
Bakelite	4.4-5.4	325-375
Bakelite (mica-filled)	4.7	250-600
Cellulose acetate	3.3-3.9	
Fiber	5-7.5	150-180
Formica	4.6-4.9	450
Glass (window)	7.6-8	200-250
Glass (pyrex)	4.8	335
Lucite	2.5-3	480-500
Mica, ruby	5.4	3800-5600
Mica (clear India)	6.4-7.5	600-1500
Mycalex	7.4	250
Paper, royal gray	3.0	200
Polyethylene	2.3-2.4	1000
Polystyrene	2.4-2.9	500-700
Porcelain	5.1-5.9	40-100
Quartz, fused	3.8	1000
Rubber (hard)	2-3.5	450
Steatite (low-loss)	4.4	150-315
Wood (dry oak)	2.5-6.8	
Teflon	2.1	1000-2000
*In volts per mil (0.001 inch).		

This table should be used for general reference or a comparative guide only.
Specific values are determined by the applicable material specifications.

COPPER-WIRE TABLE

Wire Size AWG (B & S)	Diam in Mils	Circular Mil Area	Coil Turns per Linear Inch				Feet per Lb		Ohms per 1000 ft 25°C	Diam in mm
			Enamel (Ena)	SSC	DSC or SCC	DCC	Bare	DCC		
1	289.3	83690	-	-	-	-	3.947	-	.1264	7.348
2	257.6	66370	-	-	-	-	4.977	-	.1593	6.544
3	229.4	52640	-	-	-	-	6.276	-	.2009	5.827
4	204.3	41740	-	-	-	-	7.914	-	.2533	5.189
5	181.9	33100	-	-	-	-	9.980	-	.3195	4.621
6	162.0	26250	-	-	-	-	12.58	-	.4028	4.115
7	144.3	20820	-	-	-	-	15.87	-	.5080	3.665
8	128.5	16510	7.6	-	7.4	7.1	20.01	19.6	.6405	3.264
9	114.4	13090	8.6	-	8.2	7.8	25.23	24.6	.8077	2.906
10	101.9	10380	9.6	-	9.3	8.9	31.82	30.9	1.018	2.588
11	90.74	8234	10.7	-	10.3	9.8	40.12	38.8	1.284	2.305
12	80.81	6530	12.0	-	11.5	10.9	50.59	48.9	1.619	2.053
13	71.96	5178	13.5	-	12.8	12.0	63.80	61.5	2.042	1.828
14	64.08	4107	15.0	-	14.2	13.8	80.44	77.3	2.575	1.628
15	57.07	3257	16.8	-	15.8	14.7	101.4	97.3	3.247	1.450
16	50.82	2583	18.9	18.9	17.9	16.4	127.9	119	4.094	1.291
17	45.26	2048	21.2	21.2	19.9	18.1	161.3	150	5.163	1.150
18	40.30	1624	23.6	23.6	22.0	19.8	203.4	188	6.510	1.024
19	35.89	1288	26.4	26.4	24.4	21.8	256.5	237	8.210	.9116
20	31.96	1022	29.4	29.4	27.0	23.8	323.4	298	10.35	.8118
21	28.46	810.1	33.1	32.7	29.8	26.0	407.8	370	13.05	.7230
22	25.35	642.4	37.0	36.5	34.1	30.0	514.2	461	16.46	.6438
23	22.57	509.5	41.3	40.6	37.6	31.6	648.4	584	20.76	.5733
24	20.10	404.0	46.3	45.3	41.5	35.6	817.7	745	26.17	.5106
25	17.90	320.4	51.7	50.4	45.6	38.6	1031	903	33.00	.4547
26	15.94	254.1	58.0	55.6	50.2	41.8	1300	1118	41.62	.4049
27	14.20	201.5	64.9	61.5	55.0	45.0	1639	1422	52.48	.3606
28	12.64	159.8	72.7	68.6	60.2	48.5	2067	1759	66.17	.3211
29	11.26	126.7	81.6	74.8	65.4	51.8	2607	2207	83.44	.2859
30	10.03	100.5	90.5	83.3	71.5	55.5	3287	2534	105.2	.2546
31	8.928	79.70	101	92.0	77.5	59.2	4145	2768	132.7	.2268
32	7.950	63.21	113	101	83.6	62.6	5227	3137	167.3	.2019
33	7.080	50.13	127	110	90.3	66.3	6591	4697	211.0	.1798
34	6.305	39.75	143	120	97.0	70.0	8310	6168	266.0	.1601
35	5.615	31.52	158	132	104	73.5	10480	6737	335.0	.1426
36	5.000	25.00	175	143	111	77.0	13210	7877	423.0	.1270
37	4.453	19.83	198	154	118	80.3	16660	9309	533.4	.1131
38	3.965	15.72	224	166	126	83.6	21010	10666	672.6	.1007
39	3.531	12.47	248	181	133	86.6	26500	11907	848.1	.0897
40	3.145	9.88	282	194	140	89.7	33410	14222	1069	.0799

WEIGHTS AND MEASURES

Liquid Measure

1 (U. S.) gallon = 0.1337 cu ft = 231 cu in. = 4 qt = 8 pints

1 quart = 2 pints = 8 gills

1 British gallon = 1.2009 U. S. gallon

Avoirdupois Weight

1 pound = 16 ounces = 7000 grains

1 ounce = 16 drams = 437.5 grains

Troy Weight

1 pound = 12 ounces = 5760 grains

1 ounce = 20 pennyweights = 480 grains

1 pennyweight = 24 grains

1 carat = 3.086 grains

1 grain Troy = 1 grain Avoir = 1 grain Apothecaries

Apothecaries Weight

1 pound = 12 ounces - 5760 grains

1 ounce = 8 drams - 480 grains

1 dram = 3 scruples = 60 grains

1 scruple = 20 grains

PHYSICAL PROPERTIES OF METALS

MATERIAL	RESISTIVITY COMPARED TO COPPER	THERMAL CONDUCTIVITY	LINEAR COEFFICIENT OF EXPANSION $1/1/^{\circ}\text{C} \times 10^{-6}$
Aluminum	1.70	.504 at 18°C	23.8 (20-100°C)
Alloy 42 (Nickel-Iron)	38.40	.030 at 18°C	5.3 (25-400°C)
Alloy 52 (Nickel -Iron)	25.70	.053 at 18°C	9.5 (25-500°C)
Brass	3.57	.260 at 17°C	18.9 at 20°C
Beryllium Copper	6.00	.430 at 18°C	16.8
Cadmium	5.26	.222 at 18°C	28.8 at 20°C
Chromium	1.82	.16 at 20°C	6.8 (20-100°C)
Copper (hard-drawn)	1.12	.918 at 18°C	16.8 (25-100°C)
Copper (annealed)	1.00	.918 at 18°C	16.8 (25-100°C)
Dumet	6.7	.030 at 18°C	6.5 axially (25-400°C)
Iron (pure)	5.65	.161 at 18°C	9.07 (-190 to +17°C)

PHYSICAL PROPERTIES OF METALS (Cont)

MATERIAL	RESISTIVITY COMPARED TO COPPER	THERMAL CONDUCTIVITY	LINEAR COEFFICIENT OF EXPANSION 1/1/°C x 10 ⁻⁶
Kovar	28.4	.046 at 18°C	5.71 (20-500°C)
Lead	14.3	.083 at 18°C	29.40 (18-100°C)
Nickel	6.25-833	.142 at 18°C	12.79 at 40°C
Phosphor bronze	2.78		16.8 (0-85°C)
Silver	0.94	.974 at 18°C	18.8 at 20°C
Tin	7.70	.155 at 18°C	26.92 (20-100°C)
Zinc	3.54	.265 at 18°C	26.28 (10-100°C)

Thermal conductivity is given as the heat in calories which is transmitted per second through a plate one centimeter thick across an area of one square centimeter when temperature difference is one degree centigrade.

$$\frac{\text{cm} \times \text{cal/sec}}{\text{cm}^2 \times ^\circ\text{C}}$$

DECIMAL EQUIVALENTS OF FRACTIONS

.015625	1/64	.265625	17/64	.515625	33/64	.765625	49/64
.03125	1/32	.28125	9/32	.53125	17/32	.78125	25/32
.046875	3/64	.296875	19/64	.546875	35/64	.796875	51/64
.0625	1/16	.3125	5/16	.5625	9/16	.8125	13/16
.078125	5/64	.328125	21/64	.578125	37/64	.828125	53/64
.09375	3/32	.34375	11/32	.59375	19/32	.84375	27/32
.109375	7/64	.359375	23/64	.609375	39/64	.859375	55/64
.125	1/8	.375	3/8	.625	5/8	.875	7/8
.140625	9/64	.390625	25/64	.640625	41/64	.890625	57/64
.15625	5/32	.40625	13/32	.65625	21/32	.90625	29/32
.171875	11/64	.421875	27/64	.671875	43/64	.921875	59/64
.1875	3/16	.4375	7/16	.6875	11/16	.9375	15/16
.203125	13/64	.453125	29/64	.703125	45/64	.953125	61/64
.21875	7/32	.46875	15/32	.71875	23/32	.96875	31/32
.234375	15/64	.484375	31/64	.734375	47/64	.984375	63/64
.25	1/4	.5	1/2	.75	3/4	1.	1

FRACTIONS OF AN INCH TO MILLIMETERS

mm		mm		mm		mm	
1/64	.397	9/64	3.572	17/64	6.747	25/64	9.922
1/32	.794	5/32	3.969	9/32	7.144	13/32	10.319
3/64	1.191	11/64	4.366	19/64	7.541	27/64	10.716
1/16	1.588	3/16	4.763	5/16	7.938	7/16	11.113
5/64	1.984	13/64	5.159	21/64	8.334	29/64	11.509
3/32	2.381	7/32	5.556	11/32	8.731	15/32	11.906
7/64	2.778	15/64	5.953	23/64	9.128	31/64	12.303
1/8	3.175	1/4	6.350	3/8	9.525	1/2	12.700

**SUGGESTED MAXIMUM TORQUE VALUES FOR
FASTENERS OF DIFFERENT MATERIALS**

Bolt Size	Low Carbon Steel	18-8 St. St.	Brass	Silicon Bronze	Aluminum 24ST-4	316 St. St.	Monel
	in. -lbs.	in. -lbs.	in. -lbs.	in. -lbs.	in. -lbs.	in. -lbs.	in. -lbs.
2-56	2.2	2.5	2.0	2.3	1.4	2.6	2.5
2-64	2.7	3.0	2.5	2.8	1.7	3.2	3.1
3-48	3.5	3.9	3.2	3.6	2.1	4.0	4.0
3-56	4.0	4.4	3.6	4.1	2.4	4.6	4.5
4-40	4.7	5.2	4.3	4.8	2.9	5.5	5.3
4-48	5.9	6.6	5.4	6.1	3.6	6.9	6.7
5-40	6.9	7.7	6.3	7.1	4.2	8.1	7.8
5-44	8.5	9.4	7.7	8.7	5.1	9.8	9.6
6-32	8.7	9.6	7.9	8.9	5.3	10.1	9.8
6-40	10.9	12.1	9.9	11.2	6.6	12.7	12.3
8-32	17.8	19.8	16.2	18.4	10.8	20.7	20.2
8-36	19.8	22.0	18.0	20.4	12.0	23.0	22.4
10-24	20.8	22.8	18.6	21.2	13.8	23.8	25.9
10-32	29.7	31.7	25.9	29.3	19.2	33.1	34.9
1/4"-20	65.0	75.2	61.5	68.8	45.6	78.8	85.3
1/4"-28	90.0	94.0	77.0	87.0	57.0	99.0	106.0
5/16"-18	129	132	107	123	80	138	149
5/16"-24	139	142	116	131	86	147	160
3/8"-16	212	236	192	219	143	247	266
3/8"-24	232	259	212	240	157	271	294
7/16"-14	338	376	317	349	228	393	427
7/16"-20	361	400	327	371	242	418	451
1/2"-13	465	517	422	480	313	542	584
1/2"-20	487	541	443	502	328	565	613
9/16"-12	613	682	558	632	413	713	774
9/16"-18	668	752	615	697	456	787	855
5/8"-11	1000	1110	907	1030	715	1160	1330
5/8"-18	1140	1244	1016	1154	798	1301	1482
3/4"-10	1259	1530	1249	1416	980	1582	1832
3/4"-16	1230	1490	1220	1382	958	1558	1790
7/8"-9	1919	2328	1905	2140	1495	2430	2775
7/8"-14	1911	2318	1895	2130	1490	2420	2755
1"-8	2832	3440	2815	3185	2205	3595	4130
1"-14	2562	3110	2545	2885	1995	3250	3730
	ft. -lbs.	ft. -lbs.	ft. -lbs.	ft. -lbs.	ft. -lbs.	ft. -lbs.	ft. -lbs.
1-1/8"-7	340	413	337	383	265	432	499
1-1/8"-12	322	390	318	361	251	408	470
1-1/4"-7	432	523	428	485	336	546	627
1-1/4"-12	396	480	394	447	308	504	575
1-1/2"-6	732	888	727	822	570	930	1064
1-1/2"-12	579	703	575	651	450	732	840

This table of torque values is reprinted by courtesy of the H. M. Harper Company. The table is intended as a guide only. Tests were conducted on dry or near dry products. Mating parts were wiped clean of chips and foreign matter.

appendix B

DEFINITIONS

-A-

ADAPTER - Any device used to enable a part or wire to fit where it was not originally intended.

ADJUSTABLE RESISTOR - A resistor whose resistance can be changed mechanically, often used as an adjustable voltage divider. This is not so easily varied as a variable resistor.

AIR CAPACITOR - A capacitor whose dielectric is air.

AIR CORE - Descriptive term for coils or transformers which have no iron in their magnetic circuits, used chiefly in radio frequency circuits.

AIR GAP - A path for passage of electric current or magnetic flux through air. Examples: The air gap in a spark gap; the spaces between sections of an iron-core transformer.

AIR GAP CRYSTAL HOLDER - A device consisting of two plates for holding a piezoelectric crystal such that a small air gap exists between the top plate and the crystal.

ALTERNATING CURRENT - Electric current as usually supplied by power lines. This is usually produced by rotating machines. The usual form is sinusoidal. Current flow from zero to maximum through zero to the opposite maximum and back to zero constitutes one cycle. The number of cycles per second (cps) is the frequency. Power frequencies are of the order of 60 cps, but the term a-c is used with other frequencies, often to distinguish varying currents from d-c components.

AMBIENT TEMPERATURE - The temperature of the medium surrounding an object, e.g., the temperature of the air surrounding a transistor. The term is often used to qualify specifications given for temperature-sensitive electronic components, such as transistors, capacitors, crystals, relays, etc.

AMPLIFICATION (ELECTRONIC) - The process of increasing the current, voltage and/or power of a signal usually produced by vacuum tube or transistor circuits.

AMPLIFIER - A device used to increase power, voltage, or current of a signal.

AMPLITUDE - Term used to describe the maximum value of a periodic wave or of a component of a complex wave. It is the largest or crest value measured from zero.

AMPLITUDE MODULATION - Modulating a carrier frequency current by varying its amplitude above and below normal value in step with the audio or video frequency being transmitted. The common system of radio broadcasting. Abbreviated as AM.

ANGLE OF LAG OR LEAD - Phase angle by which quantities such as voltages or currents, may follow or precede one another in time. These relations are often shown, in the cases of voltages or currents, by plotting the sinusoidal curves along an axis of angle or time. They may also be pictured by arrows (vectors) drawn at appropriate angles and with lengths corresponding to the values of the quantities. See LAG 2.

APPROXIMATE - A term generally used to estimate a value (dimension, size, quantity, etc.), based on limited data or a gauge of limited accuracy. Close to an actual or exact value. Not to be confused with the term "nominal."

-B-

BACKLASH - A form of mechanical hysteresis in which there is a lag, lost motion or slack between the application of a driving force and the response of the driven object. For example, if the knob of a tuning mechanism must be rotated several degrees before the dial pointer begins to move, the mechanism is said to have backlash. The presence of backlash is most evident when the direction of motion is reversed. Backlash is especially serious in precision systems such as gear trains in servo mechanisms.

BAND-PASS FILTER - A filter in which a frequency band is passed and all frequencies above and below this band are attenuated.

BANDSPREAD - Any method, mechanical or electronic, of increasing space on a tuning scale between stations otherwise crowded and difficult to tune.


BANDWIDTH - A section of the frequency spectrum required to transmit the desired information, whether visual, aural, or both. The bandwidth of the average television channel is 6 mc; of a broadcast channel, 10 kc, which is 1/600 that of a television channel.

BASIC - A term used to define a size shown on the drawing. The tolerances, as specified, are measured from the basic size.

BATHTUB CAPACITOR - A capacitor enclosed in a metal can with rounded corners like a bathtub.

bel - Unit of relative audio power, named after Alexander Graham Bell, used to express differences in power amplitudes. Usually used is 1/10 bel, termed a decibel, and abbreviated db. See decibel.

BILATERAL TOLERANCE - Permissible variation from a desired dimension in both directions.



Plus and minus variations are not necessarily the same.

BLIND HOLE - A hole which penetrates only part way through a material.

BLOCK DIAGRAM - A simple line diagram in which functions, parts, subassemblies or equipments are represented by labeled (block or) blocks with the functional sequence indicated by means of arrow lines similar to flow charts.

BREADBOARD - Laboratory idiom for an experimental circuit setup exposed for ease of assembly, disassembly, and test.

BREAKDOWN VOLTAGE - The voltage at which the insulation between two conductors or parts will break down.

BROKEN CORNER OR EDGE - This term designates a definite bevel or rounding of corners and edges of parts. The size of break or rounding varies with the size of parts.

ASSEMBLY - A number of parts or subassemblies, or any combination thereof, joined together to perform a specific function. (Example: Audio Frequency Amplifier.)

Note: The distinction between an assembly and a subassembly is not always exact. An "assembly" may be called a "subassembly" when it forms a portion of an over-all assembly.

ATTENUATION - Reduction in strength as of an electrical impulse.


ATTENUATOR - A fixed or variable device (usually a type of potentiometer) which is used to reduce the amplitude of an input or output signal to or from an audio or radio frequency circuit. Attenuators are commonly used to control the output level of signal generators, to control the input level to oscilloscopes, and to control the audio level of broadcast programs.

AUDIO - Pertaining to currents or frequencies corresponding to normally audible sound waves.

AUDIO FREQUENCY - A frequency corresponding to the frequency of an audible sound wave. The extreme limits of audible frequencies vary with the individual and are from about 20 cycles to about 15,000 cycles per sound.


AUDIO FREQUENCY OSCILLATOR - A device which generates voltage, current or power at audio frequencies.

AUDIO TRANSFORMER - An iron-core transformer used to couple two audio circuits.



BUNCH STRANDING - A conductor of multiple strands, twisted together.

BURR - An undesired displacement of metal. It is usually a sharp uneven projection at the edges and corners of part.



BUS BAR - A rigid bar conductor mounted on suitable supports.


BUS (WIRE) - A short solid wire, bare or insulated.

-C-

CABLE - 1. An assembly of insulated wires protected by an outer insulating jacket. It may also have an outer braided shield. 2. A wiring harness or cable harness.

CABLE ASSEMBLY - An assembly of single or multiple insulated conductors secured together by cotton braid, shielding or other materials.

CABLE HARNESS - A cable with branches for connecting to a multiplicity of points. It may or may not be preformed but the wires are usually secured by lacing.



CALIBRATION - 1. Comparing an instrument, device, or dial with a standard to determine its accuracy. 2. Devising a scale.

CAPACITANCE - The ability of a circuit element to store an electric charge. The quantity of electric charge which can be received by a system if insulated conductors from a potential source of unit value. (The term capacity was formerly used.) A capacitor does not become filled but will receive more charge with increasing potential until breakdown occurs. Theoretical unit of capacitance is the farad. A microfarad (uf) is one one-millionth 10^{-6} of a farad. A picofarad (pf) is one-one-millionth of a microfarad or 10^{-12} farads; also micromicrofarad.

CAPACITOR-INPUT FILTER - A filter in which a capacitor across the output of the rectifier precedes an inductor or a resistor. There may be several such elements. Voltage regulation with this type of filter is not as good as when using the inductor (choke) input filter. Capacitor input filters offer the advantage of about 55% greater output voltage from a given source than inductor input filters.

CAPACITOR - An electrical part consisting of two conducting surfaces separated from each other by an insulator such as air, oil, paper, glass, mica, or ceramic material. A capacitor is capable of storing electrical energy. Capacitors are used to block the flow of direct current while allowing alternating and pulsating currents to pass.

CARBON RESISTOR - A resistor made of carbon particles and a binder, usually molded into a cylindrical shape with leads attached to opposite ends.

CARRIER FREQUENCY - The frequency of an unmodulated radio wave produced by a transmitter. A broadcast station carrier frequency must be maintained within a few cycles of the frequency assigned by the Federal Communications Commission.

CHAMFER - This term is used to describe a definite bevel on the edge or corner of a part. Its most common use is in reference to edges on circular parts, such as a chamfer on the end of a shaft. The term BEVEL is used more commonly in reference to corners and straight edges.



CHAMFER




BEVEL

CHOKER COIL - An inductor used to greatly reduce the flow of alternating current while allowing direct current to pass relatively freely. R-f choke coils have air or pulverized iron cores, while (audio frequency) a-f chokes have iron cores.

CIRCUIT - A path over which an electric current can flow when the path is complete.

CIRCUIT BREAKER - A device for opening a circuit if the current exceeds a predetermined value. It can be reset without being replaced.

CLINCHING - Term used to describe riveting with hollow point rivets (hollow point rivets and tenons are used to reduce the pressure required for single stroke riveting).



CLINCHING, (LEAD) - Bending of the lead (on the printed side of a board) to mechanically secure the part (to the board).

COAXIAL CABLE (COAX) - A solid or stranded conductor along the axis of a larger hollow conductor such as a braided shield or metal tube, with insulation between the two conductors.


COIL - A number of turns of wire wound on an iron core, on a form made of insulating material, or by means of a mandrel so as to be self-supporting. A coil offers opposition to the passage of alternating current but little opposition to direct current.

COIL FORM - The tubing or solid object on which a coil is wound. Cardboard, fiber, or a plastic or ceramic materials are commonly used.

COILWINDER - A manually operated or power-driven mechanism for winding coils (used in radio and other electronic applications).

COLOR CODE - A system of colors used to identify the electrical value of a radio part or distinguish terminals or leads.

COMPONENT PART HOLDER - Clip, restraining wire or strap used to secure the part to a mounting surface.



CONCENTRIC-LAY CABLE - A multiple conductor cable composed of a central core surrounded by one or more layers of helically laid insulated conductors, successive layers being applied in opposite directions.

CONCENTRIC-LAY STRANDING - A stranded conductor composed of a central strand surrounded by one or more layers of helically laid strands.

CONDUCTANCE - A measure of ability to conduct electricity. In d-c circuits it is the reciprocal of resistance. In a-c circuits it is more strictly the resistance divided by the square of the impedance. Conductance is expressed in mhos. The symbol is G.

CONDUCTOR - 1. A wire or combination of wires that form a single electrical path.
2. That which offers little opposition to continuous current.


CONNECTION DIAGRAM - Wiring diagram.

CONNECTOR - A fitting used to join wires temporarily in an electrical circuit.

CORD - 1. A small flexible cable with insulation that will withstand wear. 2. A string.

CORES - Sand, plaster, or metal shapes placed in a mold to produce contours, recesses, cavities, openings, etc., in the cast or molded parts.

COUNTERBORE - A flat bottomed cylindrical enlargement from the mouth of a round hole to a given depth. Its center line coincides with that of the hole. (Should not be confused with spot-face.)



CRYSTAL - 1. A piece of natural quartz or similar piezoelectric material which has been ground to the proper size to produce natural vibrations at a desired radio frequency when set into vibration. A quartz crystal is used in radio transmitters to generate with a high degree of accuracy the assigned carrier frequency of a station and is used in crystal filters of radio receivers to improve the selectivity of the i-f amplifier.
2. The mineral used in a crystal detector.

CRYSTAL FILTER - A highly selective tuning circuit using a quartz crystal, sometimes used in the i-f amplifier of a communications receiver to improve selectivity so as to permit reception of a desired station even when there would otherwise be interference from stations of nearly the same frequency.

CURRENT - A movement of electrons through a conductor. Current is measured in amperes, in milliamperes and microamperes.

CUTOFF FREQUENCY - That frequency in a filter or other system at which most, if not all of the signal is attenuated.

-D-

db - Abbreviation for decibel.

db METER - A meter having a scale calibrated to read directly in decibel at a predetermined level and used to indicate volume levels.

DECIBEL - Unit of relative power, voltage or current. In electroacoustics, since the response of the ear is logarithmic (detectable change increases with level), the number of bels is defined as the logarithm of the ratio of the power level in question to that of the reference value. Since perhaps a tenth of this difference could be detected by the ear, a unit one-tenth as large is used: the decibel. The number of decibels is $10 \log P_2/P_1$ or $20 \log E_2/E_1$ or $20 \log I_2/I_1$.

DELAMINATION - Separation of layers as in the base material of a nonmetallic board.

DIELECTRIC - The insulating material between the plates of a capacitor, adjacent wires in a cable, or any two parts of an electronic circuit: generally air, mica, paper, plastics, oil, cloth, glass, or ceramic material.

DIELECTRIC CONSTANT - The relative permittivity of a dielectric material as compared to vacuum. It is measured by determining how many times greater the capacitance of a capacitor is with the dielectric between the plates than with air. Transformer oil has a dielectric constant of about 2; mica, of 5-6.

DIELECTRIC STRENGTH - Strength measured by the maximum voltage that a dielectric can withstand without breakdown (rupture). Also called insulating strength. Expressed in volts per mm, the dielectric strength of air is about 3,000, oil 16,000 and mica 50,000. May be stated in kilovolts per inch.

DIODE - A component having two electrodes, the cathode and the plate or anode, which allows more electrons to pass in one direction, from the cathode to the anode.

DISTORTION - Unfaithful reproduction of audio or video signals due to changes occurring in the wave form of the original signal, somewhere in the course it takes through the transmitting and receiving system. Classified as nonlinear (amplitude), frequency, and phase distortion.


DISTRIBUTED CAPACITANCE - Capacitance distributed between wires, between parts, between conducting elements themselves, or between the elements and ground, as distinguished from capacitance concentrated or lumped in a capacitor; usually applied to the capacitance between the turns of a coil.

DISTRIBUTED INDUCTANCE - The inductance that exists along the length of a conductor, as distinguished from inductance concentrated or lumped in a coil.

DRAFT - A relief slope or taper to facilitate the removal of the pattern from the mold.



DRIVING - Operation performed with solid rivets or tenons. (The tool has a hemispherical or similar depression to form the desired shape. High pressures are required for this operation.)



DUPLEX CABLE - Two insulated stranded conductors twisted together with a common insulating covering.

DUTCH BEND - A 180° bend (see illustration below).



-E-

ECCENTRICITY - The distance between centers of parts intended to be concentric.

ELECTRONICS - A broad term used to cover a field which deals with the use, characteristics, and properties of electrons, especially in vacuum or gas filled tubes or in semiconductors. For example, Radio, TV, Radar, control circuits.

EQUIPMENT GROUP - A collection of parts or assemblies which is a subdivision of a system but which is not capable of performing a complete operational function. (Example: Antenna Group, Indicator Group.)

EQUIVALENT - This term indicates mechanical as well as electrical interchangeability.

-F-

FACE RUNOUT - Deviation from squareness of face with respect to the axis of a turned part.

FARAD - Unit of capacitance. In the practical system of units the farad is too large for ordinary use, and capacity measurements are made in terms of microfarads and picofarads. Both are commonly used in radio. See capacitance.

FIELD COIL - An insulated winding energized by direct current, and mounted on a field pole so as to magnetize it.

FILTER CAPACITOR - A capacitor used in a filter system to provide a low-reactance path for alternating currents.

FILTER CHOKE - An iron-core used in a filter system to pass steady direct current while offering high impedance to current pulsations or alternating currents.

FIXED CAPACITOR - A capacitor having a definite value that cannot be varied.

FIXED RESISTOR - A resistor having a definite value that cannot be varied.

FLASH - Excess material (metal, pressed powder or molding compound) left on the die casting or molding, at the parting line, resulting from leakage of material into vents and between mating die or mold surfaces.

FLAWS - Such defects as cracks, blowholes, checks, ridges, or scratches.

FLUX - 1. A material used to promote joining of metals in soldering or welding. Rosin is widely used as a flux in electronic soldering. 2. All the electric or magnetic lines of force in a region.

FREQUENCY - The number of complete cycles or vibrations per unit of time, usually per second. Frequency of a wave is equal to the velocity divided by the wavelength.

FREQUENCY BAND - A range of frequencies between two limiting frequencies.

FREQUENCY RESPONSE - The manner in which a circuit or device handles the different frequencies falling within its range. Thus, the frequency response of a high-fidelity amplifier may be specified as essentially flat or uniform between 20 and 20,000 cycles per second.


FREQUENCY-RESPONSE CURVE - A graph showing the frequency response of a radio or audio part, circuit, or system.

FUSE - A protective device containing a short piece of wire which melts and breaks when the current through it exceeds the rated value. Fuses are used to open the circuits automatically in case of serious overload, thereby preventing damage.

FUSE WIRE - Wire made from an alloy that melts at a relatively low temperature.

-G-

GRIND FLUSH - Term indicating an extra smoothing operation after riveting. This operation is performed only where a countersink is provided to nest the material at the riveted end.



GRINDING - Process of dressing, shaping or finishing surfaces by means of a rotating abrasive wheel. (This is accomplished by feeding the work against the revolving wheel or by feeding the revolving wheel against the work.)

GROUND - 1. A large conducting body such as the earth or a chassis. 2. A connection, intentional or accidental, between an electric circuit and ground. (def 1).

GROUND POTENTIAL - The potential of the chassis ground or earth. The chassis ground should be zero, as a safety measure.

GROUND WIRE - A conductor leading from electrical equipment or a part to a low resistance electrical connection with the earth or a vehicle frame.

-H-

HARMONIC - A frequency of sinusoidal wave, or alternating current that is an integral multiple of the fundamental frequency which may be called the first harmonic.

HEAT LOSS - Energy dissipated as heat.

HEAT SINK - Any device that absorbs and draws off heat from a hot object, radiating it into the surrounding atmosphere. Examples of heat sinks are metal radiators placed around tubes and semiconductors to permit them to operate at temperatures much higher than would ordinarily be possible, and metal clamps placed on the leads of components that are easily damaged by heat while being soldered into a circuit.

HERMETICALLY SEALED - Sealed so as to be airtight.

HIGH Q - Having a high ratio of reactance to effective resistance. The Q expresses coil efficiency.

HIGH-RESISTANCE VOLTMETER - A voltmeter having a resistance of 10,000 ohms per volt or higher, so that it draws little current from the circuit in which a measurement is made.

HONEYCOMB WINDING - A special type of coil winding, so designed as to keep distributed capacity at a minimum. Also called lattice winding. The winding resembles a basket-weave pattern.

HOT - Connected, alive, energized. Said of a wire, terminal, or any conductor having an appreciable voltage.

IMPEDANCE - The opposition that a circuit offers to the flow of alternating current or any other current variation at a particular frequency. Impedance, symbol Z , is a combination of resistance and reactance. The ohm is the unit of impedance.

IMPREGNATED - Having spaces filled with a dielectric such as paraffin, shellac, or varnish.

INDUCTANCE - That property of a coil or other wire which tends to prevent a change in current. Inductance is effective only on varying or alternating currents; it has no effect upon the steady flow of direct current. Inductance is measured in henrys.

INDUCTOR - A part with inductance as its important property. A coil.

IN PHASE - The condition existing when waves or current variations pass through their maximum and minimum values of like polarity simultaneously.

INPUT - 1. The current, voltage, or power that is fed into a circuit or device. 2. The terminals to which the incoming signal voltage is applied.

INPUT CAPACITANCE - The total capacitance at input terminals, as between the control grid and the cathode of a vacuum-tube circuit.

INPUT IMPEDANCE - The ratio between voltage and current at input terminals. Usually a coupling network is between the source and the load for optimum power transfer. Maximum power transfer is obtained with equal source and load or input impedances.

INSERTION LOSS - The ratio (expressed in decibels) of the power delivered before, to the power delivered after, the insertion of an apparatus in a transmission system.

INSULATED WIRE - An electric wire covered with a nonconducting material.

INSULATING STRENGTH - A measure of the ability of an insulating material to withstand electric stress without breakdown. Also called electric strength and dielectric strength.

INSULATION - A nonconductive material used to prevent shorting or leakage of electricity from or to a conductor. It may be plastic, rubber, glass, mica, ceramic, etc.

INSULATION RESISTANCE - The electric resistance of an insulating material.

INSULATOR - A device having high resistance, used for supporting or separating conductors so as to prevent undesired flow of current between conductors or to persons.

INTERCONNECTION DIAGRAM - A diagram of wire, cable or conduit connections between units of an over-all installation by means of labeled blocks which indicate separate units. Delineation of points of connection may be made at edge of the blocks.

-J-

JACK - A stationary receptacle usually providing for 1, 2 or 3 temporary connections, often associated with telephone equipment.

JUMPER - A short length of conductor used to make an electrical connection.

JUNCTION - 1. A point in a circuit where two or more wires are connected. 2. A point in an electrical network at which three or more conductors meet.

-K-

KILO - Metric prefix meaning 1000.

KILOCYCLE - One thousand cycles. Abbreviated kc. Also one thousand cycles per second.

KILOHM - Unit of resistance, equal to 1000 ohms.

KNURLS - Small protuberances in the form of ridges or beads on a cylindrical surface. (General purpose of knurling is to provide an extra grip on the surface. Also used for decorative purposes.)

-L-

LAG - 1. A delay in the recording or indicating of any device with respect to the conditions being measured or reproduced. 2. Of two alternating electrical quantities of the same frequency, the one that reaches a particular cyclic point later lags the others.

LAMINATED - A type of construction widely used for the cores of iron core transformers, choke coils, electromagnets, motors and generators. It involves building up the desired thickness and shape of core with thin strips of a magnetic materials such as soft iron or silicon steel.

LAMINATED CORE - An iron core for a coil, transformer, armature, etc., built up from laminations of iron or steel.

LAMINATION - A single sheet of material used in making a laminated object, such as a transformer core or printed circuit board.

LAY - A term used to describe the amount of advance of any point in a strand for one complete turn in a stranded conductor. (The looser the twist, the greater the strength and flexibility.)


LEAD - A lead is a bare or insulated wire conductor, stranded or solid, which is a part of a component part, and used for making a connection.

LEAD-COVERED WIRE - One or more solid or stranded insulated wires with an over-all sheathing of extruded lead.

LEAKAGE RESISTANCE - The resistance of the path over which leakage current flows. It is normally a high value, as between electrodes in a vacuum tube.

LEAKY - A condition in which the resistance has dropped so much below its normal value that excessive leakage current flows. A common capacitor defect.

LIMITS - The minimum and maximum permissible dimensions of a part, considering the tolerance.



LITZ WIRE - A group of fine wires individually coated with thin insulation, braided or twisted, to reduce radio-frequency resistance; the braided or twisted conductors are covered with an over-all insulation to maintain the cross-sectional shape and furnish mechanical protection during winding.

LOSS - Energy dissipated without accomplished useful work.

LOW CAPACITANCE (COAX) CABLE - A solid or stranded inner conductor shielded cable, usually designed to a specific capacitance, with the inner conductor running through the axis of the shielding with a low dielectric insulation between the two conductors.

LUG - 1. A small strip of metal held by a screw or riveted to an insulating material to provide a convenient means for making a soldered wire connection. 2. An earlike projection.

-M-

ma - Abbreviation for milliamperere.

MACHINE FINISH - Indicates a surface produced by machine tools. Does not refer to a surface produced by casting, drawing or rolling operations.

MAGNET - A body which attracts iron and steel, and if free to rotate, sets itself in a definite direction due to the influence of the earth's magnetic field.

MASKING - Protection of certain areas from finish or coating applications by means of a covering.

MEGA - Prefix denoting one million.

MEGACYCLE - One million cycles per second, abbreviated mc.

MEGGER - A high-range ohmmeter having a built-in hand-driven generator as a direct-voltage source, used for measuring insulation resistance.

MEGOHM - One million ohms. Abbreviated meg.

mfd - Older abbreviation for microfarad. Usually written uf.

mh - Abbreviation for millihenry.

MICA - A transparent flaky mineral which splits readily into thin sheets and has excellent insulating and heat-resisting qualities. It is used extensively to separate the plates of capacitors, to insulate electrode elements of vacuum tubes, and for many other insulating purposes in radio.

MICA CAPACITOR - A type of fixed capacitor with mica as the dielectric material.

MICRO - A prefix meaning one millionth of. Often designated by the Greek letter μ (mu) in abbreviations.

MICROVOLT - One millionth of a volt.

MILLI - A prefix meaning one thousandth of.

MILLING - A machine operation whereby metal is removed by a revolving cutter.

MOLDED CAPACITOR - A capacitor encased in a molded plastic material to keep out moisture and insulate.

MULTIMETER - A test instrument having a number of different ranges for measuring voltage, current, and resistance. Multitester. Volt-ohm-milliammeters are typical.

MULTIPLE CONDUCTOR CABLE - A combination of insulated conductors with or without a common insulating covering.

-N-

NEGATIVE - A term used to describe the terminal of a pair which has more electrons. Electrons flow out of the negative terminal of a voltage source.

NETWORK - 1. A system of interconnected resistors, inductors, and capacitors, or any combination thereof. Common networks are in the form of a bridge, a Δ , an O, a Y, a T, or a π . 2. A number of broadcasting stations connected by radio, telephone lines, coaxial cable or radio relay. It enables all stations to broadcast the same program simultaneously.

NOISE - Undesirable random voltages caused by an internal circuit part or from some external source. In television, this type of interference results in a multitude of black and white spots distributed over the entire picture. It is often called "snow." In radio receivers, noise appears as an audible hissing sound, especially between stations.

NOMINAL - A term used to define a value (size, dimension, etc.) for purpose of general identification.

NONCONDUCTOR - An insulating material.

"NONCORROSIVE" FLUX - Flux that is relatively free from acid and other substances which might cause corrosion in soldering.

NONLINEAR - Not directly proportional and hence producing a curve instead of a straight line when plotted on a graph.

NONMAGNETIC - Not affected by magnetic fields. Some nonmagnetic materials are glass, wood, copper, and paper.

NORTH POLE - That pole of a magnet at which magnetic lines of force are considered as leaving the magnet; the lines enter the south pole. If the magnet is free to rotate, its north pole will point south.

NULL - Zero; insignificant.

NULL INDICATOR - Any device that indicates when a quantity such as current, voltage, or power is zero or a minimum.

-O-

OHM - The practical unit of electrical resistance. It is the resistance in which one volt will maintain a current of one ampere.

OHMMETER - An instrument for measuring resistance. It consists essentially of a milliammeter in series with a d-c voltage and suitable series resistors.

OHMS-PER-VOLT - A rating for voltage-measuring instruments, obtained by dividing the resistance of the instrument in ohms at a particular range by the full-scale voltage value at that range. The higher the ohms-per-volt rating, the less the meter lowers the voltage being measured.

OPEN CIRCUIT - An incomplete circuit. Current does not flow in an open circuit.

OPEN CORE - An iron core fitting inside a coil but having no iron for the external return path, so that the magnetic circuit has a long path through air.

OPPOSITE HAND - A mirror image of the view or object shown; that is, the object is reversed from "left to right" or vice versa.

OSCILLOSCOPE - A voltmeter/ammeter which reproduces, on the screen of its cathode-ray tube, traces of the waveforms of one or more varying quantities.

OUT OF PHASE - Having waveforms that are of the same frequency but not passing through corresponding values at the same instants.

OUTPUT - 1. Useful energy/voltage delivered. 2. The terminals from which output may be taken.

-P-

PADDER - 1. In a superheterodyne receiver, the capacitor placed in series with the oscillator tuning circuit to control the receiver calibration at the low-frequency end of a tuning range. 2. Any physically small capacitor inserted in series with a main capacitor to adjust its capacity to some predetermined value.


PAPER CAPACITOR - A fixed capacitor consisting of interleaved strips of metal foil separated by an oiled or waxed paper dielectric.

PART - One piece, or two or more pieces joined together which are not normally subject to disassembly without destruction of designed use. (Examples: Tubelet, Electron Tube, Composition Resistor, Mica Capacitor, Audio Transformer.)

PATCH CORD - A flexible conductor cable used for a temporary connection.

PEAK - The maximum instantaneous value of a quantity.

PEENING - Riveting operation performed with a hammer (or by multiple blow riveting with same type of tool used for "driving") to form a head without controlled shape. 2. Hammering around a hole (prohibited for signed assemblies.)



PICO - Prefix denoting a millionth of a millionth; micromicro.

PIGTAIL - A flexible metallic connection usually consisting of braided wire used between a stationary terminal and a portion of a circuit having a limited range of motion.

PLUG - Portion of a connector pair which is attached to a cable or cord.

POLARITY - 1. An electrical condition determining the direction in which current tends to flow. Applied to direct current sources; also to components when connected in d-c circuits. 2. The quality of having two opposite charges, one positive and the other negative. 3. The quality of having two opposite magnetic poles, one north and one south.


POSITIVE - A term used to describe a terminal having fewer electrons than the negative terminal, so that it attracts electrons in seeking to return to its uncharged state. Thus, electrons flow into the positive terminal of a voltage source.

POTENTIAL - Voltage between any two conductors or parts. The work per unit charge required to bring charge to the point at which the potential exists.

POTENTIAL SHORT - A defect which may contribute to an unintentional short circuit, but which is not detected by normal electrical testing.

POWER CORD - A flexible multiple conductor cable used for attaching equipment to a power supply. The cord is furnished with an attachment plug for insertion in a service outlet.

PRESS - The act of assembling tightly fitting parts with a designed interference.



NOTE:
PRESS ITEM A INTO ITEM B

PRESS FIT (Also called FORCE or INTERFERENCE fit) - Term indicates that force is required to assemble parts. The parts may be driven together, forced with a press, or shrunk together and are considered permanently assembled.

PRIMARY - 1. First in order of time, development or importance. 2. The transformer winding which receives the energy from a supply circuit. Sometimes called the input coil or winding.

PRIMARY VOLTAGE - The voltage applied to the input terminals of a transformer.

PRIMARY WINDING - The input winding of a transformer.


-R-

RANGE - 1. Extent of coverage or effectiveness. 2. Distance over which a radio system can operate.

REACTANCE - Opposition offered to the flow of alternating current by inductance or capacitance of a component or circuit. An inductor having an inductance L (henrys) has an inductive reactance ωL (angular velocity times inductance). The unit is ohms. The value increased with frequency. A capacitor having a capacitance C (farads) has a capacitive reactance $1/\omega C$ (reciprocal of angular velocity times capacitance). This is also in ohms. The value decreases with increasing frequency. Reactance is designated by X . Its reciprocal is susceptance, B .

RECEPTACLE - Portion of a connector pair attached to the equipment. A socket.

REFERENCE DIMENSION - A duplicated dimension or a dimension not strictly essential in fabricating or inspecting the part, but has an important reference value. Such dimensions are usually suffixed with the letters REF in parentheses.



REFERENCE LEVEL - The starting or zero point from which a scale is laid out or from which measurements are made. For example, the common reference point (level) in decibels (db) is 0.006 watt; in volume units (VU's) it is 0.001 watt.

REGISTRATION (PRINTED CIRCUIT) - Matching in position of printed wiring patterns on opposite sides of a printed board; or positioning of a pattern with respect to the details on the opposite side.

RESISTANCE (ELEC) - The nonreactive opposition which a device or material offers to the flow of direct or alternating current. The opposition results in production of heat in the material carrying the current. Resistance is measured in ohms, and may be designated by the letter R .


RESISTOR - A part which is intended to offer resistance to the flow of electric current. Its electrical size is specified in ohms or megohms (one megohm equals 1,000,000 ohms). A resistor also has a power-handling rating in watts, indicating the amount of power which can safely be dissipated as heat by the resistor.

RESISTOR CORE - The support on which a wire-wound resistor element is wound.

RHEOSTAT - A current-regulating resistor whose value may be changed by means of a control knob. One fixed and one movable terminal are used, or, usually in the larger sizes, only these two terminals are provided.

RIPPLE - The alternating-current component present in the output of a direct-current generator, rectifier system or other d-c power supply.

RIVETING - Assembling by use of rivets. Methods of riveting in common use: single squeeze or blow, and multiple blows.



RIVET OVER - Operation of forming the riveted or second head by means of squeezing or forming with hammer blows.

ROLL-OFF - A controlled attenuation (de-emphasis) of frequencies in a high-fidelity amplifier or preamplifier. Roll-off compensates for the emphasis of frequencies when phonograph records are made. Emphasis gives the recording a better signal-to-noise ratio, while roll-off helps restore correct tonal balance when the record is played.

ROLL OVER - Term applied to the assembly of eyelets, hollow point rivets and tenons by curling over the tubular extending section of metal by either clinching or spinning.

ROPE-LAY CABLE - An extremely flexible cable composed of groups of strands made up into a complete cable using concentric lay construction.

ROPE-LAY STRANDING - A flexible stranded conductor composed of a central core of stranded wires surrounded by one or more layers of helically laid groups of stranded wires.

ROSIN-CORE SOLDER - Solder made up in tubular form, with the inner space containing rosin flux for effective soldering.

RUNNING FIT (PRECISION) - This fit has a smaller minimum clearance than the Running Fit (Production), but allows a thin film of lubricant. It is suitable for shafts revolving under 600 rpm and at pressures less than 600 lb per sq in.

RUNNING FIT (PRODUCTION) - Term used where the minimum clearance between the hole and the shaft is such that it will permit free assembly and the tolerances are large enough to permit economical manufacturing.

RUNOUT - Two times the eccentricity. (See Eccentricity and Face Runout.)

SATURABLE REACTOR - A device consisting of a d-c winding and an a-c winding on the same core. The d-c winding is used to vary the core saturation and thus controls the reactance and impedance to current in the a-c winding.

SATURATION - 1. The condition existing in a tube when thermionic or photoelectric current is the maximum that can be obtained by increasing the anode voltage. Or, in the thermionic case, by increasing the temperature of the cathode. 2. The condition existing in a magnetic material when the flux density is the maximum that can be obtained by increasing the magnetomotive force. In color TV, freedom of a color from white. Vivid or strong colors are highly saturated while pastel shades are of low saturation.

SCHEMATIC DIAGRAM - A line diagram using graphic symbols to show the functional operation or diagrammatic scheme of an electrical circuit, part, subassembly, assembly, etc.

SELECTIVE - Responding to a desired frequency to a greater degree than to other frequencies.

SELECTIVITY - The characteristic which determines the ability of a radio receiver to reject undesired untuned signals.

SELECTOR - A device, mechanical, electronic, or electrical, for making connection to any of a number of circuits at will.

SENSITIVITY - 1. Characteristic of an electronic circuit which determines the minimum input signal strength required for a given signal output value. 2. The displacement (generally measured in inches) of the luminous spot on the screen of a cathode-ray tube, per volt applied to deflecting plates or per ampere of current through a deflecting coil.

SERIES - An arrangement of parts in a circuit, connecting them end to end to provide a single path for current flow.

SERIES RESONANT CIRCUIT - A circuit in which an inductor and capacitor are connected in series, and have values such that the inductive reactance of the inductor will be equal to the capacitive reactance of the capacitor at the resonant frequency. At resonance, the current through a series resonant circuit is a maximum.

SERVICE LOOP - A length of wire in excess of that required for a single connection.

SHEARING - Cutting as with scissors rather than with a beveled cutter. One blade can be stationary. The material being cut moves in the direction of the moving blade or blades.

SHIELDED WIRE - One or more insulated wires covered with shielding (usually braided wire), with or without an outer insulating covering.

SHIELDING - Metal covering used on a cable; also a metal can, case, partition, or plates enclosing an electronic circuit or component. Shielding is used to prevent undesirable radiation or pickup of signals (magnetic induction, stray current, or a-c hum).

SHORT (CIRCUIT) - A low-resistance connection across a voltage source or between the sides of a circuit or line; usually accidental and usually resulting in excessive current flow which often causes damage.

SHORTED OUT - Made inactive by connecting a wire or other low-resistance path around a device or portion of a circuit.

SHUNT - 1. A precision low-value resistor placed across the terminals of an ammeter to increase its range by allowing a definite fraction of the circuit current to go around the meter. 2. Any part connected in parallel with some other part.

SIDEBANDS - Two bands of frequencies, one on either side of the carrier frequency of a modulated radio signal, including components whose frequencies are, respectively, the sum and difference of the carrier and the modulation frequencies.

SIGNAL GENERATOR - A test instrument that generates an unmodulated or tone-modulated radio-frequency signal at any frequency needed for aligning or servicing electronic equipment.

SIMILARITY - Quality of being nearly alike, but not alike in all respects.

SINE WAVE - Waveform corresponding to harmonic motion. If amplitude is plotted against angle (or time, which is in proportion to angle) the curve is a sine function. From 0° to 90° (one quarter period) the amplitude increases as the sine of the angle. From 90° to 180° it decreases symmetrically with the increase, completing an arch (of one half period). During the interval 180° to 360° (the other half period), the arch is inverted and repeated in a trough. The periods or cycles then repeat.

SLEEVE - 1. The cylindrical metal contacting part back of the tip/ring in a telephone or radio type plug. 2. A tubular part such as a simple bearing or insulating tubing.

SNAGGING - Rough cutting and grinding operation employed to remove gates, risers, fins, flash, etc.

SNUG FIT - This fit has zero minimum clearance between the shaft and the hole, but parts can be assembled without the use of tools. This fit is not suitable for moving parts.

SOLDER - An alloy of lead and tin which melts at a fairly low temperature (361° - 496° F) and is used for making permanent electrical connections between parts and wires. Silver solder, which has a much higher melting point, is composed of silver, copper and zinc.

SOLDERING IRON - A device used to apply heat to a joint which is to be made permanent by soldering.

SOLID CONDUCTOR - A solid wire. A metallic conductor that is not composed of strands.


SOLID WIRE - A slender, generally flexible rod or filament of drawn metal, not stranded.

SOURCE - The supply, or the part which is supplying electrical energy or radio signals to a circuit.

SPAGHETTI - Heavily varnished cloth tubing sometimes used to provide insulation for radio circuit wiring.

SPARKOVER - Breakdown of the air between two electrodes producing a spark.

SPINNING - Assembly accomplished by using a rotating tool (often equipped with rolls) which causes a small section of the metal ahead of the tool to flow.




SPLICE - A connection of two or more wires not connected to a terminal or to shielding.

SPOT-FACE - A machining operation which removes irregularities and creates a smooth surface perpendicular to the axis of the hole. The area is machined sufficiently to provide a seating surface for bolts, nuts, washers and other mating parts. In all cases, the spot-facing tool should cut below the irregular surface.



STAKING - An assembly operation performed with various shapes of dull punches which cause sideward distortion of a tenon or of metal around a hole. Securing a fastener with solder is called solder staking.



STAKING, LIQUID - Securing a fastener with a friction-increasing liquid.

STATIC - Noise heard in a radio receiver due to atmospheric electrical disturbances such as lightning, or man-made causes such as electric motors, neon signs, electric shavers or other appliances which produce sparking in operation.

STEP-DOWN TRANSFORMER - A transformer in which the secondary winding has fewer turns than the primary, so that the secondary delivers a lower voltage than is applied to the primary. Current is greater in the secondary than in the primary.

STEP-UP TRANSFORMER - A transformer in which the secondary winding has more turns than the primary, so that the secondary delivers a higher voltage than is applied to the primary. Current is less in the secondary than in the primary.

STRAND - One of the wires, or group of wires, of stranded conductor.

STRANDED CONDUCTOR - A conductor composed of strands, or of any combination of strands, twisted (or braided) together.

STRANDED WIRE - A flexible conductor composed of a group of bare wires or of any combination of groups of bare wires twisted together. The entire wire is usually insulated.

STRAY CAPACITANCE - Capacitance existing between circuit wires and/or parts including the metal chassis of electronic apparatus.

SUBASSEMBLY - Two or more parts which form a portion of an assembly or a unit, replaceable as a whole (having a part or parts which are individually replaceable. (Examples: I-F Strip; Terminal Board with mounted parts).

SUPPLY - Source of voltage, current and/or power.

SURFACE ROUGHNESS - Closely spaced deviations from flatness of a surface, such as those produced in machine finished surfaces by the cutting action of tool edges or abrasive grains.

SYSTEM (Electrical & Electronic) - A combination of assemblies and parts usually physically separated in operation, necessary to perform an operational function. (Example: Fire Control System).

-T-

TERMINAL - An electrically conductive item such as is attached to the end of a wire or to terminal board for convenience in making reliable electrical connections.

TERMINAL BOARD - An insulating strip or board on which screws, solder lugs, or other electrical connecting items are fastened and used for junctions or terminations of wires and cable assemblies.

TEST LEAD - A flexible insulated lead, usually with a test prod at one end, for making tests or connecting instruments to a circuit temporarily.


TEST OSCILLATOR - A test instrument that will generate an unmodulated or tone-modulated radio-frequency signal at any desired frequency for aligning or servicing electronic equipment. Also called a signal generator.

TINNED WIRE - Copper wire that has been coated with a layer of tin or solder to simplify soldering and prevent corrosion.

TIP - The contact at the end of a telephone-type plug.

TIP JACK - A small single-hole jack into which a single pin contact plug is inserted to make an electrical connection.

TOLERANCE - Permissible variation from the desired dimension.



TOROID - A ring. A doughnut-shaped coil such as would be formed by bringing together the ends of an ordinary coil.

TRANSDUCER - 1. Generally, a device which converts energy from one form into another, always retaining the characteristic amplitude variations of the energy being converted. Examples: A microphone, which converts acoustical energy into electrical energy; a loud-speaker, which does the reverse; a photocell, which converts light energy into electrical energy; a phonograph pickup, which converts mechanical energy into electrical energy.

TRANSFORMER - An electrical device, without moving parts, that transfers electrical energy by electromagnetic induction from one or more circuits to one or more other circuits. May be used to step up or down voltage. Does not affect frequency. All the energy is transferred except for small copper wire and core losses. Consists essentially of one coil or two or more coils inductively coupled. For power or audio transformers, iron cores are used. In r-f either air or powdered iron cores are employed.

TRANSMISSION LINE, R-F- Means of transferring r-f energy from a source to a load in an efficient manner. It may consist of parallel wires properly spaced and terminated to match the source to a load. It may consist of parallel wires properly spaced and terminated to match the source impedance. It may be an arrangement of coaxial conductors or a wave guide system similarly terminated.

TRANSIENT - A temporary current or voltage existing in a circuit due to a changed load, different source voltage, or line impulse.

TRIMMER CAPACITOR - A small semiadjustable capacitor, usually adjusted with a screw-driver, and used in the tuning circuits of radio receivers and other radio apparatus. It permits fine adjustment of capacity of the tuned circuit for accurate alignment.

TRIPLEX CABLE - Three insulated stranded conductors twisted together with a common insulating covering.

TUBE VOLTMETER - A vacuum-tube voltmeter. See vacuum-tube voltmeter.

TUBULAR - Having the form of a cylinder, as a component with leads projecting axially from one or both ends.

TUNED FILTER - An arrangement of electronic components tuned either to greatly reduce or pass signals at its resonant frequency.

TUNING - 1. Adjusting the inductance or capacitance (or both) in a coil-capacitor circuit.
2. Adjusting all circuits in electronic equipment for best performance.

TUNING COIL - A variable inductor.

TUNING CAPACITOR - A variable capacitor.

TWIN-AXIAL CABLE - Same as Coaxial Cable, except there are two parallel conductors in a common shield.


TWIN CABLE - Two insulated solid or stranded conductors laid parallel with a common insulating covering.

TWISTED PAIR - Two insulated conductors twisted together either with or without a common covering.

-U-

uf - Abbreviation for microfarad. Formerly written mfd.

UNILATERAL TOLERANCE - Permissible variation from the desired dimension in one direction only.



UNIT - An assembly or any combination of parts, subassemblies, and assemblies mounted together, normally capable of independent operations in a variety of situations (Example: Radio Receiver).

-V-

v - Abbreviation for volt.

va - Abbreviation for volt-ampere.

VACUUM-TUBE VOLTMETER - A test instrument for measuring voltages which takes advantage of the high input impedance of a vacuum tube to minimize the effect on the circuit to which the instrument is connected. Abbreviated vtvm.

VARIABLE CAPACITOR - A capacitor whose capacity may be changed either by varying the space between plates (as in a trimmer capacitor) or by varying the amount of meshing between the two sets of plates (as in a tuning capacitor).

VARIABLE RESISTANCE - A resistor having a sliding contact so that its resistance value can be readily changed.

VARIABLE TRANSFORMER - A transformer, the output voltage of which can be varied continuously.

VERNIER - An auxiliary scale of slightly smaller divisions than a main measuring scale, by means of which measurements may be made with greater precision than allowed by the main scale alone. Thus any device, control, or scale used to obtain fine adjustment or more accurate measurement.

VERNIER CAPACITOR - A small variable capacitor shunt-connected with a larger tuning capacitor to provide a finer adjustment than the larger capacitor.

VOLT - The unit of voltage, potential or electromotive force. One volt is the electromotive force which will send one ampere through a resistance of one ohm.

VOLTAGE - The electrical pressure that makes current flow through a conductor. Same as electromotive force.

VOLTAGE GAIN - Voltage amplification. A rating of an amplifier stage obtained by dividing the a-c output voltage by the a-c input voltage. It is less than the amplification factor of the tube. As the external impedance becomes larger in comparison to the plate impedance the value approaches the amplification factor.

VOLTMETER - An instrument for measuring voltage.

VOLT-OHM-MILLIAMMETER - A test instrument having provisions for measuring voltages, resistances, and small currents. It consists essentially of a single meter having the necessary number of scales and a switch which places the meter in the correct circuit for a particular measurement.

-W-

WATT - The practical unit of electrical power, and in a direct-current circuit, equal to volts multiplied by amperes. In an alternating-current circuit, true watts are equal to effective (rms) volts multiplied by effective amperes, then multiplied by the factor.

WAVE GUIDE - A system of conducting boundaries (such as a copper duct) capable of guiding electromagnetic waves.

WIRE - A rod, filament, or group of strands forming a metallic conductor having practically uniform thickness. Used in radio and electronics to provide a path for electric current between two points.

WIRE GAUGE - A system of numerical designations of wire sizes, starting with low numbers for the largest sizes. The American wire gauge, abbreviated AWG (formerly the Brown and Sharpe gauge, abbreviated B & S gauge) is in common use in the United States and starts with 0000 as the largest size, going to 000, 00, 0, 1, 2, and up to 40 and beyond for the smallest sizes.

WIRING DIAGRAM - A pictorial diagram showing physical location of parts and terminating connections for illustrating the actual wiring of the electrical parts or equipment. Usually views of the wiring sides of assemblies are preferred.

WIRING HARNESS - Insulated wires, parallel or twisted with or without shields, which connect electrical circuits and which are properly bound together with lacing tape or braid. The individual wires are usually identified by color or number code. Various components may or may not be attached to the ends of the harness wires.

appendix C

APPENDIX C

INDEX

- Adapter 1.5.18B
- Alignment
 - Appearance Items 4.10.3
 - Gears 4.2.1, 4.2.2
 - Rotary Switch 4.6.2B
 - Switch or Relay 4.6.1A,G
- Arcing Due to Burrs 4.1.3B
- Arcing Due to Screw 3.1.5C2
- Backlash 4.2.1, 4.2.4C, 4.2.5A
- Bending
 - Cable 1.3.1D, 1.3.2A
 - Coaxial Cable 1.2.1B
 - Leads 2.4, 5.4.1, 6.1.2
 - Parts 4.1.4B
 - Wire 1.1.4E, 1.4.1
- Brinelling 4.4.2A
- Burnishing 4.4.3A2, 4.6.1E
- Cable Clamps 1.3.2J
- Ceramic Material 3.6.3
 - Tapped Holes 3.1.4B
- Chamfer 1.1.5A
 - Bearing 4.4.1A
- Clearance and Spacing 4.1.1, 6.8
 - Bus Wire 1.4.3
 - Coils 1.9.2B
 - Components 2.6.10, 2.6.11
 - Gear 4.2.1, 4.2.4A, 4.2.5B
 - Stud Mounted Component 2.6.16
 - Clinch 5.3.1
- Coil Form 1.9.5, 1.9.10D
 - Damage 1.9.12
 - Slug Action 4.5.3
- Color Coding
 - Capacitor A-1, A-2, A-3, A-4
 - Choke Coil A-5
 - Diode A-6
 - Resistor A-2
 - Wire 1.1.2A, E
- Committees Pages ii, iii
- Conductor Defects 1.1.3, 6.1.4
 - Prevention 1.4.5
- Crimping 1.7.2
 - Adapter 1.5.18B
 - Component Leads 2.4.1
 - Shield Terminations 1.2.2E
 - Wire Wrap 1.5.1
- Design, Preface, Page i
 - Clearance 4.1.1A, B
 - Coil Winding 1.9.13
 - Component Arrangement 2.6.12
 - Compressible Washers 3.6.3
 - Gear Loading 4.2.5C
 - Gear Mesh 4.2.4B
 - Leads as Terminals 1.5.14
 - Terminal Spacing 1.5.11
- Distortion of Parts 4.1.4C
- Eyelet 3.5.1, 3.5.2C, 3.5.3
 - Definition 5.2.1A
 - Printed Circuit 5.2.2A, D
 - Masking 5.5.4D
 - Shielded Wire Fig. 1-4B
- Float 1.5.8, 1.5.18D
- Flushness 3.1.2, 3.5.2A
- Fillister Head Screw Fig. 3-1
- Fungus Resistance 4.11.3
- Fuse Connections 1.11
 - Fuse Post 2.6.18
- Grommet 1.1.5A; Fig. 1-1; 1.3.3A
- Ground
 - Capacitor 2.6.19
 - Clean Metallic 3.1.1C
 - Connections 1.11
 - Eyelet 5.2.2A
 - Lock Washer 3.6.2E
 - Shielding 1.2.2B, E
- Heat Dissipating Parts 2.6.11
- Heat, Excessive 1.3.2G
- Heat Sinks Fig. 1-16, 1.6.3D, 2.6.12
- Hub, Pinned 4.8, Fig. 4-21
- Hubs, Split 4.2.6
- Identations in Wire 1.1.3C2
- Inserts, Thread 3.1.4D, 3.1.8

Liquid Staking 3.6.3, 3.7.1, 3.7.3
 Not in Coil Form 4.5.3
 Not on Contact Area 4.6.1B
 Not on Slug Adjustment 4.5.4

Loaded Gear 4.2.5
 Burrs 4.1.3B6
 Definition 4.2.1
 Separated Sections Fig. 4-6
 Toothiness 4.2.4A

Locking Devices, Misc. 3.7
 Locking Nuts 3.4.3, 3.6.1
 Optimum Torque 3.1.6
 Screw Projection 3.1.5B

Lock Washers 3.6.2
 Material 3.1.1B

Lubrication 4.9
 Bearing 4.4.1C, 4.4.2D, 4.4.3A
 Clamp Screw 4.2.6
 Gear 4.2.3
 Module Screw 3.1.8A

Lug 1.5.12; 1.7.1, 1.7.2A, D, 3.4.3C

Markings 4.11, 2.4.2, 5.3.1d

Mesh, Gear 4.2.4
 Definition 4.2.1

Nameplates 4.11.6, 3.1.4E

Nicks in Wire 1.1.3C4

Noise in Ball Bearings 4.4.2C

Nonmetallic Material 3.6.1, 3.7.7

Nuts 3.4
 On Nonmetallic Material 3.7.7
 Sheet Spring Nuts 3.7.4
 Stray 3.9
 Thickness 3.1.4A, 3.4.2
 Thread Engagement 3.1.5B

Oilite Bearings 4.4.3

Piggy-Back 2.6.8

Pigtail Fig. 1-4A, D

Pinched Wire 1.1.4

Pinning 4.8
 Removing Setscrew 3.2.1

Press - Sleeve Bearing 4.4.1A

Press Fit for Bearing 4.4.2E

Pressing in Assembly 4.1.4C

Process Specifications 4.12
 Cable and Connector 1.2.2G
 Decals 4.11.2A
 Printed Circuits 5.1

Revisions, Preface, Page i

Riveting 3.5, 4.1.4C

Rosin 1.6.4B, 4.1.2F
 Not on Heat Sink 2.6.12

Routing Wire 1.1.4, 1.1.5A-E
 Cable 1.1.6B, 1.3.2A-G, Fig. 1-6

Runout, Gear 4.2.2A
 Definition 4.2.1

Runout, Tuning Slug Rack 4.5.1

Screw Threads 3.1.3, 3.1.4

Setscrew 3.2
 Clamping Gear 4.2.6
 In Pinning 3.2.1

Sharp Objects 1.1.5C, 1.3.3C
 Cable Marking Bands 4.11.4
 Edges 1.3.3B, 2.6.9, 4.1.3
 Shielding 1.2.2D, Fig. 1-5E

Slack
 Bus Wire 1.4.2
 Definition 1.1.1C
 Cable 1.1.4C, 1.1.6B
 Wire 1.1.6C, D

Sleeve Bearings 4.4.1A

Sleeving 1.8
 Bus Wire 1.4.4
 Cable 1.3.3B, C
 Shielded Wire 1.2.2F
 Thermoplastic and Teflon 2.4.4
 Wire 1.1.5B, C, H

Soft Materials
 Proper Washer 3.6.2E3
 Tapped Metal 3.1.4C, D, E

Soldering 1.6
 Clearance 4.1.1B
 Component 2.4.6, 2.6.5, 2.6.6, 2.6.12
 Cup Terminal 1.5.19, D, E
 Insulation Interference 1.1.6G
 Mechanical Connections 1.5
 Printed Circuit 5.5
 Shielded Braid 1.2.2F
 Snap-In Components 5.3.3
 Splatters 4.1.2F, 4.10.2
 Switch 4.6.1B, 4.6.2C
 Tinning 2.3.5
 Solder Fusion A-15

Solder Lugs 1.5.10, 1.5.12
 Internal Tooth 3.6.2E2

Spacer 3.6.1

Spacing 1.5.15, 1.5.18, 6.3

Staking 4.1.4C
 Bearing 4.4.2E
 Rivet 3.5.3
 Solder 3.7.2

Standoff 3.6.2E

Strain Relief 2.6.6; Fig. 2-4, 2-5; 5.3.1a
 Cable 1.3.2H, I
 Threaded Leads 1.5.8

Strands 1.1.3C
Coil 1.9.3
Tantalum Leads 2.4.5
Threaded Studs 3.1.5D
Thread Insert 3.1.4D
Chassis 3.1.8A
Thrust Loading of Bearing 4.4.2C
Tooling for Riveting 3.5.1, 3.5.3
Tools
Cable Marking Band 4.11.4
Crimping 1.7.2C
Lacing Awl Fig. 1-8C
Lead Bending 2.4.5
Screwdrivers 3.1.7, 3.2.2, 3.6.2D
Soldering 1.6.3B, C; 2.6.12
Stripping 1.1.3B
Toothiness 4.2.1, 4.2.4A
Torque
Bearing 4.4.1B
Clamp 4.2.6
Detent 4.3.1
Screw 3.1.6
Switch 4.6.2A
Table A-21

Transistor Base A-8
Transistor Mounting 2.6.12
Transistor Leads 6.1.2, 6.7
Transistor Socket 5.3.3

Varnish 4.6.1B
On Stamping 4.11.3

Wire Length
Bus Wire 1.4.3
Point-to-Point 1.1.6E
Tolerance 1.1.3D
Wire Routing 1.1.4, 1.1.5C, D, E
Shielded Wire 1.2.1A

Other Subjects May be Found in the
Following:

Table of Contents Page iv
List of Illustrations Page xiii
List of Tables Page xi

